Spilay m2011

Spilay Gibbon Sushi Japanese Style DIY Dollhouse Miniature Kit

Model: m2011

1. Introduction

Thank you for choosing the Spilay Gibbon Sushi Japanese Style DIY Dollhouse Miniature Kit. This kit provides an engaging and rewarding experience for constructing a detailed 1:24 scale miniature Japanese sushi restaurant. Designed for adults and teenagers, this model features intricate wooden furniture and various accessories to create a vibrant scene. Please read this manual carefully before beginning assembly to ensure a smooth and enjoyable building process.



Image 1.1: The fully assembled Spilay Gibbon Sushi Japanese Style DIY Dollhouse Miniature Kit.

2. Package Contents

Your Spilay Gibbon Sushi DIY Dollhouse Miniature Kit includes the following components:

- Pre-cut wooden pieces for the dollhouse structure and furniture.
- Fabric and paper materials for decorations and accessories.
- Small plastic components for various details.
- LED lighting components for illumination.
- Music box mechanism.
- Dust cover for protection of the finished model.
- Detailed English instruction manual with illustrations.

Note: Silicone liquid glue and two AAA batteries are NOT included in this kit and must be purchased separately.



Image 2.1: Overview of included items and product dimensions.

3. Safety Information

Please observe the following safety guidelines during assembly:

- This kit contains small parts and is not suitable for children under 14 years of age due to choking hazards.
- Use sharp tools (e.g., craft knife, scissors) with extreme caution. Adult supervision is recommended for younger builders.
- Ensure proper ventilation when using adhesives. Avoid contact with skin and eyes.
- Dispose of waste materials responsibly.
- Keep batteries out of reach of small children.

4. Setup and Assembly

Assembly of this dollhouse kit requires patience and attention to detail. Follow the steps outlined in the included English manual. The estimated completion time is 3-4 days, depending on individual pace.

4.1 Required Tools (Not Included)

- Silicone liquid glue (or other suitable craft adhesive for wood, paper, and fabric).
- Scissors.
- Craft knife or precision cutter.
- Tweezers (often helpful for small parts).
- Ruler.
- Two AAA batteries for the lighting system.

4.2 General Assembly Steps

1. **Preparation:** Unpack all components and organize them according to the manual's part list. Familiarize yourself with the instructions and diagrams.
2. **Cutting and Shaping:** Carefully cut out paper and fabric components as indicated. Some wooden pieces may require light sanding for a perfect fit.
3. **Gluing:** Apply glue sparingly to ensure clean assembly. Allow sufficient drying time for each section before proceeding.
4. **Wiring (Lighting):** Follow the wiring diagrams precisely to connect the LED lights. Ensure all connections are secure.
5. **Detailing:** Assemble the miniature furniture and decorative elements. Pay close attention to the placement of small accessories like sushi, plants, and lanterns.
6. **Final Assembly:** Combine all sections of the dollhouse and install the music box and dust cover.

Product Information

Brand: Spilay
Name: Gibbon Sushi
Finish time: 3-4 DAY
Material:wood . paper. plastic
Finish size: 22*17.5*19.5 cm
Weight: 1.6 KG / 3.53 LB

Included: All furniture . Dust cover . Music box .

Difficulty : ★★★☆☆



Dust cover Music box

Suitable for 14+ years old

Festival & Birthday Gift
Collection
Crafts
Home Decoration



NOTE:

* **The dollhouse need to assembled by yourself**
* **Not included glue and batteries**
* **Small parts, Not for children under 3 yrs**



Image 4.1: Detailed view of the miniature sushi and interior decor, illustrating the intricate assembly required.



Image 4.2: Exterior details such as lanterns and miniature sake barrels, which are part of the assembly process.

5. Operating Instructions

5.1 Lighting System

The dollhouse features an integrated LED lighting system. To activate the lights:

1. Ensure two AAA batteries are correctly installed in the battery compartment (not included).
2. Locate the power switch, typically found on the base or side of the dollhouse.
3. Toggle the switch to the 'ON' position to illuminate the miniature scene.



Image 5.1: The dollhouse illuminated, showcasing the functional LED lighting system.

5.2 Music Box

The kit includes a music box to add an auditory element to your miniature. To operate the music box:

1. Once installed, locate the winding key or mechanism for the music box.
2. Gently wind the mechanism to play the melody.

Your browser does not support the video tag.

Video 5.1: A preview demonstrating the assembled dollhouse with its lighting and music box features.

6. Maintenance

To keep your Spilay dollhouse miniature in excellent condition:

- **Dust Protection:** Always use the provided dust cover when the dollhouse is not being actively viewed or handled to prevent dust accumulation.

- **Cleaning:** Gently wipe surfaces with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, which can damage the delicate components.
- **Storage:** Store the dollhouse in a stable, dry environment away from direct sunlight and extreme temperatures to prevent material warping or fading.



Image 6.1: The dollhouse protected by its clear dust cover, essential for maintenance.

7. Troubleshooting

If you encounter any issues during assembly or operation, refer to the following common solutions:

- **Missing Parts:** While kits are checked for completeness, if you find any missing parts, please contact Spilay customer support with details of the missing component.
- **Lights Not Working:**
  - Check if batteries are correctly inserted and have sufficient charge.
  - Verify all wiring connections are secure and follow the diagram in the manual.
  - Ensure the power switch is in the 'ON' position.

- **Pieces Don't Fit:** Double-check the part numbers against the manual's diagrams. Some pieces may require gentle sanding or trimming for a precise fit. Avoid forcing components.
- **Warped Wood Pieces:** Minor warping can sometimes occur. Apply gentle pressure during gluing and allow ample drying time. For significant warping, contact customer support.

8. Specifications

Feature	Detail
Model Number	m2011
Scale	1:24
Finished Dimensions (L x W x H)	22 x 17.5 x 19.5 cm (8.66 x 6.89 x 7.67 inches)
Weight	Approximately 1.6 kg (3.53 lbs)
Materials	Wood, Paper, Cloth, Plastic, Silicone
Recommended Age	14+ years / Adult
Batteries Required	2 x AAA (not included)
Included Features	LED Lights, Music Box, Dust Cover

9. Warranty and Support

Spilay is committed to providing high-quality products. If you have any questions, require assistance with assembly, or encounter any issues with your kit, please do not hesitate to contact Spilay customer support. Refer to your purchase documentation or the Spilay brand store for contact information.

We hope you enjoy the creative process and the beautiful finished miniature dollhouse!

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question