Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hoont H974VNDR

Hoont Bug Zapper Racket H974VNDR - Instruction Manual

Model: H974VNDR

Introduction

Thank you for choosing the Hoont Electric Fly Swatter Racket. This manual provides essential information for the safe and effective use of your new bug zapper. Please read these instructions carefully before operation and retain them for future reference.



Image: Two Hoont Electric Fly Swatter Rackets, featuring black handles and orange frames with a visible metal grid, indicating the product's design.

Important Safety Instructions

To reduce the risk of injury or electric shock, always follow these basic safety precautions:

- This device generates high voltage. Do not touch the inner metal grid with fingers or other conductive objects while the device is active.
- Keep out of reach of children and pets. This is not a toy.
- Do not use near flammable gases or liquids.
- Do not use in areas where water or moisture is present. Avoid contact with water.
- Do not attempt to modify or repair the device. Refer all servicing to qualified personnel.
- Remove batteries if the device will not be used for an extended period.
- Dispose of used batteries properly according to local regulations.

Package Contents

- 2 x Hoont Electric Fly Swatter Rackets (Model H974VNDR)

Note: 2 AA batteries per racket are required and are not included in the package.

Setup

1. Locate the battery compartment cover on the handle of the racket.
2. Slide or open the cover to access the battery compartment.
3. Insert two (2) AA batteries into the compartment, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Close the battery compartment cover securely.
5. Repeat for the second racket.

Operating Instructions

To activate and use your Hoont Electric Fly Swatter Racket:

1. Ensure batteries are correctly installed.
2. Press and hold the activation button located on the handle. A small indicator light (usually green) will illuminate, signifying that the grid is energized.
3. While holding the button, swing the racket towards the target insect. When the insect makes contact with the electrified grid, a "zap" sound will be heard, indicating it has been neutralized.
4. Release the activation button after use. The indicator light will turn off, and the grid will de-energize.



Image: A detailed view of the Hoont Electric Fly Swatter Racket handle, highlighting the activation button and the green indicator light, which signals when the device is active.

Maintenance

- **Cleaning:** After use, ensure the device is off and the activation button is released. Gently brush off any insect debris from the grid using a soft, dry brush. Do not use water or cleaning solutions on the grid.
- **Storage:** Store the racket in a dry place, away from direct sunlight and moisture. Remove batteries if storing for extended periods.
- **Battery Replacement:** Replace batteries when the indicator light dims or the zapping power decreases. Follow the setup instructions for battery insertion.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Racket does not turn on / Indicator light does not illuminate.	◦ Batteries are dead or low. ◦ Batteries are inserted incorrectly. ◦ Activation button not pressed or faulty.	◦ Replace with new AA batteries. ◦ Check battery polarity and reinsert correctly. ◦ Ensure the activation button is fully pressed and held.
Racket zaps weakly or not at all.	◦ Batteries are low. ◦ Grid is dirty with insect debris.	◦ Replace with new AA batteries. ◦ Clean the grid gently with a dry brush (ensure device is off).
Insect is not zapped on contact.	◦ Insect did not make contact with both inner and outer grids. ◦ Insect is too small or too large.	◦ Ensure full contact with the grid. ◦ Multiple attempts may be necessary for certain insects.

Specifications

- **Model:** H974VNDR
- **Brand:** Hoont
- **Color:** Black
- **Material:** Metal
- **Power Source:** 2 x AA Batteries (per racket, not included)
- **Product Dimensions:** Approximately 19.6 x 8.5 x 2.5 inches (50 x 21 x 6.35 cm)
- **Item Weight:** Approximately 1.28 pounds (0.58 kg) per racket
- **Target Species:** Fly, Gnat, Mosquito, Moth, Wasp



Image: A Hoont Electric Fly Swatter Racket with overlaid measurements, indicating a length of 19.6 inches (50 cm) and a width of 8.2 inches (21 cm).

Warranty and Support

For information regarding warranty coverage, product support, or to contact customer service, please refer to the manufacturer's official website or the retailer from whom the product was purchased. Please have your model number (H974VNDR) available when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B081ZBXWPJ

More documents and user manuals: **https://manuals.plus/**