Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aigostar Windy

Aigostar 40" Oscillating Tower Fan User Manual

Model: Windy

Introduction

Thank you for choosing the Aigostar 40" Oscillating Tower Fan. This manual provides important information for the safe operation, installation, and maintenance of your new fan. Please read it thoroughly before use and keep it for future reference.
This tower fan is designed to provide efficient and quiet cooling for various indoor spaces. It features multiple wind modes, speed settings, a programmable timer, and convenient remote control operation.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the fan is placed on a stable, level surface to prevent tipping.
- Do not insert fingers or foreign objects into the fan grilles.
- Keep the fan away from water or excessive humidity.
- Unplug the fan from the power outlet before cleaning or performing any maintenance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- The bladeless design enhances safety, especially around children and pets.

Package Contents

Please check the package for the following items:

- Aigostar 40" Tower Fan Unit
- Remote Control
- Power Cord
- User Manual (this document)

Setup

Follow these steps to assemble and set up your tower fan:

1. **Base Assembly:** Attach the fan base to the main unit. Ensure it is securely fastened using the provided screws.



Image: The Aigostar 40-inch tower fan, showing its sleek design, remote control, and the direction of airflow. This image represents the overall product and its primary function.



Image: A close-up view of the fan's top control panel and a hand holding the remote control, highlighting the ease of operation.

2. **Placement:** Place the fan on a firm, level surface in the desired location. Ensure there is adequate space around the fan for

optimal airflow and oscillation.



Image: Diagram illustrating the dimensions of the Aigostar tower fan, including its 40-inch height, to help users understand its physical size for placement.

3. **Power Connection:** Plug the power cord into a standard North American 3-prong electrical outlet (120 Volts).

Setup Video Guide

[redacted]

Video: An official Aigostar video demonstrating the setup and key features of the 40-inch oscillating tower fan, including its remote control and quiet operation.

Operating Instructions

Your Aigostar Tower Fan can be operated using the touch control panel on top of the unit or the included remote control.

Control Panel & Remote Control



Image: A detailed view of the fan's control panel and remote, illustrating the various buttons and LED indicators for modes, speeds, and timer settings.

- **Power (ON/OFF):** Press to turn the fan on or off.
- **Speed:** Cycle through 3 wind speeds: Low (L), Medium (M), High (H).
- **Mode:** Select from 3 working modes:
  - **Normal:** Constant airflow at selected speed.
  - **Nature:** Simulates natural breeze by varying fan speed.
  - **Sleeping:** Gradually decreases fan speed and dims control lights for quiet operation during sleep.



Image: Visual representation of the three distinct wind modes (Sleeping, Nature, Normal) and their associated fan speed characteristics.

- **Oscillation (OSC):** Press to turn the 60° oscillation function on or off, promoting air circulation across a wider area.
- **Timer:** Set the automatic shut-off timer from 0.5 to 7.5 hours. The LED lights on the control display will indicate the total set time.

Maintenance

Regular maintenance ensures optimal performance and longevity of your fan.

- **Cleaning:** Always unplug the fan before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or allow water to drip into the internal components.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging to protect it from dust.

Troubleshooting

If you encounter any issues with your fan, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet malfunction; Power button not pressed.	Ensure the power cord is securely plugged into a working outlet. Press the ON/OFF button.
Weak airflow.	Fan speed set too low; Obstruction in air intake/outlet.	Increase the fan speed. Check for and remove any obstructions from the grilles.
Oscillation not working.	Oscillation function is off.	Press the OSC button on the control panel or remote to activate oscillation.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and fan.	Replace remote control batteries (1 Lithium Ion battery required). Ensure no obstructions are blocking the signal.

If the problem persists after trying these solutions, please contact customer support.

Specifications

Brand: Aigostar

Model Name: Windy

Product Dimensions: 10.2"D x 10.2"W x 40"H

Power Source: Corded Electric

Voltage: 120 Volts

Wattage: 50 watts

Noise Level: 52 dB

Air Flow Capacity: 22 Cubic Feet Per Second

Control Method: Remote, Touch Panel

Number of Power Levels: 3 (Low, Medium, High)

Timer: 0.5 - 7.5 hours

Oscillation: 60 degrees

Item Weight: 8.4 Pounds

Material Type: Plastic

Certification: ETL

Warranty and Support

Aigostar products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included with your product or visit the official Aigostar website. You can also contact Aigostar customer service through the details provided on their Amazon store page.
Visit the Aigostar Store on Amazon

© 2025 Aigostar. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0823V1TJT

More documents and user manuals: **https://manuals.plus/**