SanDisk SDSDUNR-128G-GN6IN R6

SanDisk 128GB SD Ultra Memory Card User Manual

Model: SDSDUNR-128G-GN6IN R6
Brand: SanDisk

Product Overview

This manual provides instructions for the SanDisk 128GB SD Ultra Memory Card, bundled with an Everything But Stromboli Multi-Slot Card Reader and a Microfiber Cloth. This high-speed memory solution is designed for use with compatible digital cameras and other devices, enabling efficient capture and transfer of high-quality photos and Full HD videos.



Image: The complete product bundle, including the SanDisk 128GB SD Ultra Memory Card, the Everything But Stromboli Multi-Slot Card Reader, and a microfiber cleaning cloth.

Setup and Installation

1. Inserting the SD Card into a Device

1. Locate the SD card slot on your compatible digital camera, camcorder, or other device. Refer to your device's manual for exact location and orientation.
2. Ensure the SD card is oriented correctly, with the metal contacts facing the device's contacts.
3. Gently push the SD card into the slot until it clicks into place. Do not force the card.
4. Close the card slot cover, if applicable.



Image: A detailed view of the SanDisk 128GB SD Ultra Memory Card, showing its front face with capacity and speed markings.

2. Using the Everything But Stromboli Multi-Slot Card Reader

1. Insert the SanDisk SD card into the appropriate slot on the Everything But Stromboli Multi-Slot Card Reader. The reader supports SD, Micro SD, M2, and MS formats.

2. Connect the USB end of the card reader to an available USB port on your computer.
3. Your computer should automatically detect the card reader and the inserted memory card as a removable drive.



Image: The Everything But Stromboli Multi-Slot Card Reader with its protective cap removed, revealing the USB connector and various memory card slots.

Operating Instructions

1. Capturing Photos and Videos

Once the SD card is correctly inserted into your camera, it will be ready to store photos and videos. Ensure your camera settings are configured to save media to the SD card. The SanDisk Ultra card's Class 10 and UHS-I speed rating supports Full HD video recording and rapid-fire photo capture.

2. Transferring Data to a Computer

1. With the SD card inserted into the card reader and connected to your computer, open 'My Computer' or 'This PC' (Windows) or 'Finder' (Mac).
2. Locate the removable drive corresponding to your memory card.
3. Open the drive to access your photos and videos. You can drag and drop files to your computer's hard drive or use copy/paste functions.
4. After transferring, safely eject the removable drive from your operating system before physically disconnecting the card reader.

3. Formatting the SD Card

Warning: Formatting an SD card will erase all data on it. Back up any important files before proceeding.

- It is recommended to format the SD card directly within the device (camera) you intend to use it with. Refer to your device's manual for specific formatting instructions.

- Alternatively, you can format the card via your computer's disk management tools. Right-click on the removable drive, select 'Format', and choose the appropriate file system (e.g., exFAT for 128GB cards).

Maintenance and Care

1. SanDisk SD Card Care

- **Physical Handling:** Avoid touching the gold metal contacts on the card. Hold the card by its edges.
- **Environmental Protection:** The card is waterproof, temperature-proof, X-ray proof, magnet-proof, and shockproof. However, prolonged exposure to extreme conditions should be avoided.
- **Storage:** Store the card in its protective case or a dedicated memory card holder when not in use to prevent damage.

2. Everything But Stromboli Multi-Slot Card Reader Care

- Keep the USB connector clean and free of dust. Use the protective cap when not in use.
- Avoid dropping or subjecting the reader to physical impact.

3. Microfiber Cloth Care

- Use the microfiber cloth to gently clean camera lenses, screens, or the surface of the memory card and reader.
- Wash the cloth periodically with mild soap and water, then air dry. Do not use fabric softeners.



Image: The Everything But Stromboli branded microfiber cleaning cloth, useful for maintaining electronic devices.

Troubleshooting

- **Card Not Recognized:**
  - Ensure the card is fully inserted into the device or card reader.
  - Try inserting the card into a different compatible device or a different USB port on your computer.
  - Check if the card's write-protect switch (small slider on the side of the SD card) is in the unlocked position.

- Restart your computer or camera.

- **Slow Transfer Speeds:**
  - Ensure you are using a USB 3.0 port on your computer for optimal speeds, if available.
  - Close other applications that might be using system resources.
  - Verify the card reader is functioning correctly.

- **Data Corruption or Errors:**
  - Always safely eject the memory card from your computer before removing it.
  - Avoid removing the card during data transfer or while the device is writing to it.
  - If errors persist, try formatting the card (remembering to back up data first).

Specifications

Feature	Detail
Brand	SanDisk & Everything But Stromboli
Model Name	SDSDUNR-128G-GN6IN R6
Flash Memory Type	SDHC (compatible with SDXC devices)
Memory Storage Capacity	128 GB
Read Speed	Up to 120 MB/s
Write Speed	80-90 MB/s (typical for UHS-I Class 10)
Secure Digital Association Speed Class	Class 10 / UHS Speed Class 1 (U1)
Hardware Interface	SDXC
Special Features	Waterproof, Temperature-proof, X-ray proof, Shockproof, Magnet-proof
Compatible Devices	Cameras (specifically Panasonic Lumix models listed in product description), and other SDXC compatible devices.

Warranty and Support

Warranty Information

The SanDisk Ultra UHS-I cards come with a 10-year limited warranty. For specific terms and conditions, please refer to the official SanDisk warranty documentation or visit the SanDisk support website.

The Everything But Stromboli Multi-Slot Card Reader and Microfiber Cloth are covered by their respective manufacturer's warranties, if any. Please refer to their packaging or documentation for details.

Customer Support

For technical assistance or support regarding your SanDisk product, please visit the official SanDisk support website. For inquiries related to the Everything But Stromboli accessories, please contact their customer service directly.

Always ensure you have your product model number and purchase information available when contacting support.

© 2024 SanDisk. All rights reserved. Information in this manual is subject to change without notice.