Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Easytry123 Easytry8771

Easytry123 Universal Remote Control Instruction Manual

For JVC LCD LED HDTV TVs (Models: RM-C18301C, RM-C742, RM-C2031C, RM-C203G, RM-C203G1C, RM-C205, RM-C2051C, RM-C2060)

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Easytry123 Universal Remote Control. This remote is designed as a replacement for various JVC LCD LED HDTV TV models, including RM-C18301C, RM-C742, RM-C2031C, RM-C203G, RM-C203G1C, RM-C205, RM-C2051C, and RM-C2060. It is also noted to be compatible with certain Yamaha models such as RAV272, RAV273, RAV353, RAV352, RAV323, RAV361, RAV362, RAV358, RAV359. Please review this guide thoroughly to ensure proper use.



Image: Front view of the Easytry123 Universal Remote Control. This image displays the layout of all buttons, including power, input, channel, volume, number pad, and navigation controls, highlighting its ergonomic design.

Setup

Before using your new remote control, you must install batteries. This remote requires two AAA batteries (not included).

1. **Open the Battery Compartment:** Locate the battery compartment cover on the back of the remote control. Slide the cover downwards or press the latch and lift to open.
2. **Insert Batteries:** Insert two new AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. **Close the Battery Compartment:** Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control with the battery cover removed, illustrating the correct orientation for inserting two AAA batteries into their respective slots.

This remote control is designed as a direct replacement for the specified JVC TV models. In most cases, no programming is required; simply insert the batteries and begin use. If certain advanced functions do not operate as expected, please note that full functional equivalence to your original remote cannot be guaranteed for all features.

Operating Instructions

Once batteries are installed, point the remote control directly at your television. Ensure there are no obstructions between the remote and the TV's infrared sensor.

- **Power Button:** Press the **POWER** button to turn your TV on or off.
- **Input/Source:** Use the **INPUT** or **SOURCE** button to cycle through available video inputs (HDMI, AV, Component, etc.).
- **Channel Selection:** Use the number buttons (**0-9**) to directly enter channel numbers. Use **CH+** and **CH-** to navigate channels sequentially.
- **Volume Control:** Press **VOL+** to increase volume and **VOL-** to decrease volume.
- **Mute:** Press the **MUTE** button to temporarily silence the TV audio. Press again to restore sound.
- **Navigation Buttons:** Use the directional arrows (**UP, DOWN, LEFT, RIGHT**) and the **OK/ENTER** button in the center to navigate menus and confirm selections.
- **Menu/Settings:** Access your TV's main menu or settings using the **MENU** or **SETTINGS** button (if present).
- **Playback Controls:** If your TV supports media playback, use buttons like **PLAY, PAUSE, STOP, REW, FWD**.

Note: The functionality of certain buttons may vary depending on your specific JVC TV model and its features. Refer to your television's original manual for detailed information on its functions.

Maintenance

Proper care will extend the life of your remote control.

- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in liquid.
- **Battery Replacement:** Replace batteries when the remote's performance degrades or if it stops responding. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage, which can damage the device. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact. Dropping it can damage internal components.

Troubleshooting

If you encounter issues with your remote control, try the following steps:

1. **Remote Not Responding:**
   - Check if the batteries are inserted correctly with the correct polarity (+/-).
   - Replace the batteries with fresh AAA batteries.
   - Ensure there are no obstructions between the remote control and the TV's infrared sensor.
   - Make sure you are within a reasonable range and pointing the remote directly at the TV.
2. **Certain Buttons Not Working:**
   - This remote is a replacement and may not support all advanced functions of your original TV remote. Refer to the original TV manual for specific feature compatibility.
   - Verify that the button is clean and not stuck.
3. **TV Not Responding to Any Commands:**
   - Confirm that your TV is powered on.
   - Try using the manual controls on your TV to ensure the TV itself is functioning correctly.

If problems persist after trying these steps, please refer to the Warranty and Support section for further assistance.

Specifications

Brand	Easytry123
Model Number	Easytry8771
Compatible Devices	JVC LCD LED HDTV TVs (RM-C18301C, RM-C742, RM-C2031C, RM-C203G, RM-C203G1C, RM-C205, RM-C2051C, RM-C2060) and compatible Yamaha models (RAV272, RAV273, RAV353, RAV352, RAV323, RAV361, RAV362, RAV358, RAV359)
Connectivity Technology	Infrared
Controller Type	Button Control
Batteries Required	2 x AAA (not included)

Special Features	Ergonomic design, Direct replacement functionality
ASIN	B0825QV62X

Warranty

This Easytry123 Universal Remote Control comes with a **90-day quality warranty**. In case of any manufacturing defects or quality issues within this period, a hassle-free return or replacement is available. Please retain your proof of purchase for warranty claims.

Support

For further assistance, troubleshooting not covered in this manual, or warranty claims, please contact the seller directly through the platform where the product was purchased. Provide your order number and a detailed description of the issue for prompt support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0825QV62X

More documents and user manuals: **https://manuals.plus/**