Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY N2QAYB000829

ALLIMITY N2QAYB000829 Replacement Remote Control User Manual

Model: N2QAYB000829

1. Introduction

This user manual provides comprehensive instructions for the ALLIMITY N2QAYB000829 Replacement Remote Control. This remote is designed as a direct replacement for various Panasonic Vier TV models, offering seamless functionality without complex setup. Please read this manual thoroughly before use to ensure proper operation and longevity of your device.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the remote control to direct sunlight, heat sources, or extreme temperatures.
- Avoid dropping the remote control or subjecting it to strong impacts.
- Do not immerse the remote control in water or any other liquids.
- Keep the remote control out of reach of small children to prevent accidental ingestion of small parts or batteries.
- If the remote control will not be used for an extended period, remove the batteries to prevent leakage.
- Dispose of used batteries according to local regulations. Do not dispose of batteries in fire.

3. Setup and Battery Installation

The ALLIMITY N2QAYB000829 remote control requires no complex programming or pairing. Simply install the batteries, and it will be ready for use with compatible Panasonic Vier TV models.

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open the compartment.
3. Insert two new AA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.




AA
AA



Figure 3.1: Battery compartment of the ALLIMITY N2QAYB000829 remote control, showing where to insert AA batteries.

Note: This remote control is designed to work immediately after battery installation with compatible Panasonic Vier TV models. No additional setup or code entry is required.

4. Operating Instructions

The ALLIMITY N2QAYB000829 remote control features a standard layout for Panasonic Vier TVs. Below is a guide to its primary functions:





Figure 4.1: Overview of the ALLIMITY N2QAYB000829 Remote Control.

4.1 Button Functions

Button	Function
POWER (Red Button)	Turns the TV On or Off.
MENU	Accesses the TV's main menu.
INPUT / TV / AV	Selects the input source (HDMI, AV, etc.).
TEXT / STTL / ASPECT	Accesses Teletext, Subtitles, or adjusts screen aspect ratio.
EXIT	Exits the current menu or function.
i (Info)	Displays information about the current program or input.
HOME	Accesses the TV's Smart Home screen or main interface.
APPS	Opens the applications menu.
GUIDE	Accesses the Electronic Program Guide (EPG).
Navigation Pad (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms selections.
OPTION	Displays context-sensitive options.

Button	Function
BACK / RETURN	Goes back to the previous screen or menu.
Volume Up (+) / Down (-)	Adjusts the volume level.
MUTE	Mutes or unmutes the TV sound.
Channel Up (^) / Down (v)	Changes TV channels.
Number Buttons (0-9)	Direct channel selection or numerical input.
? HELP	Accesses the TV's help menu.
LAST VIEW	Switches to the previously viewed channel or input.
Colored Buttons (Red, Green, Yellow, Blue)	Context-sensitive functions, often used in menus or smart TV features.
Playback Controls (Rewind, Play, Fast Forward, Stop, Pause, Record)	Controls media playback (e.g., USB, streaming apps).

5. Maintenance and Care

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not spray cleaner directly onto the remote.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- **Avoid Spills:** Keep liquids away from the remote control to prevent internal damage.

6. Troubleshooting

If you experience issues with your remote control, please refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Remote control is not working.	◦ Check if the batteries are inserted correctly with the correct polarity (+/-). ◦ Replace old or depleted batteries with new ones. ◦ Ensure there are no obstructions between the remote control and the TV's infrared sensor. ◦ Make sure you are within the effective operating range (typically up to 10 meters).
Some buttons are unresponsive.	◦ The button might be stuck. Gently press it multiple times to free it. ◦ Batteries might be low; try replacing them. ◦ Ensure the remote is pointed directly at the TV.

Problem	Possible Cause / Solution
Remote works intermittently.	◦ Batteries may be running low. Replace them. ◦ Ensure a clear line of sight to the TV's IR receiver. ◦ Strong light sources (e.g., direct sunlight, fluorescent lights) can interfere with the IR signal. Try to minimize such interference.

If the problem persists after trying these solutions, please contact the seller or manufacturer for further assistance.

7. Specifications

Feature	Detail
Brand	ALLIMITY
Model Number	N2QAYB000829
Connectivity Technology	Infrared
Compatible Devices	Panasonic Vier TV models including TX-39AS650E, TX-39ASW654, TX-40AS640B, TX-40AX630E, TX-40AXW634, TX-42AS650E, TX-42ASW654, TX-47AS650B, TX-47AS650E, TX-47ASW654, TX-48AS640B, TX-48AS640E, TX-48ASR650, TX-48AX630E, TX-48AXW634, TX-50AS650B, TX-50AS650E, TX-50ASW654, TX-55AS640B, TX-55AS640E, TX-55AS650B, TX-55ASW654, TX-55AX630E, TX-55AXR630, TX-55AXW634, TX-60AS650B, TX-60AS650E, TX-60ASR650, TX-60ASW654, TX-L42ET60E, TX-L42ET60Y, TX-L47ET60E, TX-L47ETW60, TX-L50ET60E, TX-L50ETW60, TX-L55ET60E, TX-L55ETW60, TX-P42ST60B, TX-P42ST60Y, TX-P42STW60, TX-P50ST60B, TX-P50ST60E, TX-P50ST60Y, TX-P55STW60, TX-P65STW60.
Maximum Range	10 Meters
Number of Buttons	10
Controller Type	Button Control
Battery Description	Alkaline (AA batteries required)
Special Feature	Ergonomic

8. Warranty and Support

Specific warranty information for the ALLIMITY N2QAYB000829 Replacement Remote Control is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please refer to the product listing on the retailer's website or contact the seller directly.
For general inquiries or troubleshooting beyond the scope of this manual, please reach out to the ALLIMITY customer

support if available, or the point of purchase.

© 2023 ALLIMITY. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082NCZ1HM

More documents and user manuals: **https://manuals.plus/**