Wster WS-1816

Wster WS-1816 Karaoke Speaker Microphone User Manual

Model: WS-1816

Introduction

This user manual provides comprehensive instructions for the safe and effective operation of your Wster WS-1816 Karaoke Sing Along Bluetooth Speaker Microphone. Please read this manual thoroughly before using the device and retain it for future reference.

The Wster WS-1816 Karaoke Speaker Microphone, showcasing its multi-functionality including Bluetooth connectivity, USB and TF card support, FM radio, recording, singing, and selfie functions. A smartphone is depicted connected wirelessly, demonstrating its use as a karaoke device.

Package Contents

Ensure all items listed below are present in your package:

- WS-1816 Unit (Karaoke Speaker Microphone)
- Charging USB Cable (Micro USB)
- Recording USB Cable
- User Manual

A visual representation of the Wster WS-1816 microphone in various colors, accompanied by the essential charging and recording USB cables included in the package.

Product Features

- Integrated Hi-Fi Microphone and Speaker
- Dynamic Disco Lights for enhanced ambiance
- Multiple Connectivity Options: Bluetooth, USB, TF Card
- Built-in FM Radio function
- Recording capability
- Selfie function support
- Output Power: 3W
- Built-in Rechargeable Battery: 1800mAh
- Frequency Range: 100Hz - 10KHz

- Maximum Sound Pressure Level: >115dB 1KHz TDH

Controls and Functions

Familiarize yourself with the control panel on the microphone handle:

- **MIC VOL:** Adjusts the microphone volume.
- **REMIX VOL:** Adjusts the echo effect volume.
- **MPOWER:** Power button (long press to turn on/off).
- **MODE:** Switches between Bluetooth, FM Radio, USB, and TF Card modes.
- **PREV:** Skips to the previous track (in music playback mode).
- **NEXT:** Skips to the next track (in music playback mode).
- **PLAY/PAUSE:** Plays or pauses music playback.
- **REC:** Initiates recording (requires a TF card or USB drive).
- **VOL+:** Increases master volume.
- **VOL-:** Decreases master volume.

Setup

1. **Charging the Device:** Connect the provided Micro USB charging cable to the charging port on the microphone and the other end to a USB power adapter (not included) or a computer USB port. The charging indicator light will illuminate. Once fully charged, the light will turn off or change color.
2. **Powering On:** Long press the **MPOWER** button until the device powers on and the disco lights illuminate.
3. **Bluetooth Pairing:**
    - Ensure the microphone is in Bluetooth mode (press **MODE** button if necessary).
    - On your smartphone or Bluetooth-enabled device, search for Bluetooth devices.
    - Select "WS-1816" from the list of available devices to pair. A confirmation sound will indicate successful pairing.
4. **Inserting Storage Media:** For music playback or recording, insert a TF card into the TF card slot or a USB drive into the USB port. The device will automatically switch to the corresponding mode or you can select it using the **MODE** button.

Operating Instructions

Music Playback

- **Bluetooth Mode:** Once paired with your device, play music from your smartphone. The audio will be output through the WS-1816 speaker.
- **USB/TF Card Mode:** Insert a USB drive or TF card with MP3 files. The device will automatically begin playing. Use **PREV**, **NEXT**, and **PLAY/PAUSE** buttons to control playback.
- **FM Radio Mode:** Press the **MODE** button to switch to FM radio. Use **PREV** and **NEXT** to scan for stations.

Karaoke Function

- Play your desired instrumental track via Bluetooth, USB, or TF card.
- Adjust your singing volume using the **MIC VOL** knob.
- Adjust the echo effect using the **REMIX VOL** knob for a professional karaoke sound.

- Ensure the microphone is positioned correctly for optimal sound pickup.

Recording Function

- Ensure a TF card or USB drive is inserted.
- While playing music or singing, press the **REC** button to start recording.
- Press **REC** again to stop recording. Recorded files will be saved to the inserted storage media.

Disco Lights

- The built-in disco lights will automatically activate when the device is powered on, adding a visual element to your performance.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the device. Do not use abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.
- **Storage:** Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Handle the device with care. Avoid dropping or subjecting it to strong impacts.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Battery is low or depleted.	Charge the device fully using the provided USB cable.
No sound from speaker.	Volume is too low; device not paired correctly; incorrect mode selected.	Increase master volume (VOL+); re-pair Bluetooth device; ensure correct mode (Bluetooth, USB, TF, FM) is selected.
Bluetooth connection fails.	Device is too far; interference; microphone not in pairing mode.	Ensure devices are within 10 meters; turn off other Bluetooth devices; restart microphone and try pairing again.
Microphone sound is distorted or too low.	MIC VOL is too low or too high; REMIX VOL is too high.	Adjust MIC VOL and REMIX VOL to appropriate levels.
Cannot record.	No TF card/USB drive inserted; storage full; media not formatted correctly.	Insert a compatible TF card or USB drive; check available storage; format media if necessary (this may erase data).

Specifications

Feature	Detail
Model	WS-1816
Brand	Wster
Output Power	3W

Feature	Detail
Frequency Range	100Hz - 10KHz
Max Sound Pressure Level	>115dB 1KHz TDH
Battery	Built-in Rechargeable 1800mAh
Power Source	Battery Powered
Connector Type	USB
Speaker Count	1
Item Weight	1.8 pounds (approx. 0.82 kg)
Dimensions (Approximate)	Height: 26 cm (10.2 inches) Width (top): 7.5 cm (3.0 inches) Width (speaker part): 5.4 cm (2.1 inches) Width (handle): 3.5 cm (1.4 inches)

Detailed dimensions of the WS-1816 microphone, indicating its height, and various width measurements for the top, speaker, and handle sections.

Warranty and Support

No specific warranty information is provided with this product. For support, please refer to the retailer or point of purchase for assistance with product inquiries or issues.

© 2024 Wster. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question