K KASONIC B082QLTZD2

K KASONIC Dual-Use Folding Sheet Music Stand & Desktop Book Stand

Model: B082QLTZD2

1. Introduction and Overview

The K KASONIC Dual-Use Folding Sheet Music Stand is designed for musicians and readers seeking a versatile, stable, and portable solution for holding sheet music or books. Its robust metal construction ensures durability, while its adjustable features provide optimal comfort and adaptability for various environments, whether standing or sitting. This manual will guide you through the setup, operation, and care of your new music stand.



Figure 1: K KASONIC Dual-Use Folding Sheet Music Stand and Accessories

This image displays the K KASONIC Dual-Use Folding Sheet Music Stand in its assembled floor-standing configuration, alongside its included accessories: a portable carrying bag, a sheet music folder, and a music sheet clip holder. The stand features a black finish and a sturdy tripod base.

2. Components and What's Included

Your K KASONIC music stand package includes the following items:

- 1 x Music Stand (comprising bookplate, adjustable pole sections, and tripod base)
- 1 x Portable Carrying Bag
- 1 x Sheet Music Folder
- 1 x Music Sheet Clip Holder

3. Setup Instructions

Follow these steps to assemble your K KASONIC music stand:

1. **Unfold the Tripod Base:** Gently spread the three legs of the tripod base until they are fully extended and

stable. Ensure the locking mechanism is secure.

2. **Insert Lower Pole Section:** Insert the lower adjustable pole section into the top of the tripod base. Tighten the knob on the tripod base to secure the pole at the desired height.
3. **Insert Upper Pole Section:** Insert the upper adjustable pole section into the lower pole section. Tighten the knob on the lower pole to secure it.
4. **Attach the Bookplate:** Align the bookplate with the top of the upper pole section. Slide the bookplate onto the pole and secure it by tightening the knob on the back of the bookplate.
5. **Adjust Height and Angle:** Use the adjustment knobs on the pole sections to set the overall height. Adjust the angle of the bookplate using the knob on its back for comfortable viewing.



Figure 2: Music Stand in Various Rehearsal Scenarios

This image illustrates the versatility of the music stand in different settings, showing individuals playing various instruments with the stand in use.

Video 1: Kasonic Dual-Use Folding Sheet Music Stand SL29 Setup and Features. This video demonstrates the assembly process and highlights key features of the music stand.

4. Operating Instructions

The K KASONIC music stand offers flexible adjustments for optimal use:

- **Height Adjustment:** The stand's height can be adjusted from 30.3 inches (76.96 cm) to 55.2 inches (140.21 cm). Loosen the knobs on the pole sections, extend or retract the poles to the desired height, and then firmly tighten the knobs to secure.
- **Angle Adjustment:** The bookplate features a 180-degree adjustable angle. Loosen the knob on the back of the bookplate, tilt the bookplate to your preferred viewing angle, and then tighten the knob to lock it in place.
- **Sheet Music Retention:** Utilize the integrated spring-loaded arms at the bottom of the bookplate to hold your sheet music or book securely in place, preventing pages from turning unexpectedly. The included music sheet clip holder can be used for additional security at the top.



Figure 3: 180-Degree Adjustable Angle

This image demonstrates the 180-degree adjustable angle of the music stand's bookplate, allowing users to set it to their preferred viewing position.



Figure 4: Height Adjustable Feature

This image illustrates the adjustable height feature of the music stand, showing its range from 30.3 inches to 55.2 inches, suitable for both children and adults.

5. Dual-Use Functionality

This unique 2-in-1 design allows the music stand to be used in two configurations:

- **Floor Music Stand:** Use with the full tripod stand for standing performances or practice.
- **Desktop Book Stand:** The bookplate can be easily detached from the main pole by rotating the nut, allowing it to be placed directly on a desk or table for seated use.



Figure 5: Floor-standing & Desktop Styles

This image showcases the dual functionality of the K KASONIC stand, demonstrating its use as both a traditional floor-standing music stand and a compact desktop book stand.

6. Portability and Storage

The K KASONIC music stand is designed for maximum portability and easy storage:

- **Collapsible Design:** The stand opens and closes quickly and easily. The bookplate is removable, and the tripod base collapses for compact storage.
- **Carrying Bag:** The included carrying bag (dimensions: 17.52 x 13.58 inches) allows all components to be neatly stored and transported, making it ideal for travel, school, or home use.



Figure 6: Foldable & Portable Design

This image highlights the foldable nature of the music stand, showing it collapsed for easy transport and stored within its dedicated carrying bag.

7. Maintenance

To ensure the longevity and optimal performance of your music stand, follow these maintenance guidelines:

- **Cleaning:** Wipe down the metal surfaces with a soft, dry cloth to remove dust and fingerprints. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying. Avoid abrasive cleaners or solvents.
- **Check Connections:** Periodically inspect all knobs and connections to ensure they are tight and secure. Loose parts can affect stability and lead to wear.
- **Lubrication:** If any moving parts (e.g., pole sections, angle adjustment) become stiff, apply a small amount of silicone-based lubricant to ensure smooth operation.
- **Storage:** When not in use, store the stand in its carrying bag in a dry environment to protect it from dust and moisture.

8. Troubleshooting

Here are some common issues and their solutions:

Problem	Possible Cause	Solution
Stand is wobbly or unstable	Legs not fully extended or knobs not tightened.	Ensure tripod legs are fully spread and all adjustment knobs (especially on the tripod base and pole sections) are firmly tightened.
Bookplate angle slips	Angle adjustment knob is loose.	Tighten the knob on the back of the bookplate securely after setting the desired angle.
Missing parts upon arrival	Packaging error or transit damage.	Carefully check all packaging materials. If a part is genuinely missing, contact customer service immediately for assistance.
Difficulty adjusting height/angle	Knobs are too tight or parts need lubrication.	Loosen knobs sufficiently before attempting adjustment. If still stiff, apply a small amount of silicone lubricant to the sliding parts.

9. Specifications

- **Material:** Metal
- **Color:** Black
- **Adjustable Height:** 30.3 inches - 55.2 inches (76.96 cm - 140.21 cm)
- **Bookplate Angle:** 180 degrees adjustable
- **Item Weight:** Approximately 5.57 pounds (2.53 kg)
- **Product Dimensions (Folded):** Approximately 17 x 13 x 50 inches (43.18 x 33.02 x 127 cm)



Figure 7: Product Size and Dimensions

This diagram provides detailed measurements for the music stand, including its height range, bookplate dimensions, and the size of the carrying bag and clip holder.

10. Warranty and Support

Your K KASONIC music stand comes with a 1-year warranty. For any questions, concerns, or warranty claims, please do not hesitate to contact our customer service team. We are committed to providing timely and helpful support to ensure your satisfaction.

Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question