Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Strongway 61134

Strongway Hand Winch Stacker - 500-Lb. Capacity User Manual

Model: 61134

1. Introduction

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Strongway Hand Winch Stacker. Designed for lifting and moving materials, this unit has a 500-lb. capacity and is suitable for various applications including lifting items to and from shelves, moving office equipment, and assisting with ceiling/wall appliance installations. Please read this manual thoroughly before initial use to ensure proper handling and to prevent injury or damage.

2. Safety Information

Always prioritize safety when operating the Strongway Hand Winch Stacker. Failure to follow these instructions may result in serious injury or property damage.

General Safety Rules

- Read and understand all instructions before operating the stacker.
- Do not exceed the rated load capacity of 500 lbs.
- Ensure the load is centered and stable on the forks before lifting or moving.
- Keep hands and feet clear of moving parts, especially during lifting and lowering operations.
- Operate the stacker on a level, stable surface. Avoid sloped or uneven terrain.
- Do not use the stacker as a personnel lift or for transporting people.
- Inspect the stacker for damage or wear before each use. Do not operate if damaged.
- Wear appropriate personal protective equipment (PPE), such as safety shoes and gloves.

Specific Safety Precautions

- Ensure the winch mechanism is securely engaged before lifting or lowering.

- Lower loads slowly and in a controlled manner.
- Do not leave a raised load unattended.
- Be aware of your surroundings and clear the area of bystanders before operation.
- Store the stacker in a dry, secure location when not in use.

3. Components and Parts

The Strongway Hand Winch Stacker consists of several key components designed for efficient material handling.






Figure 3.1: Main view of the Strongway Hand Winch Stacker, showing the mast, forks, winch, and wheels.

- **Mast Assembly:** The vertical frame that supports the lifting mechanism.
- **Forks:** The load-bearing arms that slide under items for lifting.
- **Hand Winch:** Manual crank mechanism used to raise and lower the forks.
- **Cable System:** Steel cables and pulleys connected to the winch for lifting.
- **Base Frame:** The sturdy bottom structure providing stability.
- **Wheels/Casters:** For mobility and steering the stacker. Includes solid wheels for durability.
- **Handle:** For maneuvering the stacker.

4. Setup and Assembly

The Strongway Hand Winch Stacker typically arrives partially assembled. Follow these steps to complete the setup before first use.



Figure 4.1: Stacker dimensions, important for assembly and space planning.

1. **Unpacking:** Carefully remove all components from the packaging. Check for any shipping damage or missing parts against the packing list.
2. **Base Assembly:** Attach the wheels and any separate base supports to the main frame if not already installed. Ensure all bolts are tightened securely.
3. **Mast Installation:** If the mast is separate, carefully align and secure it to the base frame using the provided hardware. Double-check all connections for tightness.
4. **Winch and Cable System:** Verify that the hand winch is securely mounted and the lifting cables are properly routed through the pulleys and attached to the fork carriage. Ensure there are no kinks or fraying in the cables.
5. **Handle Attachment:** Secure the steering handle to the designated mounting points on the stacker.
6. **Pre-Operation Check:** Before loading, perform a test lift and lower cycle with no load to ensure smooth operation of the winch and cable system.

5. Operating Instructions

Follow these steps for safe and effective operation of your Strongway Hand Winch Stacker.

Before Operation

- Inspect the stacker for any visible damage, loose fasteners, or worn cables.
- Ensure the operating area is clear of obstructions and has a level, stable surface.
- Confirm the load does not exceed the 500-lb. capacity.

Lifting and Lowering Loads

1. **Positioning:** Roll the stacker to the item you wish to lift. Ensure the forks are at the lowest position.
2. **Engage Forks:** Carefully slide the forks completely under the load, ensuring the load is centered and balanced on the forks.
3. **Lifting:** Turn the hand winch crank clockwise to raise the forks and the load. Lift the load only high enough to clear any obstacles for transport.
4. **Transporting:** Once the load is lifted, carefully push or pull the stacker to the desired destination. Move slowly and maintain control.
5. **Lowering:** At the destination, position the stacker correctly. Turn the hand winch crank counter-clockwise to slowly lower the forks and the load. Control the descent to prevent sudden drops.
6. **Disengage Forks:** Once the load is fully supported by the ground or surface, carefully pull the stacker away, sliding the forks out from under the load.

Moving the Stacker (Unloaded)

When moving the stacker without a load, ensure the forks are in the lowest position to maintain a low center of gravity and prevent tipping.

6. Maintenance

Regular maintenance will extend the life of your Strongway Hand Winch Stacker and ensure safe operation.

Regular Checks (Before Each Use)

- **Visual Inspection:** Check for any signs of damage, cracks, bends, or excessive wear on the frame, forks, and wheels.
- **Cable Inspection:** Examine the lifting cables for fraying, kinks, corrosion, or broken strands. Replace immediately if any damage is found.
- **Winch Operation:** Test the winch for smooth operation. Ensure the brake mechanism (if applicable) engages properly.
- **Fasteners:** Verify that all nuts, bolts, and pins are tight and secure. Tighten any loose fasteners.

Lubrication (Monthly or as Needed)

- Apply a light coat of general-purpose grease to the winch gears and pivot points.
- Lubricate the wheel axles and any other moving parts to ensure smooth rolling.

Storage

- Store the stacker in a clean, dry area, protected from extreme temperatures and moisture.
- Lower the forks to their lowest position before storage.

7. Troubleshooting

This section provides solutions to common issues you might encounter with your Strongway Hand Winch Stacker.

Problem	Possible Cause	Solution
Forks not lifting or lowering smoothly.	Lack of lubrication; damaged cable; winch mechanism issue.	Lubricate moving parts and winch gears. Inspect cable for damage and replace if necessary. Check winch for obstructions or damage.
Stacker difficult to move or steer.	Wheels/casters are dirty or damaged; insufficient lubrication.	Clean wheels and remove debris. Lubricate wheel axles. Replace damaged wheels/casters.
Winch handle slips or does not engage.	Winch brake mechanism worn or faulty; internal winch damage.	Inspect the winch brake. If worn or damaged, contact Strongway customer support for replacement parts or service.
Unstable operation when loaded.	Load is not centered; exceeding capacity; operating on uneven surface.	Ensure load is centered and within capacity. Operate only on level, stable surfaces.

8. Specifications

Key technical specifications for the Strongway Hand Winch Stacker, Model 61134.

Specification	Value
Brand	Strongway
Model Number	61134
Load Capacity	500 lbs.
Material	Alloy Steel
Item Weight	177 lbs.
Product Dimensions (L x W x H)	34.88" x 24" x 67"
Wheel Type	Solid
Number of Wheels	4

9. Warranty and Support

Strongway products are manufactured to high-quality standards and are backed by a limited warranty against

defects in materials and workmanship. For specific warranty details, including duration and coverage, please refer to the warranty card included with your product or visit the official Strongway website.

For technical assistance, replacement parts, or warranty claims, please contact Strongway customer support. Have your model number (61134) and purchase information ready when contacting support.

Strongway Customer Support:

Please refer to your product packaging or the Strongway official website for the most current contact information.

© 2024 Strongway. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082QZW266

More documents and user manuals: **https://manuals.plus/**