SYSKA HT3052K/02

SYSKA HT3052K/02 UltraGroom Pro Styling Kit

User Manual

Introduction

This manual provides detailed instructions for the safe and effective use of your SYSKA HT3052K/02 UltraGroom Pro Styling Kit. Please read all instructions carefully before using the device and retain this manual for future reference. The UltraGroom Pro Styling Kit is designed for personal grooming, offering versatile trimming solutions for various hair types.

Important Safety Instructions

When using an electrical appliance, basic precautions should always be followed, including the following:

- Read all instructions before using this appliance.
- Keep the appliance dry. Do not use it near water or while bathing/showering.
- Do not immerse the appliance in water or any other liquid.
- Always unplug the appliance immediately after use, especially when charging.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Close supervision is necessary when this appliance is used by, on, or near children or individuals with certain disabilities.
- Use this appliance only for its intended household use as described in this manual.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Keep the cord away from heated surfaces.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Always attach the plug to the appliance first, then to the outlet. To disconnect, turn all controls to OFF, then remove the plug from the outlet.
- The appliance is not waterproof. Avoid direct contact with water.

Package Contents

Verify that all items listed below are included in your package:

- Beard Trimmer Unit
- Nose Trimmer Attachment
- Precision Trimmer Attachment
- Body Hair Trimmer Attachment
- Foil Shaver Head
- Docking Station
- Cleaning Brush
- Charging Adaptor
- User Manual cum Warranty Card

Product Overview

Familiarize yourself with the main components of your UltraGroom Pro Styling Kit.



Figure 1: Main Trimmer Unit with Adjustable Comb.



Figure 2: Ergonomic design of the trimmer body, highlighting the power button and LED indicator.



Figure 3: Detailed view of the LED indicators for battery status and operation.



Figure 4: Illustration of the self-sharpening and skin-friendly stainless steel blades.

Setup and Charging

Initial Charge

Before first use, fully charge the trimmer for approximately 1 hour. This ensures optimal battery performance and longevity.

1. Connect the charging adaptor to the docking station.
2. Place the trimmer securely in the docking station.
3. Plug the adaptor into a standard electrical outlet.
4. The LED indicator on the trimmer will show charging status. Once fully charged, the indicator may change or turn off depending on the model.

A full charge provides up to 50 minutes of cordless operation.

Attaching and Removing Trimmer Heads

To change attachments, ensure the trimmer is turned off.

- **To Remove:** Gently push the current attachment upwards from the front of the trimmer head until it detaches.
- **To Attach:** Align the desired attachment with the trimmer body and press down firmly until it clicks into place.

Operating Instructions

Ensure your skin and hair are clean and dry before trimming for best results.

General Trimming (Beard, Moustache, Body Hair)

1. Attach the desired trimming head (Beard Trimmer or Body Hair Trimmer).
2. If using the beard trimmer, attach the adjustable comb. The kit offers 10 length settings, adjustable from 1mm to 10mm. Slide the comb to your desired length setting.
3. Press the power button to turn on the trimmer.
4. Hold the trimmer with the blades flat against your skin and move it against the direction of hair growth.
5. For an even trim, use consistent pressure and speed.



Figure 5: Demonstrating the use of the trimmer for beard grooming.

Nose and Ear Trimming

1. Attach the Nose Trimmer attachment.
2. Gently insert the trimmer tip into your nostril or ear canal.
3. Move the trimmer in a circular motion to trim unwanted hair. Do not insert too deeply.

Precision Trimming

1. Attach the Precision Trimmer attachment.
2. Use this attachment for detailing edges, creating sharp lines, or trimming small areas.
3. Hold the trimmer at an angle and carefully guide it along the desired line.

Foil Shaving

1. Attach the Foil Shaver Head.
2. Stretch the skin with your free hand and move the shaver in short, circular motions against the direction of hair growth.

3. This attachment is designed for a close shave on small areas, not for full beard removal.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your trimmer.

1. **Turn Off and Unplug:** Always ensure the trimmer is turned off and unplugged from the power source before cleaning.
2. **Remove Attachment:** Detach the trimming head from the main unit.
3. **Brush Cleaning:** Use the provided cleaning brush to remove loose hairs from the blades and the trimmer body.
4. **Rinsing Blades:** The trimming blades can be rinsed under running water. Ensure the main body of the trimmer does not come into contact with water as it is not waterproof.
5. **Drying:** Allow all parts to air dry completely before reattaching or storing.
6. **Lubrication:** Periodically apply a small drop of light machine oil (not included) to the blades to maintain smooth operation.
7. **Storage:** Store the trimmer and all attachments in a dry, safe place, away from children.

Troubleshooting

If you encounter issues with your trimmer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer for at least 1 hour.
Trimmer not charging.	Adaptor or docking station not properly connected.	Ensure the adaptor is securely plugged into both the docking station and the wall outlet. Check if the trimmer is correctly seated in the docking station.
Poor trimming performance / pulling hair.	Blades are clogged with hair or not lubricated.	Clean the blades thoroughly with the brush. Rinse if necessary (only blades). Apply a drop of oil to the blades.
Trimmer makes unusual noise.	Blades may be misaligned or require lubrication.	Ensure the attachment is correctly seated. Clean and lubricate the blades. If the issue persists, contact customer support.

Specifications

- **Model:** HT3052K/02
- **Power Source:** Battery Powered (Corded & Cordless operation)
- **Battery Type:** Lithium Polymer
- **Charging Time:** Approximately 1 hour
- **Runtime:** Up to 50 minutes
- **Blade Material:** Stainless Steel (Self-sharpening, skin-friendly)
- **Length Settings:** 10 (1mm-10mm with guide comb)
- **Included Attachments:** Beard Trimmer, Nose Trimmer, Precision Trimmer, Body Hair Trimmer, Foil Shaver Head
- **Product Dimensions:** 16 x 4 x 4 cm
- **Item Weight:** 260 g

- **Water Resistance:** Not waterproof (main unit)

Warranty and Support

Your SYSKA HT3052K/02 UltraGroom Pro Styling Kit comes with a **2-Year Manufacturer Warranty** from the date of purchase. For warranty claims, technical support, or any product-related inquiries, please contact SYSKA customer service:

- **Toll Free No:** 1800-102-8787
- **Manufacturer:** Syska Led Lights Pvt. Ltd.
- **Address:** Syska Led Lights Pvt. Ltd., Songjiang Dict., Shanghai, China
- **Packer/Importer:** Syska Led Lights Pvt. Ltd. Syska House, Office No. S-2, 2nd Floor, Sakore nagar, Pune-411014, Maharashtra

Please retain your purchase receipt and the warranty card included in the package for any service requests.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question