Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kircuit B082W3J3F3

Kircuit AC Adapter User Manual

Model: B082W3J3F3

Introduction

This user manual provides essential information for the safe and effective use of your Kircuit AC Adapter, designed for the Yamaha WX11 MIDI Wind Controller. Please read this manual thoroughly before using the product to ensure proper operation and to prevent damage.





Image: The Kircuit AC Adapter, showing the main power brick with a standard US plug and the DC output cable coiled neatly.

Safety Information

Always observe the following safety precautions to reduce the risk of fire, electric shock, or injury.

- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the input voltage of the adapter (100V-240V AC) matches the power outlet's voltage.
- **Avoid Overloading:** Do not overload power outlets or extension cords, as this can result in a risk of fire or electric shock.
- **Handle with Care:** Do not drop, disassemble, or attempt to repair the adapter. Refer all servicing to qualified service personnel.
- **Cable Integrity:** Inspect the power cord for any damage before each use. Do not use if the cord is frayed or damaged.
- **Ventilation:** Ensure adequate ventilation around the adapter during use. Do not cover it with cloth or other materials.




Image: A diagram illustrating the built-in safety protections of the Kircuit adapter, including short circuit, excess voltage, over temperature, and overcurrent protection.

Setup

1. **Unpack the Adapter:** Carefully remove the Kircuit AC Adapter from its packaging.
2. **Verify Compatibility:** Ensure that the adapter's output specifications (voltage and current) match the requirements of your Yamaha WX11 MIDI Wind Controller. This adapter is specifically designed for the Yamaha WX11.
3. **Connect to Device:** Plug the DC output connector of the Kircuit adapter into the power input port of your Yamaha WX11 MIDI Wind Controller. Ensure a firm and secure connection.
4. **Connect to Power Outlet:** Insert the AC plug of the adapter into a standard wall power outlet (100V-240V AC).



Image: The Kircuit AC Adapter plugged into a power strip, demonstrating a typical setup for connecting the adapter to a power source.

Operating Instructions

Once properly connected, the Kircuit AC Adapter will supply power to your Yamaha WX11 MIDI Wind Controller. The adapter is designed for continuous operation within its specified limits.

- **Power On:** After connecting the adapter to both the device and the power outlet, power on your Yamaha WX11 MIDI Wind Controller as per its own operating instructions.
- **Stable Power:** The adapter provides a stable DC power supply, ensuring consistent performance for your device.
- **Disconnection:** To disconnect, first power off your Yamaha WX11 MIDI Wind Controller, then unplug the adapter from the wall outlet, and finally disconnect the DC connector from your device.



Image: Two Kircuit AC Adapters displayed, highlighting the compact design and standard US plug, suitable for various power outlets.

Maintenance

Proper maintenance ensures the longevity and safe operation of your Kircuit AC Adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use, store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Cable Care:** Do not bend, twist, or pull the cable excessively. Avoid placing heavy objects on the cable.




Image: A graphic illustrating the durable design of the adapter's cable, emphasizing its high-quality materials, thick insulation, and resistance to wear, tear, and high temperatures.

Troubleshooting

If you encounter issues with your Kircuit AC Adapter, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device not powering on.	Adapter not properly plugged in; power outlet issue; device issue.	Ensure adapter is securely plugged into both the device and the wall outlet. Test the outlet with another device. Verify the Yamaha WX11 is functioning correctly.
Adapter feels warm.	Normal operation; insufficient ventilation; excessive load.	A slight warmth is normal. Ensure the adapter has adequate ventilation and is not covered. If it feels excessively hot, disconnect immediately and contact support.
Intermittent power.	Loose connection; damaged cable.	Check all connections for tightness. Inspect the cable for any visible damage. If damaged, discontinue use.

Specifications

Key technical specifications for the Kircuit AC Adapter:

Input: 100V-240V AC, 50/60Hz

Output: DC (Specific voltage/current for Yamaha WX11)

Cord Length: Approximately 6.5 ft (2 meters)

Weight: 8 ounces (approx. 227 grams)

Manufacturer: Kircuit

Model Number: B082W3J3F3



Image: The Kircuit AC Adapter with an overlay indicating its cord length of 6.5 feet, providing ample reach for various setups.

Warranty and Support

For warranty information or technical support, please contact the seller or manufacturer directly. Refer to your purchase documentation for specific warranty terms and contact details.

Manufacturer: Kircuit

For further assistance, please visit the Kircuit brand page on Amazon or contact their customer service.

© 2024 Kircuit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082W3J3F3

More documents and user manuals: **https://manuals.plus/**