Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Grunkel MW-DGR

Grunkel MW-DGR 20L Digital Microwave Oven User Manual

Model: MW-DGR | Brand: Grunkel

1. Introduction

Thank you for purchasing the Grunkel MW-DGR 20L Digital Microwave Oven. This manual provides essential information for the safe and efficient operation of your appliance. Please read these instructions carefully before use and keep them for future reference.
The Grunkel MW-DGR is a 700W digital microwave with a 20-liter capacity, featuring 6 adjustable power levels, 8 pre-set programs, quick cooking function, weight defrosting, a 60-minute timer, and a child lock for enhanced safety and convenience.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should be followed, including the following:

- Read all instructions before using the appliance.
- Ensure the voltage in your home corresponds to the voltage shown on the rating label of the microwave.
- To reduce the risk of fire, electric shock, or injury:
  - Do not operate the oven if it is damaged.
  - Do not attempt to service or repair the oven yourself.
  - Do not heat liquids or other foods in sealed containers as they are liable to explode.
  - Do not use corrosive chemicals or vapors in this appliance.
  - Do not allow children to use the microwave without supervision.
- Always place the microwave on a flat, stable surface.
- Do not block any ventilation openings.
- Only use utensils suitable for microwave ovens.
- Clean the microwave regularly and remove any food deposits.

3. Product Overview

Familiarize yourself with the components and control panel of your Grunkel MW-DGR microwave oven.



Image 3.1: Front view of the Grunkel MW-DGR microwave, showing the digital display, control dial, and function buttons.



Image 3.2: The Grunkel MW-DGR microwave with its door open, revealing the interior cavity and the glass turntable.

Control Panel Features:

- **Digital Display:** Shows time, power level, and program indicators.

- **Control Dial:** Used to set cooking time, weight, and navigate menus.
- **Function Buttons:**
    - **Defrost/Clock:** Selects defrost mode or sets the clock.
    - **Weight/Time:** Toggles between weight-based defrost and time-based cooking.
    - **Power:** Adjusts microwave power levels.
    - **Menu:** Selects pre-set cooking programs.
    - **Stop/Cancel:** Stops cooking or clears settings.
    - **Start/+30 Sec:** Starts cooking or adds 30 seconds to cooking time.

4. Setup and Installation

Follow these steps to set up your microwave oven:

1. **Unpacking:** Carefully remove the microwave oven and all packing materials. Check for any damage. Do not operate if damaged.
2. **Placement:** Place the microwave on a flat, stable, heat-resistant surface. Ensure there is adequate ventilation space: at least 20 cm (8 inches) above, 10 cm (4 inches) at the rear, and 5 cm (2 inches) on each side.
3. **Turntable Assembly:**
    - Place the roller ring (component included) in the center of the oven cavity floor.
    - Position the glass turntable plate securely on top of the roller ring. Ensure it rotates freely.
4. **Power Connection:** Plug the microwave into a grounded electrical outlet. Ensure the outlet meets the electrical specifications of the appliance (230V, 50Hz).



Image 4.1: Dimensional diagram of the Grunkel MW-DGR microwave, indicating external measurements (45.5 cm width, 26.5 cm height, 35 cm depth) and internal cavity dimensions (29 cm width, 18 cm height, 25 cm depth).

5. Operating Instructions

5.1 Setting the Clock

1. Press the "Defrost/Clock" button once.
2. Turn the control dial to set the hour.
3. Press "Defrost/Clock" again.
4. Turn the control dial to set the minutes.
5. Press "Defrost/Clock" to confirm the setting.

5.2 Microwave Cooking

1. Place food in a microwave-safe container on the turntable. Close the door.
2. Press the "Power" button repeatedly to select the desired power level (P100, P80, P60, P40, P20, P0). The

microwave has 6 power levels.

3. Turn the control dial to set the cooking time (up to 60 minutes).
4. Press the "Start/+30 Sec" button to begin cooking.



Image 5.1: Overview of key features including 700W power, 20L capacity, 8 pre-set programs, and defrost function.

5.3 Quick Start Cooking

For quick cooking at full power (P100):

- Press the "Start/+30 Sec" button repeatedly to add 30 seconds of cooking time per press. The maximum quick start time is 10 minutes.

5.4 Defrosting by Weight

1. Place the frozen food on the turntable. Close the door.
2. Press the "Defrost/Clock" button twice to enter weight defrost mode.
3. Turn the control dial to select the food weight (e.g., 100g to 2000g).
4. Press the "Start/+30 Sec" button to begin defrosting.



Image 5.2: Illustration of the defrost by weight function, allowing precise defrosting based on food weight.

5.5 Pre-set Cooking Programs

The microwave includes 8 pre-set programs for common foods. Refer to the internal label or a separate quick guide for specific program numbers and corresponding food types.

1. Press the "Menu" button repeatedly to select the desired program number (e.g., P1 for popcorn, P2 for potato).
2. Turn the control dial to adjust the quantity or weight if applicable.
3. Press the "Start/+30 Sec" button to begin.

5.6 Child Lock Function

To prevent unsupervised operation by children:

- **To Activate:** Press and hold the "Stop/Cancel" button for 3 seconds. A lock indicator will appear on the display.
- **To Deactivate:** Press and hold the "Stop/Cancel" button for 3 seconds again. The lock indicator will disappear.



Image 5.3: Visual representation of the child lock feature, ensuring safety by preventing accidental operation.

6. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your microwave oven.

- **Exterior:** Wipe the exterior with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Interior:** Clean the interior cavity after each use. For stubborn food splatters, place a bowl of water with lemon slices inside and microwave for 2-3 minutes. The steam will loosen food particles, making them easier to wipe away.
- **Door Seal:** Keep the door seal and adjacent parts clean to ensure proper closure.
- **Turntable and Roller Ring:** The glass turntable and roller ring can be removed and washed in warm soapy water or a dishwasher. Ensure they are completely dry before placing them back in the oven.
- **Odor Removal:** To remove odors, combine a cup of water with the juice of one lemon in a microwave-safe bowl. Microwave for 5 minutes, then let it sit in the oven for another 5 minutes before opening the door.

Caution: Always unplug the microwave before cleaning. Do not immerse the appliance in water or other liquids.

7. Troubleshooting

If you encounter issues with your microwave, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Oven does not start	Power cord not plugged in; Door not closed properly; Fuse blown or circuit breaker tripped.	Ensure power cord is securely plugged in; Close the door firmly; Check household fuse or reset circuit breaker.
Food not heating	Door not closed properly; Cooking time or power level set incorrectly; Food not suitable for microwave.	Ensure door is closed; Adjust cooking time and power level; Use microwave-safe dishes.
Turntable not rotating	Turntable or roller ring not positioned correctly; Obstruction under turntable.	Re-position turntable and roller ring; Remove any obstructions.
Unusual noise during operation	Turntable or roller ring not seated correctly; Food container touching oven walls.	Check turntable and roller ring placement; Ensure food container is centered and not too large.
Child lock activated	Child lock is engaged, preventing operation.	Press and hold the "Stop/Cancel" button for 3 seconds to deactivate the child lock.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Model Number	MW-DGR
Brand	Grunkel
Capacity	20 Liters
Microwave Power	700 Watts
Power Levels	6 adjustable levels
Voltage	230 Volts
Frequency	50 Hz
Control Type	Digital (Dial and Touch buttons)
Special Functions	Defrost by weight, Programmable, Timer, Child Lock
Installation Type	Countertop
Product Dimensions (D x W x H)	35 x 45.5 x 26.5 cm (13.8 x 17.9 x 10.4 inches)
Product Weight	10.3 kg (22.7 lbs)
Interior Material	Stainless Steel
Included Components	Turntable Ring

9. Warranty and Support

Warranty: The Grunkel MW-DGR microwave oven comes with a product warranty. Please refer to the warranty card

included with your purchase for specific terms and conditions, or visit the official Grunkel website for detailed warranty information.

Customer Support: For technical assistance, spare parts, or any questions regarding your appliance, please contact Grunkel customer service. Contact details can typically be found on the Grunkel website or in your product documentation.

You can visit the Grunkel brand store for more information:Grunkel Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B082ZRCQ3Y

More documents and user manuals: **https://manuals.plus/**