De'Longhi 8024651202325

De'Longhi PLI 59 GH Gas Hob User Manual

Model: 8024651202325

1. Product Overview

The De'Longhi PLI 59 GH is a high-quality stainless steel gas hob designed for efficient and precise cooking. Featuring five gas burners with knob controls, it offers versatile cooking options for various culinary needs. This manual provides essential information for the safe installation, operation, and maintenance of your appliance.



Figure 1: De'Longhi PLI 59 GH Gas Hob
This image displays the full view of the De'Longhi PLI 59 GH gas hob. It features a sleek stainless steel surface with five distinct gas burners, each equipped with sturdy black cast-iron pan supports. On the right side, a vertical panel houses five rotary control knobs for precise flame adjustment. The De'Longhi logo is visible on the upper right corner of the control panel.

2. Important Safety Information

Please read all instructions carefully before using the appliance. Failure to follow these instructions could result in fire, electric shock, or personal injury.

- **Gas Safety:** Ensure proper ventilation. Do not store flammable materials near the hob. In case of a gas leak, turn off the gas supply, open windows, and do not operate electrical switches.
- **Installation:** Installation must be performed by a qualified technician in accordance with local regulations and standards.
- **Hot Surfaces:** The hob and surrounding areas become hot during use. Use oven mitts and keep children away.
- **Supervision:** Never leave cooking unattended.
- **Cleaning:** Disconnect from power and ensure the hob is cool before cleaning.

3. Setup and Installation

The installation of this gas hob requires specialized knowledge and must be carried out by a certified professional. Incorrect installation can lead to serious hazards.

3.1 Unpacking

Carefully remove the appliance from its packaging. Inspect for any damage during transit. Retain packaging materials for future transport if needed.

3.2 Gas Connection

Connect the hob to the natural gas supply using appropriate fittings and flexible hoses, ensuring all connections are leak-tested according to local gas regulations.

3.3 Electrical Connection

The hob requires an electrical connection for the automatic ignition system. Ensure the voltage and frequency match the appliance's requirements as specified on the rating plate.

3.4 Ventilation

Adequate ventilation is crucial for gas appliances. Ensure the kitchen is well-ventilated, possibly with an extractor hood, to remove combustion products.

4. Operating Instructions

4.1 Igniting a Burner

1. Ensure the pan support is correctly positioned over the burner.
2. Place your cookware on the pan support.
3. Push down and turn the corresponding control knob counter-clockwise to the maximum flame position (large flame symbol).
4. Hold the knob down for a few seconds until the flame ignites and stabilizes. If the flame goes out, repeat the process.

4.2 Adjusting the Flame

Once ignited, you can adjust the flame intensity by rotating the control knob between the maximum (large flame symbol) and minimum (small flame symbol) positions. For simmering, use the minimum flame setting.

4.3 Turning Off a Burner

To turn off a burner, rotate the control knob clockwise until it clicks into the "off" position (dot symbol).

4.4 Cookware Selection

Use flat-bottomed cookware appropriate for the size of the burner. The flame should not extend beyond the base of the pan to ensure efficient heating and prevent damage to the hob.

5. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your hob and ensure safe operation.

5.1 Daily Cleaning

- Ensure the hob is cool before cleaning.
- Wipe the stainless steel surface with a soft cloth and mild detergent. Avoid abrasive cleaners or scourers.
- For stubborn stains, use a specialized stainless steel cleaner, following the product instructions.

5.2 Cleaning Burner Components

- Remove the pan supports, burner caps, and flame spreaders when cool.
- Wash them in warm soapy water. For stubborn food residue, soak them before cleaning.
- Ensure all components are completely dry before reassembling them. Blocked burner holes can affect flame quality.

6. Troubleshooting

Before contacting customer service, please refer to the following common issues and their solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, power outage, clogged burner hole, wet ignition electrode.	Check gas valve, check power, clean burner components, dry electrode.
Flame is uneven or yellow.	Clogged burner holes, incorrect gas pressure.	Clean burner holes, contact a qualified technician to check gas pressure.
Gas smell detected.	Gas leak.	Immediately turn off gas supply, open windows, do not operate electrical switches, evacuate, and call emergency services.

7. Specifications

Brand: De'Longhi

Model: 8024651202325

Material: Stainless Steel

Fuel Type: Natural Gas

Control Type: Knob

ASIN: B0832Z246

First Available Date: February 26, 2020

8. Warranty and Support

For warranty information, please refer to the documentation provided with your purchase or visit the official De'Longhi website. For technical support or service, please contact De'Longhi customer service.
You can find more information and support on the official De'Longhi store:De'Longhi Store

© 2023 De'Longhi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question