ALLIMITY AMT-AXD7692

ALLIMITY AXD7692 Replacement Remote Control User Manual

Model: AMT-AXD7692

Product Overview

This manual provides instructions for the ALLIMITY AXD7692 Replacement Remote Control, designed for use with various Pioneer AV Receivers. This infrared (IR) remote control requires no programming and operates by aiming at the receiver's sensor.





Image: Front view of the ALLIMITY AXD7692 Replacement Remote Control, showing all buttons and their labels.

Compatible Models:

- Pioneer VSX-43
- Pioneer VSX-823
- Pioneer VSX-528
- Pioneer VSX-828
- Pioneer VSX-1023
- Pioneer VSX-528-K
- Pioneer VSX-528-S
- Pioneer VSX-828-K
- Pioneer VSX-828-S

Setup

Battery Installation:

The ALLIMITY AXD7692 remote control requires two (2) AA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch (if present) to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image: Back view of the remote control showing the open battery compartment and two AA batteries.

No programming is required for this replacement remote control. Once batteries are installed, it is ready for use with compatible Pioneer AV Receivers.

Operating Instructions

To operate your Pioneer AV Receiver using the ALLIMITY AXD7692 remote control, ensure a clear line of sight between the remote's infrared emitter and the receiver's IR sensor. Obstacles can block the signal.

Basic Usage:

- **Power On/Off:** Press the **RECEIVER** button to power on or off the AV Receiver.
- **Input Selection:** Use the **INPUT SELECT** buttons (e.g., BD, DVD, SAT/CBL, CD, TV, TUNER, NETWORK, iPod/USB, ADAPTER) to switch between different audio/video sources connected to your receiver.
- **Volume Control:** Adjust the volume using the **VOLUME +** and **-** buttons.
- **Mute:** Press the **MUTE** button to temporarily silence the audio. Press again to restore sound.
- **Navigation:** Use the directional arrow buttons (**UP, DOWN, LEFT, RIGHT**) and the **ENTER** button for menu navigation on your receiver's display.
- **Menu Access:** Buttons like **TOP MENU**, **TOOLS MENU**, and **HOME MENU** (if present on your receiver's interface) allow access to various settings and functions.

Refer to your Pioneer AV Receiver's original user manual for detailed functions and specific button operations related to your model.

Maintenance

Battery Replacement:

If the remote control's performance degrades or it stops responding, the batteries may need replacement. Replace both AA batteries simultaneously with new ones, following the installation steps outlined in the "Setup" section.

Cleaning:

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive cleaners, solvents, or excessive moisture, as these can damage the remote.

Troubleshooting

Problem	Possible Cause	Solution
Remote control does not work.	Batteries are dead or incorrectly installed. Obstruction between remote and receiver. Remote is too far from the receiver. Receiver's IR sensor is blocked or faulty.	Replace batteries with new ones, ensuring correct polarity. Remove any objects blocking the line of sight. Move closer to the receiver. Ensure the receiver's IR sensor is clean and unobstructed. Test with original remote if available.
Some buttons do not respond.	Batteries are low. Button is stuck or damaged. Function not supported by your specific receiver model.	Replace batteries. Gently press the button multiple times. If stuck, cleaning may be required (see Maintenance). Verify the function in your receiver's original manual.

If issues persist after attempting these solutions, please refer to the Support section for further assistance.

Specifications

Model Number	AMT-AXD7692
Brand	ALLIMITY
Product Material	Plastic
Connective Technology	Infrared (IR)
Dimensions (L x W x H)	7 x 2 x 0.7 inches
Item Weight	2.46 ounces
Batteries Required	2 x AA batteries
Compatible Devices	Pioneer AV Receivers (VSX-43, VSX-823, VSX-528, VSX-828, VSX-1023, VSX-528-K, VSX-528-S, VSX-828-K, VSX-828-S)
Color	Black
Manufacturer	ALLIMITY inc
Country of Origin	China

Support

For further assistance, questions regarding compatibility, or if you cannot find your specific model listed, please contact ALLIMITY customer support. While no specific contact email is provided in the product description, general inquiries can often be directed through the seller's contact information on the platform where the product was purchased.
This product is a replacement remote control and typically does not come with a separate manufacturer's warranty beyond standard consumer rights. Please refer to the retailer's return policy for details on product returns or exchanges.

© 2024 ALLIMITY. All rights reserved.

Pioneer is a registered trademark of Pioneer Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question