USHA CO0150WW2

Usha Colossal Wet Grinder CO0150WW2 Instruction Manual

Model: CO0150WW2

Introduction

Thank you for choosing the Usha Colossal Wet Grinder. This appliance is designed for efficient wet grinding, atta kneading, and coconut scraping, making your kitchen tasks easier. Please read this manual carefully before operating the appliance to ensure safe and optimal performance. Keep this manual for future reference.



Image: The Usha Colossal Wet Grinder in magenta, shown with its stainless steel drum, motor unit, and various accessories including the atta kneader, coconut scrapper, and spatula.

Important Safety Instructions

- Read all instructions before use.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Keep hands and utensils away from moving parts during operation to prevent injury.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Close supervision is necessary when any appliance is used by or near children.
- Place the grinder on a stable, flat, and dry surface.
- Do not overload the grinder. Refer to the capacity specifications.

Product Components

The Usha Colossal Wet Grinder package includes the following components:

- Main Motor Unit (Magenta ABS body)
- Stainless Steel Drum (2 Liters capacity)
- Transparent PC Lid
- Roller Assembly with 2 Stone Rollers and Dual Flow Breakers
- Atta Kneader attachment
- Coconut Scrapper attachment
- Spatula
- Instruction Manual (this document)



Image: All components of the Usha Colossal Wet Grinder laid out, including the main unit, stainless steel drum, lid, roller stones, atta kneader, coconut scrapper, and spatula.

Setup and Assembly

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the stainless steel drum, roller assembly, transparent lid, atta kneader, coconut scrapper, and spatula with mild soap and water. Rinse thoroughly and dry completely before first use. The main motor unit should only be wiped with a damp cloth.
3. **Place the Drum:** Position the clean stainless steel drum securely onto the motor unit base. Ensure it is seated correctly.
4. **Insert Roller Assembly:** For grinding, place the roller assembly into the center shaft of the drum. Ensure it rotates freely.
5. **Secure Lid:** Place the transparent PC lid over the drum.
6. **Power Connection:** Ensure the appliance is switched off before plugging the power cord into a suitable electrical outlet.



Image: The Usha Colossal Wet Grinder fully assembled with the stainless steel drum and transparent lid in place, ready for operation.

Operating Instructions

1. Wet Grinding

1. Ensure the drum and roller assembly are clean and correctly placed.
2. Add pre-soaked and drained ingredients (e.g., rice, lentils) into the stainless steel drum. Do not exceed the 2-liter capacity.
3. Add a small amount of water as needed to facilitate grinding.
4. Place the transparent lid securely on the drum.
5. Plug in the grinder and switch it on. The 100% copper motor will begin grinding.
6. Allow the grinder to operate until the desired consistency is achieved. The dual flow breakers and stone rollers ensure efficient and uniform grinding.
7. Use the spatula to occasionally push down ingredients from the sides of the drum towards the rollers if necessary.
8. Once grinding is complete, switch off the grinder and unplug it.
9. Carefully remove the lid and then the roller assembly. Scoop out the ground batter.

2. Atta Kneading

1. Remove the roller assembly from the drum.
2. Attach the atta kneader to the central shaft in the drum.
3. Add flour and a small amount of water to the drum.

4. Place the transparent lid securely.
5. Switch on the grinder and allow it to knead the atta until it reaches the desired consistency.
6. Switch off and unplug the appliance. Remove the atta kneader and take out the dough.

3. Coconut Scraping

1. Remove the roller assembly or atta kneader from the drum.
2. Attach the coconut scrapper to the central shaft in the drum.
3. Hold a half-cut coconut firmly against the rotating scrapper.
4. Exercise caution and keep fingers away from the rotating scrapper.
5. Switch off and unplug the appliance once scraping is complete.

Cleaning and Maintenance

- Always unplug the grinder before cleaning.
- The detachable SS-304 stainless steel drum and roller assembly, atta kneader, coconut scrapper, and spatula can be washed with warm soapy water. Rinse thoroughly and dry.
- Do not use abrasive cleaners or scouring pads on any part of the grinder.
- Wipe the main motor unit with a soft, damp cloth. Never immerse the motor unit in water.
- Ensure all parts are completely dry before reassembling or storing the appliance.
- Store the grinder in a clean, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Grinder does not start.	Not plugged in; power switch off; power outage.	Check power connection; ensure switch is ON; check household power supply.
Motor runs but rollers do not rotate.	Roller assembly not properly seated; drum not correctly placed.	Ensure roller assembly is firmly placed on the shaft; verify drum is seated correctly.
Grinding is slow or inefficient.	Insufficient water; overloaded drum; ingredients not pre-soaked.	Add small amounts of water; reduce quantity of ingredients; ensure ingredients are properly pre-soaked.
Unusual noise during operation.	Foreign object in drum; loose parts.	Switch off and unplug immediately. Inspect drum for foreign objects. Ensure all parts are correctly assembled. If noise persists, contact customer service.

Specifications

Model Number: CO0150WW2

Brand: USHA

Power: 150 Watts

Voltage: 230 Volts

Frequency: 50 Hz

Drum Capacity: 2 Liters (Stainless Steel SS-304 Food Grade)

Motor: 100% Copper Motor, Sturdy High Torque

Body Material: ABS Plastic

Color: Magenta

Item Weight: Approximately 13000 Grams

Dimensions (L x W x H): 44L x 28W x 28H Centimeters

Included Accessories: Atta Kneader, Coconut Scrapper, Spatula



Image: Diagram illustrating the dimensions of the Usha Colossal Wet Grinder, showing its height of 29 cm (approximately 12 inches).

Warranty and Customer Support

The Usha Colossal Wet Grinder comes with a comprehensive warranty:

- **Product Warranty:** 2 Years from the date of purchase.
- **Motor Warranty:** 5 Years on the motor from the date of purchase.

For any service, support, or warranty claims, please contact Usha Customer Service:
Toll Free No.: 1800 1033 111
Manufacturer Contact Information: Usha International Limited, Registered Office: Surya Kiran Building, 19 K.G. Marg, New Delhi-110 001, India.
Please retain your purchase receipt for warranty validation.

© 2024 USHA International Limited. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question