nania MADY

Nania MADY 4-in-1 Convertible High Chair Instruction Manual

Model: MADY

1. Introduction

Thank you for choosing the Nania MADY 4-in-1 Convertible High Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your product. Please read these instructions carefully before use and retain them for future reference. Proper use ensures the safety and comfort of your child.

2. Safety Instructions

Your child's safety is paramount. Always follow these safety guidelines:

- Never leave your child unattended in the high chair.
- Always use the safety harness to secure your child.
- Ensure the high chair is placed on a flat, stable surface.
- Keep children away from the product during assembly and disassembly.
- Regularly check all parts for wear, damage, or loose fittings. Discontinue use if any part is damaged.
- Do not use accessories or replacement parts other than those approved by Nania.
- Keep the high chair away from heat sources, open flames, and electrical appliances.
- Do not allow children to stand on the footrest or tray.

3. Product Overview

The Nania MADY is a versatile 4-in-1 high chair designed to adapt as your child grows. Its robust wooden legs provide stability and a modern aesthetic.
The 4 configurations include:

1. **High Chair (6 to 36 months):** For feeding infants and toddlers at table height.
2. **Child Chair (2 to 5 years):** A lower chair suitable for older toddlers.
3. **Stool:** A standalone stool for various uses.

4. **Booster Seat:** Can be used to elevate your child at a dining table.



Image: The Nania MADY high chair, showcasing its design and primary function.

4. Assembly Instructions

Assembly is required for the Nania MADY high chair. Please follow these general steps. Refer to the included pictorial guide for detailed illustrations.

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the parts list are present.
2. **Attach Legs:** Securely attach the wooden legs to the main seat unit. Ensure they click into place or are fastened tightly with the provided hardware.
3. **Install Footrest:** Slide the footrest into the designated slots on the legs. Adjust to the desired height if applicable.
4. **Attach Tray:** Position the removable tray onto the armrests. Ensure it locks securely.
5. **Insert Seat Cushion:** Place the washable seat cover onto the seat unit.
6. **Final Check:** Before first use, ensure all connections are secure and the chair is stable.

5. Operating Instructions

The Nania MADY high chair is designed for ease of use and conversion.

5.1 Adjusting and Removing the Tray

The tray is adjustable and easily removable for cleaning or to allow your child to sit closer to the table. Locate the release mechanisms (usually buttons or levers) on the underside or sides of the tray. Press or pull these mechanisms simultaneously to slide the tray forward/backward or lift it off completely.

5.2 Converting Between Modes

To convert the high chair into a child chair, stool, or booster seat, follow these general steps:

- **High Chair to Child Chair:** Detach the lower sections of the wooden legs. The seat unit with shorter legs forms the child chair.
- **Child Chair to Stool:** Remove the seat back and/or armrests from the child chair configuration, leaving only the base.
- **Booster Seat:** The seat unit can be detached from the legs and secured to an adult dining chair using straps (if provided, check your specific model for booster seat attachment details).

Always ensure all parts are securely fastened in the desired configuration before placing your child in the chair.

6. Maintenance and Cleaning

Regular cleaning and maintenance will prolong the life of your Nania MADY high chair.

- **Seat Cover:** The seat cover is easily washable. Refer to the care label for specific washing instructions (typically machine wash cold on a gentle cycle).
- **Tray:** The removable tray can be wiped clean with a damp cloth and mild soap or washed in a sink. Avoid abrasive cleaners.

- **Frame and Legs:** Wipe down the wooden legs and plastic frame with a damp cloth. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the high chair in a clean, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter any issues with your Nania MADY high chair, please refer to the following common solutions:

- **Chair feels wobbly:** Ensure all leg connections and screws are tightened. Check that the chair is on a flat, even surface.
- **Tray is difficult to attach/remove:** Ensure the release mechanisms are fully engaged/disengaged. Check for any food debris or obstructions in the tracks.
- **Harness is difficult to adjust:** Ensure the straps are not twisted. Refer to the harness adjustment instructions in the pictorial guide.
- **Parts missing or damaged:** Do not use the product. Contact Nania customer support for assistance.

8. Specifications

- **Model:** MADY
- **Brand:** Nania
- **Material:** Wood (legs), Plastic (seat unit), Fabric (seat cover)
- **Product Weight:** Approximately 5.6 kg
- **Assembly Required:** Yes
- **Portability:** Not portable (in full high chair mode)
- **Manufacturer:** TEAM TEX
- **Recommended Age (High Chair):** 6 to 36 months
- **Recommended Age (Child Chair):** 2 to 5 years

9. Warranty and Support

For information regarding warranty coverage, product registration, or to contact customer support, please refer to the warranty card included with your purchase or visit the official Nania website. Please have your product model number (MADY) and purchase date available when contacting support.
No official product videos were found in the provided data.

© 2024 Nania. All rights reserved.