**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Bell+Howell 2818**

# Bell+Howell TACSHAVER Moustache and Beard Trimmer User Manual

Model: 2818

## Introduction

Thank you for choosing the Bell+Howell TACSHAVER Moustache and Beard Trimmer. This versatile 2-in-1 shaver and trimmer is designed for precise and comfortable grooming of facial hair. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.

## Safety Information

**Caution:**

- Keep away from water. Do not use near or in water.
- Do not use near eyes.
- Not for use on infants or sensitive areas.
- Ensure the device is turned off before cleaning or performing maintenance.
- Do not attempt to disassemble or repair the unit yourself. Contact customer support if service is required.
- Keep out of reach of children.

*Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.*

## Package Contents

Verify that all items are present in your package:

- Bell+Howell TACSHAVER Unit
- Storage Pouch
- Cleaning Brush
- USB Charging Cable

**Image Description:** The image displays the front of the Bell+Howell TACSHAVER product packaging, highlighting its "2 in 1 Shaver & Trimmer" and "Rechargeable" features. The packaging also indicates "As Seen On TV" and "Use Wet or Dry!" with "Stainless Steel Blades." A clear plastic window shows the black TACSHAVER unit inside. Below the unit, icons illustrate a "Built-in Trimmer" and "3

Powerful Rotary Heads." The bottom of the box mentions "Water Proof," "Compact," "Cordless," and "Rechargeable."

## Setup

### Charging the TACSHAVER

1. Before first use, fully charge the TACSHAVER.
2. Connect the provided USB charging cable to the charging port on the shaver.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a computer's USB port.
4. Allow the unit to charge for approximately 4-5 hours for a full charge. The charging indicator light (if present) will typically change or turn off when charging is complete.
5. Disconnect the charger once fully charged.

### Initial Inspection

- Inspect the shaver for any visible damage before first use.
- Ensure the rotary heads are clean and free of debris.

## Operating Instructions

### General Use

1. Ensure the TACSHAVER is fully charged.
2. Press the power button to turn on the device.
3. For shaving, gently press the rotary heads against your skin and move the shaver in small, circular motions.
4. For trimming, activate the pop-up trimmer by sliding the switch located on the side of the unit. Use the trimmer for precise shaping of sideburns, beards, and moustaches.
5. The TACSHAVER can be used for both wet and dry shaving. For wet shaving, apply shaving foam or gel to your face before use.
6. After use, turn off the device by pressing the power button.

**Image Description:** This image provides a close-up view of the Bell+Howell TACSHAVER's three rotary shaving heads. Two heads are silver-colored, while the central head is highlighted with a blue ring, indicating its powerful rotary function for a smooth shave.

**Image Description:** The image shows a side view of the Bell+Howell TACSHAVER with its pop-up trimmer extended. This trimmer is designed for precise detailing and shaping of sideburns, beards, and moustache edges.

**Image Description:** This image depicts the Bell+Howell TACSHAVER being used on a man's jawline. To the right, a list of key features is presented with checkmarks: "Uses Stainless Steel Blades" and "Very Easy To Use and Clean." Below these, the same features are listed in French.

## Maintenance

### Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

1. Turn off the TACSHAVER and disconnect it from any charging cable.
2. Open the shaver head assembly (refer to diagrams in the full manual if available, or gently twist/pull to open).

3. Use the provided cleaning brush to remove loose hairs from the rotary blades and the internal chamber.
4. For a more thorough clean, the shaver heads can be rinsed under running water as the unit is waterproof. Ensure the unit is completely dry before reassembling or charging.
5. Close the shaver head assembly securely.

### Storage

- Store the TACSHAVER in its provided storage pouch when not in use to protect it from dust and damage.
- Store in a cool, dry place, away from direct sunlight and extreme temperatures.

## Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Shaver does not turn on. | Battery is low or depleted. | Charge the shaver for 4-5 hours. |
| Poor shaving performance. | Blades are dirty or clogged with hair. | Clean the shaver heads thoroughly using the cleaning brush or by rinsing. |
| Shaver pulls hair. | Blades are dull or unit is not fully charged. | Ensure full charge. If problem persists, blades may need replacement (contact support). |
| Charging light not working. | Faulty cable or power source. | Try a different USB cable or power adapter. Ensure connection is secure. |

## Specifications

**Model:** 2818

**Brand:** Bell+Howell

**Power Source:** Rechargeable (USB Charging Cable included)

**Blades:** Stainless Steel Rotary Blades

**Features:** 2-in-1 Shaver & Trimmer, Waterproof, Compact, Cordless

**Color:** Black

**Item Weight:** 0.19 Kilograms (approx. 6.74 ounces)

**Package Dimensions:** 7.24 x 5.08 x 2.28 inches

**Manufacturer:** Emson

**Image Description:** This image presents a table comparing features of the Bell+Howell TACSHAVER in both English and French. Key features listed include "Close Shave," "Water Proof," "Stainless Steel Blades," "3 Rotary Heads For Smooth Shave," "Pop Up Trimmer For Sidebur/beard Edges," "No Cuts/no Bleeding," "Includes Storage Pouch," "Cleaning Brush," and "USB Charging Cable."

## Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Bell+Howell website. Keep your proof of purchase for warranty claims.
**Manufacturer:** Emson
**Amazon Store Link:** Visit the Bell+Howell Store on Amazon

© 2025 Bell+Howell. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B083C53BBK**

More documents and user manuals: **https://manuals.plus/**