Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit Replacement Remote Control

ZdalaMit Replacement Remote Control User Manual

For Vizio Soundbar Models: SB3651-E6, SB3820-C6, SB3851-D0, SB4451-C0, SB4051-D5, SB4551-D5

1. Introduction

This document provides comprehensive instructions for the ZdalaMit Replacement Remote Control. It is designed to function with specific Vizio Soundbar models without the need for programming or pairing. Please read this manual thoroughly to ensure proper use and longevity of your remote control.

2. Getting Started

2.1 Package Contents

- 1x ZdalaMit Replacement Remote Control

2.2 Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included) for operation. No programming or pairing is necessary; simply install the batteries, and the remote will be ready for use.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch and lift to open the compartment.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align with the indicators inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.



Image: Angled view of the ZdalaMit Replacement Remote Control, showing its ergonomic design and the location of the battery compartment on the reverse side.

3. Operating Instructions

The remote control features a standard layout for Vizio soundbar functions. Point the remote directly at your soundbar for optimal performance.



Image: Front view of the ZdalaMit Replacement Remote Control, displaying all buttons and their labels for easy identification.

3.1 Button Functions

- **Power Button ( ):** Turns the soundbar on or off.
- **Input Button (⏏):** Cycles through available audio input sources (e.g., HDMI, Optical, Bluetooth).
- **Bluetooth Button (⌘):** Activates Bluetooth pairing mode or switches to the Bluetooth input.
- **Volume Up (+):** Increases the soundbar's volume.
- **Volume Down (-):** Decreases the soundbar's volume.
- **Play/Pause ( ):** Plays or pauses audio playback.
- **Previous Track ( ):** Skips to the beginning of the current track or the previous track.
- **Next Track ( ):** Skips to the next track.
- **Mute Button ( ):** Mutes or unmutes the soundbar's audio output.
- **TVOL (TV Volume):** Adjusts the TV volume if the soundbar is connected via HDMI ARC and supports CEC.

- **TSHD (TruSurround HD):** Activates or deactivates TruSurround HD audio enhancement.
- **LAST:** Recalls the last input source or setting.
- **BASS:** Adjusts the bass level of the soundbar.
- **EQ (Equalizer):** Cycles through preset equalizer modes (e.g., Movie, Music, Direct).
- **TREB (Treble):** Adjusts the treble level of the soundbar.

4. Care and Maintenance

4.1 Cleaning

To clean the remote control, use a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these may damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries or different types of batteries.

4.3 Storage

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are installed correctly with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the soundbar's infrared receiver.
  - Confirm you are pointing the remote directly at the soundbar.
- **Specific functions not working:**
  - Verify that your Vizio soundbar model is listed as compatible in Section 6.1.
  - Some advanced functions may depend on the specific soundbar model's capabilities.

6. Product Specifications

6.1 Compatible Vizio Soundbar Models

- SB3651-E6
- SB3820-C6
- SB3851-D0
- SB4451-C0
- SB4051-D5
- SB4551-D5

6.2 General Specifications

- **Brand:** ZdalaMit
- **Product Dimensions:** 5.1 x 1.2 x 0.5 inches (approximately)
- **Item Weight:** 1.41 ounces (without batteries)
- **Power Supply:** 2 x 1.5V AAA Alkaline Battery
- **Color:** Black

7. Support

For any questions or assistance regarding your ZdalaMit Replacement Remote Control, please contact our customer support. We are available to help with any queries you may have.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083PXR5J3

More documents and user manuals: **https://manuals.plus/**