JUKSTG HD1906C

JUKSTG LED Desk Lamp HD1906C User Manual

Model: HD1906C | Brand: JUKSTG

INTRODUCTION

Thank you for choosing the JUKSTG LED Desk Lamp. This manual provides essential information for the safe and efficient operation of your lamp. Please read it thoroughly before use and retain it for future reference.

SAFETY INSTRUCTIONS

- Ensure the power supply voltage matches the lamp's requirements (15V).
- Do not disassemble or modify the lamp.
- Avoid exposing the lamp to water or high humidity.
- Keep the lamp away from heat sources.
- Clean the lamp with a soft, dry cloth. Do not use abrasive cleaners.
- If any issues arise, disconnect the power immediately and contact customer support.

PACKAGE CONTENTS

- JUKSTG LED Desk Lamp (Model HD1906C)
- Power Adapter (Electric Cable)
- User Manual

PRODUCT OVERVIEW

The JUKSTG LED Desk Lamp is designed for optimal lighting with eye-caring features. It includes 64 high-quality LED beads, offering flicker-free and anti-blue light illumination.

Durability and Elegance

ABS + Aluminium alloy metal body
ensure scratch-resistant and long last using

Figure 1: Lamp construction featuring durable ABS and Aluminum alloy metal body for scratch resistance and longevity.

Figure 2: The lamp boasts a Color Rendering Index (CRI) of 85 or higher, ensuring colors are displayed faithfully and naturally.

Figure 3: Eye-friendly LED technology protects your eyes from fatigue with flicker-free and anti-blue light emission.

SETUP

1. Unpack the lamp and all components from the packaging.

2. Place the lamp base on a stable, flat surface.

3. Connect the power adapter cable to the lamp's power input port.

4. Plug the power adapter into a suitable electrical outlet.

5. Adjust the lamp head and arm to your desired position. The lamp features multi-angle adjustments: the base can tilt 40°, the head can tilt 180° upwards, and rotate 350°.

Figure 4: Multi-angle adjustments allow you to position the light precisely where needed. The lamp head tilts 180 degrees, the arm tilts 40 degrees, and the base rotates 350 degrees.

OPERATING INSTRUCTIONS

Touch Control Panel

The lamp is equipped with a sensitive touch control panel on its base for easy operation. It also features a memory function that recalls the last used brightness and mode settings.

Power On/Off

- **Power Button:** Lightly touch the power icon on the base to turn the lamp ON or OFF.

Adjusting Brightness Levels

The lamp offers 10 levels of brightness. To adjust:

- **Brightness Slider:** Slide your finger along the brightness control area on the touch panel to increase or decrease the light intensity.
- Alternatively, tap specific points on the slider for quick adjustments.

Figure 5: The lamp provides 10 distinct brightness levels, allowing precise control over illumination intensity.

Changing Color Modes (Color Temperature)

The lamp features 5 color temperature modes to suit various activities and preferences.

- **Mode Button:** Touch the mode icon (often represented by a sun or color temperature symbol) to cycle through the 5 available color modes:

  - 6000K (Cool White) - Ideal for focused work.
  - 4700K (Natural White) - General purpose lighting.
  - 4200K (Neutral White) - Balanced light.
  - 3800K (Warm White) - Relaxed reading.
  - 3000K (Warm Yellow) - Ambient or night light.

Figure 6: Select from 5 distinct color modes (color temperatures) to match your activity or mood.

MAINTENANCE

- **Cleaning:** Disconnect the power before cleaning. Use a soft, dry, lint-free cloth to wipe the lamp. Do not use liquid cleaners, sprays, or abrasive materials.
- **Storage:** If storing the lamp for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight.
- **LEDs:** The LED light source is integrated and not user-replaceable.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	No power supply. Power adapter not connected properly.	Check if the power adapter is securely plugged into both the lamp and the wall outlet. Try a different outlet.

Problem	Possible Cause	Solution
Light flickers or is unstable.	Loose connection. Incompatible power source.	Ensure all connections are secure. Use the original power adapter.
Touch controls are unresponsive.	Dust or moisture on the touch panel. Temporary software glitch.	Clean the touch panel with a dry cloth. Disconnect the power for 30 seconds, then reconnect.

If the problem persists after trying these solutions, please contact JUKSTG customer support.

SPECIFICATIONS

Brand	JUKSTG
Model Number	HD1906C
Dimensions (D x W x H)	14.9 cm x 20 cm x 42 cm
Weight	1.2 Kilograms
Material	ABS, Aluminum Alloy
Color	White
Light Source	64 LEDs
Wattage	12 Watts
Voltage	15 Volts
Luminous Flux	820 lm
Color Modes	5 (e.g., 6000K, 4700K, 4200K, 3800K, 3000K)
Brightness Levels	10
Switch Type	Touch Control
Special Features	Dimmable, Eye-Caring (Flicker-free, Anti-blue light), Memory Function, Multi-angle Adjustment, CRI ≥ 85

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact JUKSTG customer service directly. Keep your purchase receipt as proof of purchase.
Note: The product is ETL certified.