oneisall X2

oneisall Dog Clippers User Manual

Model: X2 | Brand: oneisall

Introduction

This manual provides comprehensive instructions for the safe and effective use, maintenance, and troubleshooting of your oneisall Dog Clippers. Designed for low noise and efficient grooming, these clippers are suitable for various pet hair types and sizes.

What's Included

Your oneisall Dog Grooming Kit includes the following components:

- Oneisall Dog Grooming Clipper (Gold)
- 6 Guide Guards (3 mm, 6 mm, 9 mm, 12 mm, 15 mm, 18 mm)
- Cleaning Brush
- Comb
- Scissor
- Charging Cable
- Lubricating Oil



Figure 1: Complete Oneisall Dog Grooming Kit contents.

Setup

1. ### Charging the Clipper

   Before first use, fully charge the clipper. Connect the charging cable to the clipper's charging port and plug it into a power outlet. The built-in LCD display will show the battery life percentage. A full charge takes approximately 3 hours and provides 3-4 hours of runtime.



Figure 2: LCD display showing battery life during charging or operation.

2. **Attaching Guide Guards**

   Select the desired guide guard (3mm, 6mm, 9mm, 12mm, 15mm, or 18mm) based on the desired hair length. Align the guard with the clipper blade and push it firmly until it clicks into place. Ensure it is securely attached before use.



Figure 3: Various guide guards for different hair lengths.

Operating Instructions

1. **Pre-Grooming Preparation**

   For best results, ensure your pet's coat is clean, dry, and free of tangles. For pets with long and thick hair, a preliminary trim with the included scissors can enhance the grooming experience and prevent clogging.

2. **Powering On and Speed Selection**

Press the power button to turn on the clipper. It features a 2-speed setting. Speed 1 is ideal for small dogs or general trimming, while Speed 2 provides more power for dogs with thick coats or matted fur.



Figure 4: Speed settings for optimal grooming based on pet size and coat thickness.

3. **Grooming Technique**

Hold the clipper firmly and move it in the direction of hair growth. Apply gentle, even pressure. The ultra-quiet and low vibration design (below 50 dB) helps keep pets calm during grooming.



Figure 5: The clipper's low noise level helps prevent startling pets during grooming.

Your browser does not support the video tag.

Video 1: Demonstration of the oneisall Dog Clippers in action, highlighting its quiet operation and ease of use.

Maintenance

1. ### Cleaning the Blade

   The ceramic blade is detachable and waterproof for easy cleaning. After each use, remove the blade by adjusting the gear to 0.8mm and pushing the blade down. Use the provided cleaning brush to remove any trapped hair. The

blade can be rinsed directly under running water.



Figure 6: Step-by-step guide for detaching and reattaching the clipper blade for cleaning.

2. **Lubricating the Blade**

   Apply a few drops of the provided lubricating oil to the blade before or after each use to ensure smooth operation and prolong blade life.

Troubleshooting

Problem	Possible Cause	Solution
Clipper not turning on	Low battery; Power button not pressed firmly.	Charge the clipper fully; Press the power button firmly.
Clipper pulling hair	Dull blade; Hair is tangled or matted; Blade not oiled.	Clean and oil the blade; Pre-trim matted hair with scissors; Ensure hair is clean and dry.
Clipper getting warm	Extended use; Blade needs lubrication.	Allow clipper to cool down; Apply lubricating oil to the blade.

Specifications

Model: X2

Item Weight: 7.2 ounces (205 Grams)

Product Dimensions: 3.94 x 3.15 x 0.79 inches

Material: Ceramic, Plastic

Battery: 1 Lithium Polymer battery (included)

Charging Time: Approximately 3 hours)

Operating Time: 3-4 hours on a full charge

Noise Level: Below 50 dB

Adjustable Blade Settings: 0.8mm, 1.1mm, 1.4mm, 1.7mm, 2.0mm

Guide Guard Lengths: 3mm, 6mm, 9mm, 12mm, 15mm, 18mm

Safety Information

WARNING:

- Keep away from face and eyes.
- Do not ingest or inhale small parts.
- Clean with a damp cloth.
- Not suitable for children; use under adult supervision.

Warranty and Support

Oneisall offers a 2-year warranty on this product. For any issues or support, please contact oneisall customer service. Many users have reported excellent warranty support and quick resolutions for product concerns.
For more information or to contact support, please visit the officialoneisall Store on Amazon.

© 2025 oneisall. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question