Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AIDITIYMI RMT-AH411U

AIDITIYMI RMT-AH411U Replacement Remote Control User Manual

For Sony Sound Bar Speaker Systems HT-SF200, HT-S100F, HT-SF150

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of the AIDITIYMI RMT-AH411U replacement remote control. This remote is designed to be compatible with specific Sony Sound Bar Speaker Systems, including models HT-SF200, HT-S100F, and HT-SF150.

Please read this manual thoroughly to ensure proper use and to maximize the functionality of your replacement remote control.

2. Product Overview

The AIDITIYMI RMT-AH411U is a direct replacement remote control, replicating the functions of the original Sony remote. It features a standard layout for easy navigation and control of your sound bar.





Image 2.1: Front view of the RMT-AH411U remote control. This image displays the full button layout, including power, input, volume, and sound mode selection buttons.

Button Functions:

- **Power Button:** Turns the sound bar on or off.
- **INPUT:** Selects the audio input source (e.g., TV, Bluetooth).
- **AUTO SOUND:** Activates automatic sound optimization.
- **STANDARD:** Sets the sound mode to standard.
- **CINEMA:** Optimizes sound for movie viewing.
- **MUSIC:** Optimizes sound for music playback.

- **VOICE:** Enhances vocal clarity.
- **NIGHT:** Adjusts sound for low-volume listening, reducing sudden loud sounds.
- **Volume (+/-):** Increases or decreases the sound bar's volume.
- **Mute ( ):** Mutes or unmutes the sound.
- **INDICATOR:** (Function may vary by sound bar model, often related to status display).
- **PLAY MODE:** (Function may vary, often related to playback options).
- **AUDIO:** (Function may vary, often related to audio settings).
- **ENTER:** Confirms selections in menus.
- **Navigation Buttons (Up, Down, Left, Right):** Used for menu navigation.
- **Playback Controls (Play/Pause, Skip Forward, Skip Backward):** Controls media playback.

3. Setup

Battery Installation:

The AIDITIYMI RMT-AH411U remote control requires two (2) AAA alkaline batteries for operation. No programming is required; simply install the batteries, and the remote will be ready for use with compatible Sony Sound Bar models.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards and remove it.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.





Image 3.1: Rear view of the RMT-AH411U remote control with the battery cover removed, illustrating the correct orientation for AAA battery insertion.

4. Operating Instructions

Once batteries are installed, the AIDITIYMI RMT-AH411U remote control is immediately operational with compatible Sony Sound Bar models. No additional pairing or programming steps are required.

Compatibility:

This remote control is compatible with the following Sony Sound Bar Speaker System models:

- HT-SF200
- HT-S100F
- HT-SF150

Basic Operation:

1. **Power On/Off:** Point the remote at your sound bar and press the**Power Button**.

2. **Adjust Volume:** Use the **Volume +** and **Volume -** buttons to control the audio level.
3. **Change Input:** Press the **INPUT** button repeatedly to cycle through available audio sources (e.g., TV, Bluetooth, HDMI).
4. **Select Sound Mode:** Use buttons like **AUTO SOUND**, **STANDARD**, **CINEMA**, **MUSIC**, **VOICE**, or **NIGHT** to apply different audio profiles.
5. **Mute Audio:** Press the **Mute** button to temporarily silence the sound bar. Press it again to restore audio.

5. Maintenance

Battery Replacement:

Replace batteries when the remote's responsiveness decreases or it stops functioning. Always replace both AAA batteries simultaneously with new ones. Do not mix old and new batteries, or different types of batteries.

Cleaning:

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

6. Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Check for any obstructions between the remote control and the sound bar's infrared receiver.
  - Ensure you are within the effective operating range and pointing the remote directly at the sound bar.
- **Specific buttons not working:**
  - This remote is a replacement and may not support all advanced functions of the original sound bar remote if those functions were unique to the original. Verify compatibility with basic functions.
  - Ensure the sound bar model is listed in the compatible models section (HT-SF200, HT-S100F, HT-SF150).

7. Specifications

Model Number	RMT-AH411U
Brand	AIDITIYMI
Compatible Sound Bar Models	Sony HT-SF200, HT-S100F, HT-SF150
Power Source	2 x AAA 1.5V Alkaline Batteries (not included)
Dimensions (L x W x H)	Approximately 6 x 2 x 0.6 inches (15.24 x 5.08 x 1.52 cm)
Weight	Approximately 1.44 ounces (40.8 grams)
Color	Black

8. Warranty and Support

Information regarding product warranty and customer support is not provided in the available product data. For any warranty claims or technical assistance, please refer to the retailer or manufacturer's official website where the product was purchased.

© 2023 AIDITIYMI. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083R82C32

More documents and user manuals: **https://manuals.plus/**