John Deere 522, 524

John Deere 522, 524 Snow Blower Service Manual

Detailed Repair and Maintenance Instructions

1. Introduction to this Service Manual

This Service Manual for John Deere 522 and 524 Snow Blowers provides comprehensive information for mechanics and technicians on how to properly disassemble, repair, and reassemble your equipment. It is an essential resource for diagnosing issues, performing routine maintenance, and executing complex repairs. This manual is a factory-written reproduction, mirroring the original documentation provided to dealer service shops when the equipment was new. It covers all necessary procedures to ensure the longevity and optimal performance of your John Deere snow blower.




Image of the front cover of the John Deere 522 and 524 Snow Blower Service Manual, illustrating the manual's appearance.

2. General Safety Information

Always prioritize safety when performing any service or maintenance on your John Deere snow blower. Failure to follow safety precautions can result in serious injury or damage to the equipment.

- **Read the Manual:** Familiarize yourself with all instructions and warnings before beginning any work.
- **Personal Protective Equipment (PPE):** Always wear appropriate PPE, including safety glasses, gloves, and sturdy footwear.
- **Disconnect Power:** Before servicing, ensure the engine is off, the spark plug wire is disconnected, and all moving parts have stopped.
- **Ventilation:** Work in a well-ventilated area, especially when dealing with fuel or exhaust fumes.
- **Secure Equipment:** Ensure the snow blower is stable and cannot move unexpectedly during service.
- **Proper Tools:** Use only the correct tools for each task to prevent damage and injury.

3. Component Identification and Overview

This section provides an overview of the main components of the John Deere 522 and 524 Snow Blowers. Understanding the location and function of each part is crucial for effective servicing.

- **Engine Assembly:** Power source for the snow blower.
- **Auger/Impeller System:** Collects and expels snow.
- **Drive System:** Transmits power to the wheels or tracks.
- **Chute Assembly:** Directs the expelled snow.
- **Control Panel:** Houses operational controls and levers.
- **Frame and Housing:** Structural components protecting internal parts.

Refer to specific diagrams within the manual for detailed exploded views and part numbers for each component.

4. Disassembly and Assembly Procedures

This section outlines the systematic steps for disassembling and reassembling various components of the snow blower. Always follow the specified torque values and sequence for fasteners.

4.1 Engine Removal and Installation

1. Drain fuel and oil.
2. Disconnect spark plug wire and all electrical connections.
3. Remove drive belts and linkages.
4. Unbolt engine mounting hardware.
5. Carefully lift and remove the engine.
6. Reverse steps for installation, ensuring all connections are secure and belts are properly tensioned.

4.2 Auger System Disassembly

- Remove shear pins.
- Detach auger housing from main frame.
- Carefully remove auger blades and shaft.
- Inspect bearings and seals for wear.

5. Maintenance Procedures

Regular maintenance is crucial for the reliable operation and longevity of your John Deere snow blower. Adhere to the recommended service intervals.

5.1 Engine Oil Change

1. Run engine briefly to warm oil.
2. Place drain pan under drain plug.
3. Remove drain plug and allow oil to drain completely.
4. Replace drain plug and refill with recommended oil type and quantity.
5. Check oil level with dipstick.

5.2 Spark Plug Inspection and Replacement

- Remove spark plug wire.
- Use a spark plug wrench to remove the plug.
- Inspect for fouling, wear, or damage.
- Gap new plug to specifications before installing.

5.3 Drive Belt Inspection and Adjustment

Regularly inspect drive belts for cracks, fraying, or excessive wear. Adjust tension as needed according to the manual's specifications to ensure proper power transfer.

6. Troubleshooting Guide

This section provides a guide to common problems and their potential solutions. Always perform basic checks before attempting complex repairs.

Problem	Possible Cause	Solution
Engine Fails to Start	No fuel, fouled spark plug, clogged fuel filter, carburetor issues.	Check fuel level, clean/replace spark plug, replace fuel filter, clean carburetor.
Snow Blower Not Throwing Snow	Clogged chute, worn auger/impeller, broken shear pins, loose drive belt.	Clear chute, inspect/replace auger/impeller, replace shear pins, adjust/replace drive belt.
Loss of Drive Power	Loose or worn drive belt, transmission issue, low tire pressure (if applicable).	Inspect/adjust/replace drive belt, consult transmission section of manual, check tire pressure.

7. Technical Specifications

This section provides key technical specifications for the John Deere 522 and 524 Snow Blowers. Refer to the full manual for detailed component-specific specifications and torque settings.

- **ASIN:** B083RY3F77
- **Publisher:** jensale
- **Publication Date:** January 1, 2019
- **Language:** English

Note: Specific engine models, horsepower, clearing width, and other operational specifications are detailed within the comprehensive service manual.

© 2019 John Deere. All rights reserved. This is a reproduction service manual.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question