Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nostalgia SM32RR

Nostalgia 32-Ounce Frozen Drink & Slush Maker

Model: SM32RR - Instruction Manual



The Nostalgia 32-Ounce Frozen Drink & Slush Maker in Retro Red, ready to create refreshing beverages.

Introduction

Welcome to your new Nostalgia 32-Ounce Frozen Drink & Slush Maker. This appliance is designed to create a variety of refreshing frozen beverages, including slushies, margaritas, and daiquiris, right in your home. Please read these instructions carefully before first use to ensure safe and optimal operation.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before operating this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or any part of the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest repair shop for examination, repair, or adjustment.
- The use of accessory attachments not provided by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use appliance for other than intended use.
- **Important:** This machine is designed for sugar-based beverages. Sugar-free drinks and beverages with high alcohol content may not freeze properly.

Parts Overview

Familiarize yourself with the main components of your Frozen Drink & Slush Maker:



This image illustrates the internal mechanism, highlighting where to add ice, salt, and your sugar-based drink for optimal slushie creation.

- **Lid:** Secures the blending chamber.
- **Inner Metal Canister:** Holds ice and salt for freezing.
- **Blending Paddle:** Scrapes frozen mixture from the canister walls.
- **Outer Clear Chamber:** Holds the beverage to be frozen.
- **Dispensing Spout:** For serving your frozen drink.
- **Control Switch:** Selects FREEZE, OFF, or DISPENSE modes.
- **Motor Base:** Houses the motor and controls.
- **Drip Tray:** Collects any spills from the spout.

Before First Use

Before using your Frozen Drink & Slush Maker for the first time:

1. Unpack the unit and remove all packaging materials.
2. Wipe down the exterior of the motor base with a damp cloth.
3. Wash the lid, inner metal canister, blending paddle, outer clear chamber, and drip tray in warm, soapy water. Rinse thoroughly and dry completely.
4. Ensure all parts are dry before assembly.

Setup

To set up your appliance:

1. Place the motor base on a stable, level surface away from the edge of the counter.
2. Ensure the outer clear chamber is securely seated on the motor base.
3. Insert the inner metal canister into the center of the outer clear chamber.
4. Place the blending paddle inside the inner metal canister, ensuring it sits correctly on the central spindle.
5. Place the lid on top, ensuring it is properly aligned and secured. The locking handle helps secure the lid.
6. Position the drip tray under the dispensing spout.

Operating Instructions

Follow these steps to create your frozen beverages:

1. Ensure the unit is unplugged and assembled as described in the Setup section.
2. **Prepare the Freezing Mixture:** Fill the inner metal canister with crushed ice. A recommended method for effective freezing is to add approximately 2 tablespoons of Kosher salt to the bottom of the canister, then fill it halfway with crushed ice. Add another tablespoon of Kosher salt, then fill the rest of the canister to the top with crushed ice.
3. **Add Beverage:** Pour your desired sugar-based beverage into the outer clear chamber. Do not exceed the MAX FILL line indicated on the chamber. Pre-chilling your beverage can help speed up the freezing process.
4. **Power On:** Plug the unit into a suitable electrical outlet.
5. **Start Freezing:** Turn the control switch on the side of the unit to the "FREEZE" position. The blending paddle will begin to rotate, and the freezing process will start.
6. **Monitor and Adjust:** The machine will churn and freeze the beverage. This typically takes 10-15 minutes, depending on the beverage and initial temperature. If the ice level in the inner canister drops significantly during operation, you may add more crushed ice through the opening in the lid to maintain optimal freezing.
7. **Dispense:** Once your desired slushy consistency is achieved, turn the control switch to the "DISPENSE" position. Place a glass under the spout and pull the spout handle forward to release the frozen drink.
8. **Turn Off:** After dispensing, return the control switch to the "OFF" position and unplug the unit.

Note: The double-insulated design of the outer chamber helps keep your drinks cold for extended periods.

Your browser does not support the video tag.

Video demonstrating the operation of the Nostalgia 32-Ounce Slush Drink Maker, showing the process of adding ingredients and

dispensing the finished product.

Cleaning and Maintenance

Proper cleaning ensures the longevity and hygiene of your appliance:

1. Always unplug the unit before cleaning.
2. Disassemble the lid, blending paddle, inner metal canister, outer clear chamber, and drip tray from the motor base.
3. Wash all removable parts (lid, paddle, canisters, chamber, drip tray) with warm, soapy water. Rinse thoroughly to remove all soap residue.
4. Dry all parts completely before reassembling or storing.
5. **Do NOT immerse the motor base in water or any other liquid.**Wipe the motor base with a damp cloth and dry thoroughly.
6. This appliance is **NOT** dishwasher safe. Hand washing is required for all removable parts.
7. For storage, ensure the unit is clean and dry, then store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Beverage is not freezing or is too watery.	◦ Insufficient ice or salt in the inner canister. ◦ Beverage is sugar-free or has high alcohol content. ◦ Beverage was not pre-chilled.	◦ Ensure the inner canister is filled with crushed ice and the correct amount of Kosher salt (refer to Operating Instructions). ◦ Use only sugar-based beverages. Sugar-free or high-alcohol content drinks will not freeze properly. ◦ Pre-chill your beverage in the refrigerator before adding it to the machine.
Machine is making loud noises or jamming.	◦ Frozen drink has become too thick. ◦ Ice in the inner canister is too large or not crushed.	◦ Turn off the unit. Allow the mixture to soften slightly, or add a small amount of liquid to thin it. ◦ Ensure only crushed ice is used in the inner canister.
Unit is leaking.	◦ Parts not assembled correctly. ◦ Dispensing spout is not fully closed.	◦ Review the Setup section and ensure all components are securely in place. ◦ Check that the dispensing spout is pushed fully closed after use.

Specifications



Visual representation of the product dimensions.

Feature	Detail
Brand	Nostalgia
Model Number	SM32RR
Capacity	32 Ounces (approx. 2 pounds)
Material	Stainless Steel (canister), Plastic (housing)
Color	Retro Red
Item Weight	5.5 pounds

Feature	Detail
Control Type	Manual (3-way switch: Freeze, Off, Dispense)
UPC	082677001320

Warranty

This Nostalgia product is covered by a limited warranty from the date of purchase. Please refer to the warranty card included with your product for specific terms and conditions. Keep your proof of purchase for warranty claims.

Customer Support

For further assistance, questions, or to inquire about replacement parts, please visit the official Nostalgia website or contact their customer service department. Contact information can typically be found on the product packaging or the manufacturer's website.

© 2023 Nostalgia Products LLC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B083VNPKF2

More documents and user manuals: **https://manuals.plus/**