Westek ZHL210MB

Westek ZHL210MB Commercial 2-Device Universal Remote Control User Manual

Model: ZHL210MB

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Westek ZHL210MB Commercial 2-Device Universal Remote Control. Designed for ease of use and durability, this remote allows you to control two devices, such as a television and a DVD/VCR player, with a single unit. It features Microban antimicrobial protection for enhanced hygiene.

Key Features

- **Microban Antimicrobial Protection:** Integrated technology that continuously inhibits the growth of bacteria on the remote's surface, contributing to a cleaner environment.
- **2-Device Control:** Capable of controlling two different entertainment devices, typically a TV and a DVD/VCR.
- **Universal Compatibility:** Works with a wide range of television brands.
- **Commercial Design:** Features a secure, screw-on battery drawer suitable for hospitality and commercial environments.
- **User-Friendly Interface:** Equipped with large, rubberized buttons for clear readability and comfortable operation.



Image: Diagram showing how Microban antimicrobial protection inhibits bacterial growth on surfaces over time compared to an unprotected surface.

Product Overview

Familiarize yourself with the layout and functions of your remote control.



Image: Front view of the Westek ZHL210MB remote control, displaying all buttons including power, device selection (TV, DVD/VCR), number pad, volume, channel, and playback controls.



Image: Back view of the Westek ZHL210MB remote control, highlighting the secure, screw-on battery compartment cover.



Image: Side profile view of the Westek ZHL210MB remote control, showing its ergonomic design.

Button Functions:

- **POWER (●):** Turns the selected device on or off.
- **TV** / **DVD** / **VCR:** Selects the device you wish to control.
- **Number Pad (0-9):** For direct channel entry or menu navigation.
- **VOL (+/-):** Adjusts the volume of the selected device.
- **CH (+/-):** Changes channels on the selected device.
- **PLAY, REW, F.F, STOP, PAUSE, REC:** Standard playback controls for DVD/VCR.
- **MENU, SLEEP, EXIT, INPUT:** Various function buttons for device control.
- **ENTER:** Confirms selections.
- **LAST:** Returns to the previous channel.
- **CC:** Activates/deactivates Closed Captioning.

Setup

1. Battery Installation

The remote requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Using a small Phillips head screwdriver, carefully loosen the screw securing the battery compartment cover.
3. Remove the cover.
4. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
5. Replace the battery compartment cover and tighten the screw to secure it.

2. Programming Your Remote

Your Westek ZHL210MB remote is a universal remote and needs to be programmed to control your specific devices. While specific programming codes are not provided in this manual, universal remotes typically use one of two methods:

- **Auto Code Search:** This method allows the remote to scan through a library of codes until it finds one that operates your device.
- **Direct Code Entry:** This method requires you to enter a specific 3, 4, or 5-digit code for your device's brand, usually found in a separate code list provided with the remote or available online from the manufacturer.

Please refer to the separate code list or the Westek website for detailed programming instructions and device codes specific to your remote model (ZHL210MB).

Operating Your Remote

1. Selecting a Device

To control a specific device (TV, DVD, or VCR), press the corresponding device button at the top of the remote. The remote will then send commands to that selected device.

- Press **TV** to control your television.
- Press **DVD/VCR** to control your DVD player or VCR.

2. Basic Functions

- **Power On/Off:** Press the **POWER** button.
- **Volume Control:** Use the **VOL +** and **VOL -** buttons.
- **Channel Selection:** Use the **CH +** and **CH -** buttons for sequential channel changes, or the number pad for direct channel entry.
- **Playback Controls:** For DVD/VCR, use **PLAY**, **REW**, **F.F**, **STOP**, **PAUSE**, and **REC** buttons.
- **Menu Navigation:** Use the **MENU** button to access device menus and the arrow keys (if available, or number pad for selection) to navigate.

Maintenance

1. Cleaning Your Remote

The Westek ZHL210MB remote features Microban antimicrobial protection, which helps keep the surface cleaner. To maintain hygiene and functionality:

- Wipe the remote regularly with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote or its antimicrobial properties.
- Ensure the remote is dry before use.

2. Battery Replacement

Replace batteries when the remote's performance diminishes or it stops responding. Follow the battery installation steps outlined in the "Setup" section.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly inserted and have sufficient charge. Replace if necessary.
  - Ensure the remote is pointed directly at the device's infrared sensor.
  - Verify that the correct device mode (TV, DVD/VCR) is selected.
  - Confirm the remote is properly programmed for your device. Re-program if unsure.
- **Device not turning on/off:**
  - Ensure the device is plugged into a power source.
  - Try using the device's original remote or manual controls to confirm it is functional.
- **Only some functions work:**
  - This may indicate an incomplete or incorrect programming code. Try re-programming the remote using a different code for your device brand, if available.

Specifications

Brand	Westek
Model Name	ZHL210MB
Max Supported Devices	2
Compatible Devices	Television, DVD/VCR
Connectivity Technology	Infrared
Controller Type	Button Control
Battery Description	AAA (2 required, not included)
UPC	070686003626

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question