Bily BG371200

Bily Retractable Safety Gate Instruction Manual

Model: BG371200

1. Product Overview

The Bily Retractable Safety Gate provides a secure barrier for various openings in your home. Its design features a durable mesh that retracts when not in use, offering a space-efficient solution without a tripping hazard. This gate is suitable for doorways, hallways, and the bottom of stairs. It can also be used outdoors on decks, patios, and porches. The gate includes two sets of mounting brackets for convenient relocation between different areas.

Key Features:

- Sturdy and durable mesh barrier.
- Retracts completely when not in use, eliminating tripping hazards.
- Suitable for openings up to 55 inches wide and 32.5 inches high.
- Designed for both indoor and outdoor use.
- Includes two sets of mounting brackets for flexible placement.

2. Important Safety Information

WARNING: Read all instructions before installation and use. Failure to follow these warnings and instructions could result in serious injury or death.

- This safety gate is intended for use with children from 6 to 24 months.
- NEVER use at the top of stairs. This gate is designed for use at the bottom of stairs, doorways, and hallways.
- Always ensure the gate is securely locked before leaving a child unattended.
- Periodically check all fasteners to ensure they are tight and secure.
- Do not use this gate if any components are missing or damaged.
- Never allow children to climb on, shake, or hang from the gate.
- Keep small parts out of reach of children during assembly.

3. Package Contents

Please verify that all components are present before beginning installation:

- Retractable Gate Unit (main mesh barrier and housing)
- Mounting Brackets (2 sets)
- Wall Spacers (if applicable for uneven surfaces)
- Screws and Wall Anchors
- Installation Template

4. Setup and Installation

The Bily Retractable Safety Gate can be installed with an inside frame or outside frame mount. Refer to the included installation template for precise drilling locations.

4.1 Choose Installation Location

Select a flat, stable surface for mounting. Ensure there are no obstructions that would prevent the gate from retracting or extending fully. This gate is suitable for openings up to 55 inches (139.7 cm) wide.

4.2 Prepare for Mounting

1. Unpack all components and identify the gate unit, mounting brackets, and hardware.
2. Position the installation template at the desired height and location. The gate height is 32.5 inches (82.6 cm).
3. Mark the drilling points accurately using a pencil.

4.3 Attach Mounting Brackets

1. Drill pilot holes at the marked locations. Use appropriate drill bit size for your wall material and anchors.
2. Insert wall anchors if installing into drywall or masonry.
3. Securely attach the mounting brackets to the wall using the provided screws. Ensure they are level and firmly fixed.



Image: The Bily Retractable Safety Gate shown installed in a doorway, with the mesh partially retracted into its housing on the left side. The gate is black and blends with the door frame.

4.4 Mount the Gate Unit

1. Align the gate unit with the installed mounting brackets.
2. Slide the gate unit onto the brackets until it clicks securely into place.
3. Test the gate by gently pulling and pushing to ensure it is firmly attached and does not wobble.



Image: The Bily Retractable Safety Gate fully extended, showing the black mesh barrier stretched across an opening. The gate's housing is on the left, and the latch mechanism is on the right.

5. Operating the Gate

The Bily Retractable Safety Gate is designed for ease of use while maintaining security.

5.1 To Open the Gate (Retract)

1. Locate the locking mechanism on the top of the gate's handle side.
2. Press and hold the release button or turn the knob (depending on model variation).
3. While holding the button/knob, gently guide the handle towards the main housing unit. The mesh will retract smoothly.
4. Once fully retracted, release the button/knob. The gate will remain open.



Image: A person's hand is shown engaging the latch mechanism on the Bily Retractable Safety Gate, demonstrating how to open or close the gate. The gate is partially extended.

5.2 To Close the Gate (Extend)

1. Press and hold the release button or turn the knob on the handle.
2. Gently pull the handle across the opening until it reaches the opposite mounting bracket.
3. Engage the handle with the latch on the mounting bracket.
4. Release the button/knob. Ensure the gate is securely locked and the mesh is taut.



Image: Two young children are seated on the floor near the Bily Retractable Safety Gate, which is securely closed across a doorway. The gate provides a barrier while the children play.



Image: A small dog is lying on the floor in front of the Bily Retractable Safety Gate, which is closed across a doorway. The gate effectively contains the pet within the designated area.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your Bily Retractable Safety Gate.

- **Cleaning:** Wipe the gate and mesh with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals, as these can damage the material.
- **Inspection:** Periodically inspect the gate for any signs of wear, damage, or loose components. Check the mesh for tears or fraying, and ensure all mounting hardware is tight.
- **Lubrication:** If the retraction mechanism becomes stiff, a small amount of silicone-based lubricant can be applied to the moving parts, avoiding contact with the mesh.

7. Troubleshooting

If you encounter issues with your Bily Retractable Safety Gate, refer to the following common problems and solutions:

- **Gate does not retract smoothly:** Check for any obstructions in the retraction path. Ensure the mesh is not twisted or caught. Clean the mechanism if dirt or debris is present.
- **Gate does not lock securely:** Verify that the handle is fully engaged with the latch on the mounting bracket. Ensure the release button/knob is fully released after closing. Check if the mounting brackets are properly aligned and securely fastened.
- **Gate feels loose or wobbly:** Re-check all mounting screws and ensure they are tightened. If installed into drywall, verify that wall anchors are properly seated and not stripped.
- **Gap at the bottom of the gate:** Ensure the gate is installed at the recommended height according to the template. If a small gap remains, ensure it is not large enough for a child to pass through or get stuck.

8. Specifications

Feature	Specification
Model Number	BG371200
Product Dimensions (Extended)	139.7 cm (W) x 82.6 cm (H) x 7 cm (D)
Maximum Opening Width	55 inches (139.7 cm)
Gate Height	32.5 inches (82.6 cm)
Item Weight	1.59 kg (3.5 lbs)
Material	Plastic, Mesh
Color	Black
Mounting Type	Wall Mount
Manufacturer	EI Brand Management Inc
UPC	627972371206

9. Warranty and Support

For warranty information, product support, or to purchase replacement parts, please contact the manufacturer directly. Keep your proof of purchase for warranty claims.

Manufacturer: EI Brand Management Inc

Refer to the product packaging or the manufacturer's official website for the most current contact details and warranty terms.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question