BABYLO BL11907

Babylo Safe and Secure Playpen User Manual

Model: BL11907
Brand: BABYLO

INTRODUCTION

Thank you for choosing the Babylo Safe and Secure Playpen. This manual provides essential information for the safe and proper assembly, operation, and maintenance of your playpen. Please read all instructions carefully before use and retain this manual for future reference.

Image: The Babylo Safe and Secure Playpen, shown with a baby happily playing inside, demonstrating its spacious and safe environment.

Important Safety Information

Your child's safety is paramount. Always follow these safety guidelines:

- Never leave your child unattended in the playpen.
- Ensure all parts are correctly assembled and securely locked before placing your child in the playpen.
- Do not use the playpen if any parts are broken, torn, or missing. Contact customer support for replacement parts.
- Keep the playpen away from open flames, heaters, and other heat sources.
- Do not place toys with long strings or cords in the playpen to avoid strangulation hazards.
- The playpen is suitable for children aged 6 to 36 months.
- Maximum recommended body weight: 4.7 kg (Note: This specification refers to the product's weight, not the child's. Always adhere to the manufacturer's stated child weight limit, typically found on product packaging or official documentation, for safe use.)
- Only use the mattress/pad provided by the manufacturer or one specifically approved for this playpen.

Setup and Assembly

The Babylo Safe and Secure Playpen is designed for easy assembly. Follow these steps:

1. Unpack all components from the carry bag. Verify that all parts are present: fabric enclosure, frame poles, and connectors.
2. Connect the frame poles using the provided connectors to form the hexagonal structure. Ensure each connection clicks securely into place.
3. Carefully slide the fabric enclosure over the assembled frame. Ensure the mesh sides are properly aligned with the frame sections.
4. Secure the fabric to the frame using any integrated fasteners (e.g., Velcro straps, clips) to ensure a snug fit.
5. Place the soft base material inside the playpen for your baby's comfort.
6. Before use, double-check all connections and ensure the playpen is stable and secure.

Image: The Babylo Safe and Secure Playpen fully assembled, showcasing its hexagonal shape and breathable mesh sides.

Disassembly and Storage

To disassemble the playpen for storage or travel:

1. Remove the soft base material.
2. Unfasten the fabric enclosure from the frame.
3. Carefully disconnect the frame poles by pressing the release buttons (if any) or gently pulling them apart.
4. Fold the fabric and poles compactly.
5. Place all components into the provided carry bag for easy transport and storage.

Image: The Babylo Safe and Secure Playpen compactly folded and stored within its black carry bag, highlighting its portability.

OPERATING INSTRUCTIONS

The Babylo Safe and Secure Playpen is designed for simple and safe use.

- **Zipper Door:** The playpen features a convenient zipper door for easy access. To open, simply pull the zipper downwards. To close, pull the zipper upwards, ensuring it is fully closed to prevent your child from exiting unsupervised.

- **Safe Play Area:** With dimensions of 134 x 116 x 66 cm, this freestanding playpen provides a spacious and secure area for your baby to play, crawl, and explore.

- **Ball Pit Functionality:** The playpen can also be used as a ball pit for added fun. (Note: Play balls are not included).

- **Visibility:** The breathable mesh sides allow for excellent visibility, enabling you to keep an eye on your child while ensuring proper ventilation.

Image: The Babylo Safe and Secure Playpen with its zipper door open, demonstrating easy access for children to crawl in and out.

MAINTENANCE AND CARE

Regular cleaning and maintenance will extend the life of your playpen.

- **Fabric Cleaning:** The fabric enclosure is removable and washable. For best results, hand wash with mild soap and cold water, or machine wash on a gentle cycle. Air dry thoroughly before reassembling. Do not bleach or tumble dry.
- **Frame Cleaning:** Wipe the frame poles and connectors with a damp cloth and mild soap. Dry thoroughly.
- **Inspection:** Periodically inspect all parts for wear, damage, or loose connections. Replace any damaged parts immediately.

TROUBLESHOOTING

If you encounter any issues with your Babylo Safe and Secure Playpen, refer to the following common solutions:

- **Difficulty Assembling Frame:** Ensure you are applying firm, even pressure when connecting poles. Some connections may require a bit of force to click into place securely. Refer to the assembly steps and ensure

connectors are oriented correctly.

- **Fabric Not Fitting Properly:** Ensure the fabric is oriented correctly and stretched evenly over the frame. If it seems too tight, double-check that all frame poles are fully extended and connected.

- **Zipper Issues:** If the zipper is stiff, try applying a small amount of zipper lubricant or a graphite pencil lead along the teeth. Ensure the fabric is not caught in the zipper mechanism.

- **Playpen Feels Unstable:** Re-check all pole connections to ensure they are fully engaged. Make sure the playpen is placed on a flat, level surface.

If the problem persists, please contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	BL11907
Product Dimensions (L x W x H)	134 x 116 x 66 cm
Item Weight	4.7 Kilograms
Material Type	Mesh Fabric, Metal
Material Composition	100% Polyester
Color	Dark Grey
Recommended Age Range	6 to 36 Months
Special Features	Zipper crawl-through door, Mesh sides for ventilation

WARRANTY AND SUPPORT

For warranty information or technical support, please contact BABYLO customer service. Keep your purchase receipt as proof of purchase.

Contact Information: Please refer to the contact details provided on the product packaging or the official BABYLO website for the most up-to-date support information.