Samsung BN59-01303A

Samsung BN59-01303A Remote Control User Manual

Model: BN59-01303A

1. Product Overview

This manual provides instructions for the Samsung BN59-01303A remote control. This remote is designed as a replacement and is ready for use immediately after battery insertion, requiring no programming. It operates via infrared technology and is compatible with a wide range of Samsung televisions and displays.



Image 1.1: Samsung BN59-01303A Remote Control. This image displays the front view of the remote control, showing its button layout and ergonomic design.

1.1 Compatible Models

The BN59-01303A remote control is compatible with, but not limited to, the following Samsung models:

- NU7093, NU7172, NU7172U, UE55NU7093, UE55NU7172U
- E450A1W, ED65E, ED75E, KS9090T
- L22D390EW, L24D390EW, LA19D400E1M, LA22D400E1M, LA32D400E1M, LA32D403E2M, LA32D403E2W
- LE19B450C4WXXU, LE19B650T6W, LE19D450, LE22D450, LE26B350F, LE32B460, LE32D400E1W, LE32D403E2W, LE32D404E2W, LE32D450, LE32D550, LE32D580
- PS42B4300, PS43D450, PS43E400U1W, PS43E450A, PS43E450A1M, PS43E450A1W, PS43E450A1WXXC, PS43E451A2W, PS43E452A4W, PS43E455A1W, PS43E470A1M, PS43F4500AW, PS43F4510AW, PS43F4520AW
- T19B300EW, T22B300EW, T22B300MW, T22B350, T22B350EW, T22C300, T22E390, T23B350EW, T24B300EW, T24B301, T24B301EW, T24B350EW, T24C300, T24C300EW, T27B300EW, T27B300MW
- UA19ES4000M, UA22D5003BJ, UA22D5003BM, UA22D5003BW, UA22ES5000M, UA26D4003BJ, UA26D4003BM, UA26EH4000M, UA26EH4000W, UA28F4000AM, UA32D4003BM, UA32D4003BW, UA32EH4000M, UA32EH4000W, UA32EH4003M, UA32EH5000M, UA32EH5006M
- *And many more Samsung models. Refer to your device's manual for specific remote compatibility.*

2. Setup

2.1 Inserting Batteries

The remote control requires two AAA alkaline batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 2.1: Battery Compartment. This image shows the rear of the remote control with the battery cover removed, illustrating the correct orientation for battery insertion. *(Note: Image is a placeholder, representing the general area for battery access.)*

Important: Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries. Remove batteries if the remote control will not be used for an extended period.

3. Operating the Remote Control

The Samsung BN59-01303A remote control provides intuitive access to your television's functions. Point the remote control directly at the infrared receiver on your TV for optimal performance.

3.1 Basic Functions

- **Power ( ):** Turns the television on or off.
- **Source:** Cycles through available input sources (HDMI, AV, Component, etc.).
- **Volume (+/-):** Increases or decreases the audio volume.
- **Mute ( ):** Silences the television audio.
- **Channel (CH +/-):** Changes the television channel up or down.
- **Number Pad (0-9):** Directly enters channel numbers.
- **Menu:** Opens the television's main menu.
- **Navigation Buttons (Up, Down, Left, Right, Enter):** Used to navigate through menus and select options.
- **Return/Exit:** Returns to the previous screen or exits the current menu.
- **Smart Hub/Home:** Accesses the Smart Hub or Home screen (if supported by your TV model).



Image 3.1: Remote Control Button Layout. This image highlights the various buttons on the remote control, indicating their general functions. *(Note: Image is a placeholder, representing the general button layout.)*

4. Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or solvents.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades. Do not leave depleted batteries in the remote for extended periods, as they may leak and cause damage.
- **Avoid Drops:** Protect the remote from physical impact by avoiding drops or rough handling.

5. Troubleshooting

If you experience issues with your remote control, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly inserted batteries. Obstruction between remote and TV. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the TV and ensure direct line of sight to the IR receiver.

Problem	Possible Cause	Solution
Some buttons not working.	Dirty contacts under the buttons. Damaged button mechanism.	Try cleaning the remote (refer to Maintenance section). If problem persists, the remote may be damaged and require replacement.
Short operating range.	Weak batteries. Interference from other devices.	Replace batteries. Ensure no strong light sources (like direct sunlight) or other infrared devices are interfering with the TV's IR receiver.

6. Specifications

- **Model Name:** BN59-01303A
- **Brand:** Samsung
- **Connectivity Technology:** Infrared (IR)
- **Controller Type:** Button Control
- **Maximum Range:** 10 Meters (approximately 33 feet)
- **Battery Type:** AAA Alkaline (x2, not included)
- **Supported Devices:** Television (Samsung models as listed in Section 1.1)
- **Number of Supported Devices:** 1
- **ASIN:** B0847L8N67
- **GTIN/UPC:** 667379369253, 745062217910

7. Warranty and Support

This remote control is a replacement part. For specific warranty information, please refer to the documentation provided with your original television or contact Samsung customer support directly. Warranty terms may vary by region and retailer.
For further assistance or technical support, please visit the official Samsung website or contact their customer service hotline in your region.

© 2024 Samsung. All rights reserved. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question