Nokia 2720

Nokia 2720 Flip Phone User Manual

Model: TA-1170

Introduction

Welcome to the user manual for your Nokia 2720 Flip Phone. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. The Nokia 2720 is a compact and user-friendly flip phone designed for reliable communication and essential smart features, running on KaiOS.

Important Note on Network Compatibility: This is an unlocked international mobile phone. It is designed to work with GSM networks worldwide that support its frequencies. This device is **NOT compatible** with CDMA networks such as Verizon, Sprint, or Boost. Wireless frequencies for 3G and 4G vary by network and location. A new SIM card or additional configuration may be required for optimal performance. Please verify compatibility with your chosen carrier before use.

Safety Information

- Read all safety information before using your device to ensure safe and proper use.
- Use only original Nokia accessories or accessories approved by Nokia.
- Do not expose your device to extreme temperatures, direct sunlight, or excessive moisture.
- Avoid dropping or subjecting the device to severe impact.
- Keep the device away from pacemakers and other medical devices.
- Dispose of batteries and the device according to local regulations.

What's in the Box

Upon opening the package, please ensure all the following items are present:

- Nokia 2720 Flip Phone Device
- Charger
- Data Cable
- Quick Start Guide

Setup

1. Inserting SIM Card and Battery

To begin using your Nokia 2720, you will need to insert a SIM card and the battery.

1. Open the back cover of the phone by gently prying it from the notch.
2. If the battery is already in place, remove it.
3. Locate the SIM card slot(s). This phone supports Dual SIM. Insert your Nano-SIM card(s) into the designated slot(s) with the gold contacts facing down.
4. Insert the battery, aligning the gold contacts on the battery with those in the phone.
5. Replace the back cover, pressing firmly until it clicks into place.



Image: The Nokia 2720 Flip Phone with its back cover removed, illustrating the placement of the SIM card and battery.

2. Charging the Battery

Before first use, it is recommended to fully charge the battery.

1. Connect the data cable to the charging port on your phone.
2. Connect the other end of the data cable to the charger.
3. Plug the charger into a wall outlet.
4. The battery indicator on the screen will show charging progress.

3. Powering On/Off

- **To Power On:** Press and hold the Power/End Call button until the phone vibrates and the Nokia logo appears.
- **To Power Off:** Press and hold the Power/End Call button, then select "Power off" from the options on the screen.



Image: The Nokia 2720 Flip Phone in its closed state, displaying the time and date on its external screen.

Operating Your Device

1. Basic Navigation

The Nokia 2720 uses a traditional keypad and a directional navigation pad.

- **Navigation Key:** Use the center navigation key to scroll through menus and select items. Press the center button to confirm.
- **Soft Keys:** The two keys directly below the screen (left and right soft keys) perform functions indicated by the text above them on the display.
- **Call/End Key:** Press to make or answer a call, or to end a call and return to the home screen.
- **Back Key:** Returns to the previous screen or menu.



Image: The Nokia 2720 Flip Phone opened, revealing its internal screen displaying various application icons and the full physical keypad for

navigation and input.

2. Making Calls

1. From the home screen, dial the phone number using the keypad.
2. Press the Call key (green button) to initiate the call.
3. To end a call, press the End Call key (red button).
4. To answer an incoming call, press the Call key.

3. Sending Messages

1. Go to **Menu** > **Messages**.
2. Select **New message**.
3. Enter the recipient's phone number or select from contacts.
4. Type your message using the keypad. Press the**#** key to switch between text input modes (e.g., T9, ABC, 123).
5. Press **Send**.

4. Camera Usage

Your Nokia 2720 is equipped with a rear camera.

1. From the home screen, navigate to**Menu** > **Camera**.
2. Frame your shot using the screen as a viewfinder.
3. Press the center navigation key to take a photo.
4. Photos are saved to the Gallery.

5. Connectivity (Wi-Fi)

Connect to Wi-Fi networks for internet access and app functionality.

1. Go to **Menu** > **Settings** > **Network & Connectivity** > **Wi-Fi**.
2. Turn Wi-Fi **On**.
3. Select your desired Wi-Fi network from the list.
4. Enter the network password if prompted, then select**Connect**.

Maintenance

1. Cleaning Your Device

- Use a soft, lint-free cloth to clean the screen and body of the phone.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Avoid getting moisture into openings.

2. Battery Care

- Do not attempt to replace the battery yourself unless it is a user-replaceable type.
- Avoid fully discharging the battery frequently to prolong its lifespan.
- Store the device in a cool, dry place when not in use for extended periods.

3. Software Updates

Periodically check for software updates to ensure your device has the latest features and security enhancements.

1. Ensure your phone is connected to Wi-Fi.
2. Go to **Menu** > **Settings** > **Device** > **Device information** > **Software update**.
3. Follow the on-screen instructions to download and install any available updates.

Troubleshooting

Problem	Possible Solution
Phone does not power on.	Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on. Check if the battery is properly inserted.
Cannot make or receive calls.	Check network signal strength. Ensure SIM card is correctly inserted. Verify network compatibility with your carrier (especially for international versions). Restart the phone.
Poor call quality.	Move to an area with better network coverage. Check for obstructions around the microphone and speaker.
Wi-Fi connection issues.	Ensure Wi-Fi is enabled on the phone. Restart your Wi-Fi router. Re-enter the Wi-Fi password.
Phone is slow or unresponsive.	Close unnecessary applications. Restart the phone. Consider performing a factory reset (backup data first).

Specifications

Feature	Detail
Model Name	Nokia 2720 (TA-1170)
Operating System	KaiOS
Form Factor	Flip Phone
Display Size	2.8 Inches (Internal)
Resolution	320 x 240 pixels
Internal Memory	4 GB
RAM	4 GB
Cellular Technology	3G, 4G (Network compatibility varies by region and carrier)
Wireless Connectivity	Wi-Fi
Camera	Rear Camera
GPS	Yes
Dimensions (L x W x H)	7 x 3 x 2.5 inches
Item Weight	4.2 ounces (118 Grams)

Feature	Detail
Color	Black

Warranty and Support

This product is an international version and is explicitly stated to come with**No Warranty**. Please refer to the seller's return policy for any issues upon receipt.
For technical support or further inquiries, please contact the retailer or refer to the official Nokia support website for general information on KaiOS devices, if applicable.

© 2024 Nokia. All rights reserved. Nokia and the Nokia Logo are trademarks of Nokia Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question