Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Naxa NDS-1233

Naxa NDS-1233 Portable Party System User Manual

Model: NDS-1233

Introduction

Thank you for purchasing the Naxa NDS-1233 Portable Party System. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.
The NDS-1233 is a versatile 12-inch Bluetooth portable party system designed to deliver powerful audio with dynamic disco lighting. It features wireless Bluetooth streaming, True Wireless Stereo (TWS) connectivity for pairing two speakers, USB and TF card playback, AUX input, and a wired microphone for karaoke or announcements.

What's in the Box

Carefully unpack your Naxa NDS-1233 Portable Party System and ensure all items are present:

- Naxa NDS-1233 Portable Party Speaker
- Wired Microphone
- Remote Control
- Power Adapter/Charging Cable
- User Manual (this document)



Image: The NDS-1233 speaker shown with its accessories, including the wired microphone and remote control, highlighting the complete package contents.

Product Overview

Familiarize yourself with the various parts and controls of your NDS-1233 speaker:



Image: Detailed front view of the NDS-1233 speaker, with numbers indicating specific controls and ports on the top panel for easy identification.

1. LED Light On/Off Switch
2. Power On/Off Switch
3. Echo / Mic Volume / Volume Adjust
4. USB / Card Input Slots
5. Mode: Mode Selection (Bluetooth, USB, TF, AUX, FM)
6. REC: Recording Function
7. REPE: Repeat Playback
8. PREV: Previous Track
9. SCAN / PAUSE: TWS On/Off Switch (Press & Hold) / Play/Pause
10. NEXT: Next Track
11. MIC PRI: Microphone Priority Effect On/Off Button
12. Equalizer: Treble and Bass Adjust
13. AUX IN

14. MIC IN
15. Battery Charge Indicator Light
16. DC 9V IN: DC 9V Charging Input

Setup

Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power adapter to the DC 9V IN port (16) on the speaker and plug the other end into a standard wall outlet. The Battery Charge Indicator Light (15) will illuminate during charging and turn off when fully charged.

Initial Power On

Locate the Power On/Off Switch (2) on the control panel. Slide it to the "ON" position to power on the speaker. You will hear an audible prompt indicating the speaker is ready for operation.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on.
2. Press the Mode button (5) repeatedly until "BLUETOOTH" mode is selected. The LED display will show "BLUE" and you will hear a prompt indicating Bluetooth pairing mode.
3. Enable Bluetooth on your mobile device (smartphone, tablet, etc.).
4. Search for available Bluetooth devices and select "NAXA NDS-1233" from the list.
5. Once successfully paired, you will hear a confirmation sound. You can now stream audio wirelessly from your device to the speaker.

True Wireless Stereo (TWS) Function

The TWS function allows you to connect two NDS-1233 speakers wirelessly for a stereo sound experience.

1. Ensure both NDS-1233 speakers are powered on and in Bluetooth mode.
2. On one of the speakers (this will be the primary speaker), press and hold the SCAN / PAUSE button (9) for a few seconds until you hear a confirmation sound, indicating TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, you will hear another confirmation sound.
4. Now, connect your mobile device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section. Audio will play through both speakers in stereo.



Image: The NDS-1233 speaker with an overlay indicating its True Wireless Stereo (TWS) capability, allowing two speakers to connect wirelessly for enhanced sound.

USB / TF Card Playback

Insert a USB flash drive or TF (microSD) card into the respective input slot (4). The speaker will automatically switch to USB/TF mode and begin playing compatible audio files (e.g., MP3) from the storage device.

- Use the PREV (8) and NEXT (10) buttons to navigate between tracks.
- Press the SCAN / PAUSE button (9) to play or pause playback.
- Press the REPE (7) button to repeat the current track or all tracks.

AUX Input

Connect an external audio device (e.g., MP3 player, laptop) to the AUX IN port (13) using a 3.5mm audio cable (not included). Press the Mode button (5) to select "AUX" mode. Audio from the connected device will play through the speaker.

Microphone Usage

Connect the included wired microphone to the MIC IN port (14). Adjust the microphone volume using the Echo / Mic Volume / Volume Adjust knob (3). The MIC PRI (Microphone Priority) button (11) can be pressed to lower the music volume automatically when speaking into the microphone, prioritizing your voice.

Disco Light Control

Slide the LED Light On/Off Switch (1) to turn the integrated disco lights on or off. The lights will pulse and change colors with the music.

Equalizer Adjustment

Use the Equalizer (Treble and Bass Adjust) controls (12) to fine-tune the audio output to your preference. Rotate the knobs to increase or decrease treble and bass frequencies.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use, to maintain battery health.
- **Handling:** Handle the speaker with care. Avoid dropping it or subjecting it to strong impacts.

Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is depleted; Power switch is off.	Charge the speaker; Ensure the Power On/Off Switch is in the "ON" position.
No sound	Volume is too low; Incorrect mode selected; Device not connected properly.	Increase the volume; Press the Mode button to select the correct input; Reconnect Bluetooth device or AUX cable.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in Bluetooth pairing mode; Move device closer to speaker (within 33 feet); Turn off other Bluetooth devices.
Microphone not working	Microphone not fully plugged in; Microphone volume too low.	Ensure microphone is securely plugged into MIC IN port; Increase Mic Volume using the knob.
TWS connection issues	Speakers too far apart; One speaker not in TWS pairing mode.	Ensure speakers are within range of each other; Re-initiate TWS pairing on the primary speaker.

Specifications

- **Model:** NDS-1233
- **Brand:** Naxa

- **Speaker Size:** 12-inch
- **Connectivity:** Bluetooth, USB, TF Card, AUX, Wired Microphone
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Dimensions (L x W x H):** 12.8 x 13 x 21.3 inches
- **Weight:** 17.69 pounds
- **Features:** True Wireless Stereo (TWS), Disco Light, LED Display, Microphone Priority, Equalizer
- **UPC:** 840005015650

Warranty and Support

Naxa Electronics, Inc. provides a limited warranty for this product. Please refer to the warranty card included with your purchase or visit the official Naxa website for detailed warranty information and terms and conditions.
For technical support, troubleshooting assistance, or inquiries about replacement parts, please contact Naxa customer service. Contact information can typically be found on the Naxa website or on the product packaging.
Manufacturer: Naxa Electronics, Inc.

© 2024 Naxa Electronics, Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084BXVL2M

More documents and user manuals: **https://manuals.plus/**