Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi EN200RAE

De'Longhi Nespresso Essenza Plus User Manual

Model: EN200RAE

Introduction

Welcome to the world of Nespresso with your new De'Longhi Essenza Plus coffee machine. This compact and stylish machine, combined with the Aeroccino3 frother, allows you to create a variety of coffee and milk-based beverages with ease. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your appliance.

Please read this manual thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Setup and First Use

1. Unboxing and Placement

Carefully remove all packaging materials from the machine and the Aeroccino3 frother. Place the machine on a stable, flat, heat-resistant surface, away from water splashes and heat sources. Ensure adequate space around the machine for ventilation and access to the water tank and capsule container.



Image: The De'Longhi Nespresso Essenza Plus coffee machine in red, shown alongside the Aeroccino3 milk frother and a prepared coffee beverage. This illustrates the complete setup of the product.

2. Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill the water tank with fresh, potable water up to the MAX level indicator.
3. Place the water tank back onto the machine, ensuring it is securely seated.

3. First Use and Rinsing

Before preparing your first coffee, it is recommended to rinse the machine to clean the internal components and preheat

the system.

1. Ensure the water tank is filled.
2. Place a container (at least 0.5L) under the coffee outlet.
3. Press any coffee button (e.g., Lungo button) to start the rinsing cycle. The machine will dispense hot water.
4. Repeat this process 2-3 times until clear water flows out.
5. The machine is now ready for use.

4. Aeroccino3 Setup

The Aeroccino3 frother is designed for preparing hot or cold milk froth for various coffee recipes.

1. Ensure the Aeroccino3 is clean and dry.
2. Place the whisk inside the frother. Use the spring whisk for latte/cappuccino froth, or the plain whisk for hot milk.
3. Plug the Aeroccino3 into a power outlet.

Operating Instructions

1. Coffee Preparation (Essenza Plus Machine)

The Essenza Plus offers 4 programmable coffee recipes: Espresso, Lungo, Americano, and Hot Water.

1. **Power On:** Press any coffee button to turn on the machine. It will heat up in approximately 30 seconds. The buttons will stop blinking when ready.
2. **Insert Capsule:** Lift the lever completely and insert a Nespresso capsule. Close the lever.
3. **Place Cup:** Place a cup under the coffee outlet.
4. **Select Beverage:**
    - Press the **Espresso** button for a 40 ml shot.
    - Press the **Lungo** button for a 110 ml shot.
    - Press the **Americano** button for a 25 ml coffee shot followed by 125 ml hot water.
    - Press the **Hot Water** button for 200 ml of hot water (without a capsule).
5. **Stop Flow:** To stop the coffee flow at any time, press the illuminated button again.
6. **Eject Capsule:** After brewing, lift the lever to eject the used capsule into the container.





Image: The De'Longhi Nespresso Essenza Plus coffee machine in red, with various Nespresso capsules and a Nespresso capsule box. This image highlights the machine's compact design and its compatibility with Nespresso capsules.

2. One-Touch Capsule Reordering

The Essenza Plus features a convenient One-Touch Order button to easily reorder your Nespresso capsules.

- Ensure your machine is connected to the Nespresso app (refer to the Nespresso app instructions for setup).

- Press the **One-Touch Order** button on the machine.
- Your pre-selected capsules will be reordered through the Nespresso app.

3. Aeroccino3 Operation

Use the Aeroccino3 to prepare hot or cold milk froth.

1. **Fill Milk:** Pour fresh, cold milk into the Aeroccino3. Do not exceed the MAX froth level indicator for frothed milk, or the MAX hot milk level indicator for hot milk.
2. **Select Whisk:** Use the whisk with the spring for frothed milk (latte/cappuccino). Use the whisk without the spring for hot milk (no froth).
3. **Start Frothing:**
    - For **hot milk froth** or **hot milk**: Press the button once. The button will illuminate red.
    - For **cold milk froth**: Press and hold the button for approximately 2 seconds. The button will illuminate blue.
4. **Completion:** The Aeroccino3 will automatically stop when the preparation is complete.

Maintenance and Cleaning

1. Daily Cleaning of the Machine

- **Drip Tray and Capsule Container:** Empty and rinse the drip tray and used capsule container daily. Wash them with warm water and a mild detergent.
- **Water Tank:** Rinse the water tank with fresh water daily.
- **Machine Exterior:** Wipe the machine's exterior with a damp cloth. Do not use abrasive cleaning agents or immerse the machine in water.

2. Descaling

Descaling is crucial for maintaining the machine's performance and coffee quality. The Essenza Plus features an automatic descaling alert.

- When the descaling alert illuminates, it's time to descale your machine.
- Use only the Nespresso descaling kit. Follow the instructions provided with the descaling kit carefully.
- The descaling process typically involves filling the water tank with the descaling solution and running several cycles through the machine.
- After descaling, rinse the machine thoroughly with fresh water.

3. Cleaning the Aeroccino3

- Unplug the Aeroccino3 from the power outlet.
- Remove the whisk.
- Rinse the inside of the jug and the whisk immediately after each use with warm water.
- Do not immerse the base of the Aeroccino3 in water. The jug is not dishwasher safe.
- Wipe the exterior with a damp cloth.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No coffee flow, or very little coffee.	Water tank empty; machine needs descaling; capsule blocked.	Fill water tank; perform descaling procedure; open and close lever to eject capsule, then try again with a new capsule.
Coffee is not hot enough.	Cups not preheated; machine needs descaling.	Preheat cups with hot water (using the hot water function); descale the machine.
Milk froth is not consistent or sufficient.	Incorrect milk type/temperature; Aeroccino3 not clean; incorrect whisk.	Use fresh, cold, semi-skimmed milk; clean Aeroccino3 thoroughly; ensure correct whisk is used (spring whisk for froth).
Machine leaks.	Water tank not correctly positioned; drip tray full.	Ensure water tank is securely in place; empty and clean drip tray.
Machine does not turn on.	No power supply.	Check power cord connection and wall outlet.

If the problem persists after attempting these solutions, please contact Nespresso or De'Longhi customer support.

Specifications

Brand:	De'Longhi
Model Number:	EN200RAE
Color:	Cherry Red
Coffee Maker Type:	Espresso Machine
Special Feature:	Milk Frother (Aeroccino3 Included)
Operation Mode:	Fully Automatic
Pump Pressure:	19 Bar
Heat-up Time:	Approximately 30 seconds
Coffee Recipes:	Espresso, Lungo, Americano, Hot Water
Human Interface Input:	Buttons
UPC:	044387200257

Warranty and Support

Your De'Longhi Nespresso Essenza Plus machine is covered by a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical assistance, troubleshooting beyond this manual, or to inquire about warranty service, please contact

De'Longhi or Nespresso customer support. Contact information can typically be found on the official brand websites or on the product packaging.

Online Resources:

- Nespresso Official Website
- De'Longhi Official Website

© 2024 De'Longhi. All rights reserved. Nespresso is a registered trademark of Nestlé S.A.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084GZZWC1

More documents and user manuals: **https://manuals.plus/**