arendo 847416384

Arendo Elegant Kettle User Manual

Model: 847416384

1. Introduction

Thank you for choosing the Arendo Elegant Kettle. This manual provides important information regarding the safe operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.
The Arendo Elegant Kettle is designed for superior user comfort and features. It is particularly appealing to users who value a high-quality product.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or kettle in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The kettle features a double-wall design, ensuring the exterior remains cool to the touch during operation, enhancing safety.
- Equipped with dry-boil protection and overheat protection.
- This product has been extensively tested and certified with the globally recognized GS safety mark.



Figure 2.1: Safety Features of the Arendo Elegant Kettle. This image highlights key safety aspects such as overheat protection, double-wall design, Strix controller, safety lid, and dry-boil protection, along with the SGS GS safety certification.

3. Product Overview

3.1 Components

- Kettle body (1.5L capacity)
- Lid
- Handle with control panel
- Power base with cable storage
- Internal stainless steel body (Food Grade SUS/SAE304)
- Hidden heating element



Figure 3.1: Arendo Elegant Kettle with its digital control panel. The main image shows the sleek black kettle, while an inset highlights the control panel with temperature display and buttons for adjustment, setting, keep warm, and start.

3.2 Features

- **Temperature Control:** Adjustable in 5°C increments from 40°C to 100°C. Quick access buttons for 40°C, 60°C, 80°C, and 100°C.
- **Keep Warm Function:** Maintains the set temperature for over 30 minutes.
- **Double-Wall Design:** The outer casing remains cool to the touch, providing protection against scalding and better heat insulation.
- **BPA-Free:** The kettle is free from plasticizers (BPA-free) and does not release microplastic particles, ensuring maximum health tolerance.
- **Food-Grade Stainless Steel:** The inner body is made of food-grade SUS/SAE304 stainless steel.
- **Easy Cleaning:** Flat bottom design for easy cleaning of the reservoir.

- **LED Display:** White LED display shows temperature during boiling.
- **Buzzer:** Deactivatable buzzer for quiet operation.



Figure 3.2: Interior of the Arendo Elegant Kettle. This image shows the clean, food-grade SUS 304 stainless steel interior with a "MAX 1.5L" fill line. A "BPA FREE" and "NON-TOXIC PLASTIC" label is prominently displayed, emphasizing the health-conscious design.



Figure 3.3: Double-Wall Design. This diagram illustrates the kettle's double-wall construction, with an outer plastic layer and an inner stainless steel layer, providing protection against scalding and improved thermal insulation.

4. Setup

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, fill the kettle with fresh water up to the MAX line and boil it. Discard the water. Repeat this process 2-3 times to remove any manufacturing residues.
3. **Placement:** Place the power base on a stable, flat, heat-resistant surface, away from the edge of the countertop. Ensure the power cord is not dangling where it can be pulled or tripped over.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet (220-240V, 50/60Hz).

5. Operating Instructions

5.1 Filling the Kettle

Open the lid and fill the kettle with the desired amount of fresh water. Do not fill below the MIN mark or above the MAX (1.5L) mark. The internal level indicator helps with easy filling.

5.2 Setting Temperature and Boiling

1. Place the kettle securely on its power base. The LED display will show the current water temperature.
2. Use the **+** and **-** buttons to adjust the desired temperature in 5°C increments (from 40°C to 100°C).
3. Alternatively, press the **SET** button for quick access to preset temperatures: 40°C (ideal for baby food), 60°C (e.g., white tea), 80°C (e.g., instant coffee), and 100°C (e.g., black tea).
4. Press the **START** button to begin the heating process. The LED display will show the rising temperature.
5. The kettle will automatically switch off once the set temperature is reached. A buzzer will sound (if not deactivated).



Figure 5.1: Temperature Control Panel. This image provides a detailed view of the kettle's control panel, showing the digital temperature display, plus/minus buttons for fine adjustment, a SET button for quick access to common temperatures (40°C, 60°C, 80°C, 100°C), a KEEP WARM button, and a START button. It also indicates the power consumption of 1850-2200W.

5.3 Keep Warm Function

After reaching the desired temperature, press the**KEEP WARM** button. The kettle will maintain the set temperature for up to 30 minutes. This allows you to enjoy your beverage at your leisure.

5.4 Deactivating the Buzzer

The kettle features a deactivatable buzzer. Refer to the specific instructions in the full manual for how to turn off the sound, useful for quiet environments (e.g., not waking a baby).

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your kettle.

1. **Before Cleaning:** Always unplug the kettle from the power outlet and allow it to cool completely.
2. **Exterior Cleaning:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the finish.
3. **Interior Cleaning (Descaling):** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.
    - Fill the kettle with a mixture of water and white vinegar (1:1 ratio) or a commercial descaling solution.
    - Boil the mixture and let it stand for at least 30 minutes, or longer for heavy deposits.
    - Empty the kettle and rinse thoroughly with fresh water several times to remove any residue and odor.
    - The flat bottom design of the reservoir facilitates easy cleaning.
4. **Storage:** When not in use, store the kettle in a dry place. The power base has convenient cable storage.

7. Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in; power outage; kettle not properly seated on base; dry-boil protection activated.	Check power connection; ensure kettle is correctly placed on base; allow kettle to cool if dry-boil protection was activated.
Water has an unusual taste or odor.	New appliance odor; limescale buildup.	Perform initial cleaning (boil and discard water several times); descale the kettle.
Kettle switches off before boiling.	Limescale buildup; faulty temperature sensor.	Descale the kettle. If problem persists, contact customer support.
Buzzer sound is annoying.	Buzzer is active.	Refer to the full manual for instructions on deactivating the buzzer.

8. Specifications

- **Model:** Arendo Elegant Kettle
- **Model Number:** 847416384
- **Capacity:** Max. 1.5 Liters
- **Power Supply:** 220-240 V, 50/60 Hz

- **Power Consumption:** 1850 - 2200 W
- **Standby Power:** <= 0.46 W
- **Material:** Stainless Steel (inner), Double-wall design (outer plastic)
- **Dimensions (H x W x D):** 24.5 cm x 22 cm (with handle) x 15.2 cm (diameter)
- **Power Cord Length:** Approx. 70 cm
- **Weight:** Kettle 1200g + Base 213g
- **Color:** Black

9. Warranty and Support

Arendo products are built to high-quality standards. For any questions, technical support, or warranty claims, please contact Arendo customer service. Please have your model number (847416384) and purchase details ready.
For more information, visit the official Arendo website:www.arendo.de

© 2024 Arendo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question