Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kobalt 80-Volt Max 630-CFM Brushless Cordless Electric Leaf Blower

Kobalt 80-Volt Max 630-CFM Brushless Cordless Electric Leaf Blower User Manual

Model: 80-Volt Max 630-CFM Brushless Cordless Electric Leaf Blower

Introduction

This manual provides essential information for the safe operation, maintenance, and troubleshooting of your Kobalt 80-Volt Max 630-CFM Brushless Cordless Electric Leaf Blower. Please read and understand all instructions before using the product to ensure safe and efficient operation.

Important Safety Instructions

Always follow basic safety precautions when using electric appliances to reduce the risk of fire, electric shock, and personal injury.

- **Read All Instructions:** Familiarize yourself with the controls and proper use of the blower.
- **Wear Eye Protection:** Always wear safety glasses or goggles with side shields that comply with ANSI Z87.1.
- **Wear Hearing Protection:** Use earplugs or earmuffs during operation.
- **Wear Appropriate Clothing:** Do not wear loose clothing or jewelry that could get caught in moving parts. Wear long pants, heavy shoes, and gloves.
- **Keep Area Clear:** Ensure bystanders, children, and pets are at a safe distance (at least 50 feet/15 meters) from the operating area.
- **Inspect Before Use:** Check for loose parts, damaged components, or any condition that may affect safe operation.
- **Do Not Operate in Wet Conditions:** Avoid using the blower in rain or wet environments.
- **Use Only Kobalt 80V Batteries and Chargers:** Using other batteries or chargers may cause injury or damage.
- **Remove Battery When Not in Use:** Always remove the battery pack when assembling, adjusting, cleaning, or storing the blower.
- **Maintain Good Balance:** Keep proper footing and balance at all times. Do not overreach.
- **Never Point Nozzle at People or Animals:** The powerful air stream can cause injury.
- **Store Safely:** Store the blower indoors in a dry, secure place out of reach of children.

Product Overview

The Kobalt 80-Volt Max Brushless Cordless Electric Leaf Blower is designed for efficient clearing of leaves and debris. It

features a powerful brushless motor and variable speed control.

Components Included:

- Kobalt 80-Volt Max Leaf Blower Unit
- 2.5 Ah 80-Volt Max Lithium-Ion Battery
- 80-Volt Max Battery Charger
- Blower Nozzle

Key Features:

- **80-Volt Max Power:** Provides strong performance for demanding tasks.
- **630 CFM / 140 MPH:** High air volume and speed for effective debris clearing.
- **Brushless Motor:** Delivers increased power, efficiency, and extended motor life.
- **Variable Speed Trigger:** Allows precise control over airflow.
- **3-Speed Selection:** Offers different power levels for various applications.
- **Cruise Control:** Maintains desired speed without holding the trigger.
- **Lightweight Design:** Weighs approximately 8.9 lbs (without battery) for comfortable use.



Figure 1: The Kobalt 80-Volt Max Leaf Blower shown with its included 80V battery and charger.



Figure 2: Side view of the Kobalt 80-Volt Max Leaf Blower, highlighting the motor housing and battery compartment.

Setup

1. Charging the Battery

1. Connect the charger to a standard 120V AC outlet. The charger indicator light will illuminate.
2. Slide the 80-Volt battery pack onto the charger until it clicks into place.
3. The charger indicator light will show the charging status. Refer to the charger's specific instructions for light patterns (e.g., solid red for charging, solid green for fully charged).
4. Once fully charged, remove the battery from the charger.

Note: It is recommended to fully charge the battery before first use. Do not store the battery on the charger for extended periods.

2. Attaching the Blower Nozzle

1. Ensure the battery pack is removed from the blower.
2. Align the blower nozzle with the air outlet of the blower unit.
3. Push the nozzle firmly onto the blower until it locks securely into place. Some models may require a twist to lock.
4. Verify the nozzle is securely attached before proceeding.



Figure 3: The blower unit with the nozzle attached, ready for battery insertion.

3. Installing the Battery Pack

1. Align the ribs on the battery pack with the grooves in the blower's battery port.
2. Slide the battery pack into the blower until it clicks securely into place.
3. Ensure the battery is fully seated before operating the blower.

Operating Instructions

Starting and Stopping the Blower

- **To Start:** With the battery installed, press and hold the trigger switch. The blower will start.
- **To Stop:** Release the trigger switch.

Speed Control

Your blower features a variable speed trigger, a 3-speed selection switch, and a cruise control lever for precise airflow management.

- **Variable Speed Trigger:** The further the trigger is pressed, the higher the air speed. This allows for fine-tuning of blowing power.
- **3-Speed Selection Switch:** Located near the handle, this switch allows you to select between Low, Medium, and High power modes.
    - **Low:** For light debris or delicate areas.
    - **Medium:** For general clearing tasks.
    - **High (Turbo):** For heavy, wet leaves or stubborn debris, providing maximum CFM and MPH.
- **Cruise Control Lever:** Once the desired speed is reached using the variable speed trigger, push the cruise control lever forward to lock the speed. This allows continuous operation without holding the trigger. To disengage, pull the cruise control lever back or release the trigger.



Figure 4: Detailed view of the blower's handle, showing the variable speed trigger and the 3-speed selection switch.



Figure 5: Close-up of the cruise control lever on the Kobalt 80-Volt Max Leaf Blower, used to maintain a constant blowing speed.

Blowing Techniques

- Start blowing debris from the outer edges of the area and work towards the center.
- Use a sweeping motion from side to side to gather debris effectively.
- For heavy or wet debris, use the High (Turbo) speed setting and make shorter, more powerful sweeps.
- Avoid blowing debris towards people, animals, or open windows.
- Be mindful of dust and small particles; consider wearing a dust mask in very dusty conditions.

Maintenance

Regular maintenance ensures optimal performance and extends the life of your blower. Always remove the battery pack before performing any maintenance.

Cleaning the Blower

- Wipe the exterior of the blower with a clean, damp cloth. Do not use strong detergents or solvents.
- Keep the air vents free from debris to prevent overheating. Use a soft brush or compressed air to clear vents.
- Inspect the blower nozzle for any blockages and clear them if necessary.

Battery Care and Storage

- Store the battery pack in a cool, dry place, away from direct sunlight and extreme temperatures.
- For long-term storage, charge the battery to approximately 50% capacity.
- Do not store the battery pack fully discharged or fully charged for extended periods.
- Keep battery terminals clean and free of debris.

General Inspection

- Periodically check all fasteners for tightness.
- Inspect the power cord of the charger for damage. If damaged, have it replaced by a qualified technician.
- Ensure all safety labels are intact and legible.

Troubleshooting

This section addresses common issues you might encounter. If you experience problems not listed here, contact customer support.

Problem	Possible Cause	Solution
Blower does not start.	Battery not installed correctly.	Ensure battery is fully seated and clicks into place.
	Battery is discharged.	Charge the battery fully.
	Battery or blower is too hot/cold.	Allow battery/blower to reach ambient temperature.
Reduced airflow.	Nozzle or air intake blocked.	Remove battery, then clear any debris from the nozzle or air intake vents.
	Battery charge is low.	Recharge the battery.
Blower stops during operation.	Battery is depleted.	Replace with a charged battery or recharge the current one.
	Overheating protection activated.	Allow the blower and battery to cool down for several minutes. Ensure air vents are clear.

Specifications

Feature	Detail
Brand	Kobalt
Model	80-Volt Max 630-CFM Brushless Cordless Electric Leaf Blower
Power Source	Battery Powered
Voltage	80 Volts

Feature	Detail
Motor Type	Brushless
Air Flow Capacity	630 Cubic Feet Per Minute (CFM)
Air Speed	Up to 140 Miles per Hour (MPH)
Noise Level	74 Decibels
Item Weight	13.87 pounds (with battery)
Included Components	Blower, 2.5 Ah Battery, Charger
ASIN	B084HK9JKX
UPC	370801870264

Warranty and Support

For specific warranty information, please refer to the warranty card included with your product or visit the official Kobalt website. Keep your purchase receipt as proof of purchase.

If you require technical assistance, replacement parts, or have questions regarding the operation of your Kobalt 80-Volt Max Leaf Blower, please contact Kobalt Customer Support. Contact details can typically be found on the product packaging or the official Kobalt website.

Online Resources: For additional information, FAQs, and product registration, visit the official Kobalt Tools website.

© 2023 Kobalt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084HK9JKX

More documents and user manuals: **https://manuals.plus/**