NKF BN59-01223A

Instruction Manual for NKF BN59-01223A Replacement Samsung Remote Control

Model: BN59-01223A

1. Product Overview

The NKF BN59-01223A is a direct replacement remote control designed for various Samsung Smart TV models. It offers seamless control without the need for complex programming or pairing. This remote is built with durable ABS materials for long-lasting use.



Image: Front and back view of the BN59-01223A remote control, showcasing its ergonomic design.

Button Layout and Functions

Familiarize yourself with the remote's button layout to effectively navigate your television. Key functions include power, volume, channel control, and navigation buttons.



Image: A clear diagram illustrating the function of each button on the BN59-01223A remote control.

- **TV Power:** Turns the television on or off.
- **Number Keys (0-9):** Directly select channels or input numerical data.
- **Mute:** Silences the television audio.
- **Volume Keys (+/-):** Adjust the audio volume up or down.
- **Channel Keys (CH +/-):** Change channels up or down.
- **Menu:** Access the TV's main menu.
- **Tools:** Provides quick access to various TV settings and options.
- **Info:** Displays information about the current program or input.
- **Back:** Returns to the previous screen or menu.

- **Exit:** Exits the current menu or application.
- **Rewind/Fast Forward:** Control media playback.

2. Setup

The BN59-01223A remote control is designed for immediate use with compatible Samsung TVs. No programming or pairing is required. Simply install the batteries to begin operation.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open the compartment.
3. Insert two (2) new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Illustration of the battery compartment and correct battery orientation for the BN59-01223A remote.

Note: Batteries are not included with the remote control.

3. Operating Instructions

Once batteries are installed, the remote is ready for use. Point the remote directly at your Samsung TV and press the desired buttons.

Basic Operation

- **Power On/Off:** Press the **Power** button (red circle with line) to turn your TV on or off.
- **Volume Control:** Use the **VOL +** and **VOL -** buttons to increase or decrease the volume.
- **Channel Navigation:** Use the **CH ^** and **CH v** buttons to change channels.
- **Smart Hub/Menu Access:** Press the **Menu** button to access your TV's smart features or settings.
- **Navigation:** Use the directional pad (up, down, left, right arrows) and the **Enter** button (center of directional pad) to navigate menus and select options.



Image: The remote control being used to interact with a Samsung Smart TV's interface.

Optimal Remote Distance

The remote control operates effectively up to a distance of 10 meters (33 feet). Actual remote distance may vary depending on your TV model and environmental factors.



Image: Visual representation of the remote's operational range.

Product Video Demonstration

Watch this official product video for a visual guide on the remote's features and basic operation, including battery installation and button usage.

Your browser does not support the video tag.

Video: A demonstration of the BN59-01223A remote control, highlighting its design, button functions, and battery installation process.

4. Compatibility

The NKF BN59-01223A remote control is specifically designed to be compatible with a wide range of Samsung Smart TV models. This remote serves as a direct replacement for your original or lost remote.

Compatible Samsung TV Models (Partial List):

- UN32J5500, UN32J5500AF, UN32J5500AFXZA
- UN32J6300, UN32J6300AF, UN32J6300AFXZA
- UN40J5500, UN40J5500AF, UN40J5500AFXZA
- UN40J6300, UN40J6300AF, UN40J6300AFXZA
- UN40JU650, UN40JU6500, UN40JU6500F, UN40JU6500FXZA, UN40JU650DFXZA, UN40JU650DF
- UN48J5500AF, UN48J5500FXZA, UN48J550DAF, UN48J6300AF, UN48JU6500FX, UN48JU650DFX
- UN50J5500AF, UN50J550DAF, UN50J6300AF, UN50JS7000F, UN50JU6500F, UN50JU650DF, UN50JU650DFX, UN50JU650DFXZA
- UN55J6300AF, UN55JS700DF, UN55JU6500F, UN55JU6500FX, UN55JU650DF, UN55JU650DFX
- UN60JS700DF, UN60JS700DFXZA, UN60JU6500F, UN60JU6500FX, UN60JU650DFX, UN60JU7090F, UN60JU7090FXZA
- UN65J6300AF, UN65J630DAF, UN65JU6500FX, UN65JU650DF, UN65JU650DFX, UN65JU650DFXZA
- UN75J6300AF, UN75J630DAF, UN75JU641DF, UN75JU6500FX, UN75JU650DF, UN75JU650DFX

This list is not exhaustive. If your original remote was BN59-01223A, this replacement should be compatible.



Image: Visual representation of the remote's compatibility with various Samsung TV models.

5. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials.
- **Battery Care:** If the remote will not be used for an extended period, remove the batteries to prevent leakage, which can damage the remote.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** While durable, repeated drops can damage internal components. Handle the remote with care.

6. Troubleshooting

If you encounter issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new 1.5V AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Point the remote directly at the TV.
- **Buttons Not Working:**
  - Clean the remote's surface, especially around the buttons, to remove any dirt or debris that might be obstructing them.
  - If only specific buttons are not working, it might indicate internal damage.
- **Intermittent Operation:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure you are within the effective operating range (up to 10 meters / 33 feet).

If these steps do not resolve the issue, please refer to the support section for further assistance.

7. Specifications

Feature	Detail
Model Number	BN59-01223A
Brand	NKF
Product Dimensions	9.02 x 1.88 x 0.91 inches
Item Weight	2.89 ounces
Batteries Required	2 x AAA batteries (not included)
Color	Black
Special Feature	No Programming Required
Compatible Devices	Television (Samsung Smart TVs)
Max Number of Supported Devices	1
Country of Origin	China
Date First Available	February 3, 2020



Image: Detailed dimensions of the remote control.

8. Warranty Information

This product comes with a standard manufacturer's warranty. Please retain your proof of purchase for any warranty claims. For specific warranty terms and conditions, refer to the product packaging or contact the manufacturer directly.

9. Support

For further assistance, technical support, or inquiries regarding the NKF BN59-01223A remote control, please contact the manufacturer or seller through the platform where the product was purchased.
You may also visit the NKF Store on Amazon for additional product information and support resources.

© 2024 NKF. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question