Skil HT4221-10

SKIL PWR CORE 40 Brushless 40V 24” Cordless Hedge Trimmer Kit User Manual

Model: HT4221-10

Product Overview

The SKIL PWR CORE 40 Brushless 40V 24” Cordless Hedge Trimmer Kit (Model HT4221-10) offers powerful, cordless performance for efficient hedge trimming. This kit includes the hedge trimmer, a 2.5Ah PWR CORE 40™ lithium battery, and an Auto PWR JUMP™ charger. Designed for durability and ease of use, it features a digital brushless motor and dual-action blades for clean cuts.



Figure 1: SKIL PWR CORE 40 Brushless 40V 24 inch Cordless Hedge Trimmer Kit, showing the trimmer, 2.5Ah battery, and Auto PWR JUMP charger.

Safety Information

Always read and understand all safety warnings, instructions, illustrations, and specifications provided with this power tool. Failure to follow all instructions listed below may result in electric shock, fire, and/or serious injury.

- Wear appropriate personal protective equipment, including eye protection, gloves, and sturdy footwear.
- Ensure the work area is clear of debris, obstacles, and bystanders.
- Do not operate the hedge trimmer in wet conditions or near flammable liquids or gases.
- Keep hands and feet away from the cutting blades.
- Disconnect the battery pack before performing any adjustments, changing accessories, or storing the tool.
- Use only SKIL PWR CORE 40™ batteries and chargers with this tool.

Setup

1. Battery Charging

Before first use, fully charge the 2.5Ah PWR CORE 40™ lithium battery using the Auto PWR JUMP™ charger. The charger is designed to charge the battery from 0-30% in approximately 15 minutes.

1. Connect the charger to a standard electrical outlet.
2. Slide the battery pack onto the charger until it clicks into place.
3. The charger's indicator light will show the charging status. Refer to the charger's specific instructions for detailed light patterns.
4. Once fully charged, remove the battery from the charger.



Figure 2: The SKIL PWR CORE 40 battery being charged on the Auto PWR JUMP charger, illustrating the 15-minute charging capability.

2. Attaching the Battery

Ensure the hedge trimmer is turned off and the blades are stationary before attaching the battery.

1. Align the battery pack with the battery port on the hedge trimmer.
2. Slide the battery pack firmly into the port until it clicks securely into place.
3. To remove the battery, press the release button(s) on the battery pack and slide it out.

Operating Instructions

1. Pre-Operation Check

- Inspect the hedge trimmer for any damage or loose parts.
- Ensure the blades are clean and free of debris.
- Verify that the battery is securely attached and fully charged.

2. Starting the Hedge Trimmer

The SKIL PWR CORE 40 Hedge Trimmer features a dual-action blade system for efficient cutting.

1. Grip the front handle and the rear handle firmly.
2. Press the safety lock-off button (if applicable) and then squeeze the trigger switch to start the motor.
3. Release the safety lock-off button once the motor is running.



Figure 3: A user demonstrating the operation of the SKIL PWR CORE 40 Hedge Trimmer for trimming hedges.

3. Trimming Techniques

The 24-inch dual-action blade is designed for clean and efficient cuts, with a 3/4-inch cut capacity.

- Maintain a firm grip on both handles during operation.
- Move the trimmer smoothly and evenly along the hedge.
- For optimal results, cut small amounts of material at a time.
- Avoid forcing the blades through thick branches; the maximum cutting capacity is 3/4 inch.




Figure 4: A close-up view of the hedge trimmer's dual-action blade, highlighting its 3/4-inch cutting capacity.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your hedge trimmer.

1. Blade Care

- After each use, disconnect the battery and clean the blades of sap and debris using a stiff brush or cloth.
- Apply a light coat of machine oil or blade lubricant to the blades to prevent rust and ensure smooth operation.
- Periodically check the blades for sharpness. Dull blades can tear foliage and strain the motor. Sharpen or replace blades as needed by a qualified service technician.

2. General Cleaning and Storage

- Wipe down the exterior of the tool with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Store the hedge trimmer in a dry, secure location, out of reach of children and away from direct sunlight or extreme temperatures.

- Ensure the battery is removed from the tool before storage. Store the battery in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not start.	Battery not charged or not properly inserted.	Ensure battery is fully charged and securely clicked into place.
Trimmer stops during operation.	Overload protection activated; battery low.	Release trigger, allow motor to cool, recharge or replace battery.
Blades are not cutting effectively.	Dull blades; debris caught in blades.	Clean blades; lubricate blades; have blades sharpened or replaced.
Excessive vibration.	Loose components; damaged blade.	Check for loose screws; inspect blade for damage and replace if necessary.

Specifications

Brand: Skil

Model Number: HT4221-10

Power Source: Battery Powered (SKIL PWR CORE 40™ Lithium)

Blade Length: 24 Inches

Cutting Capacity: 3/4 Inch

Blade Type: Dual Action, Hardened Alloy Steel

Motor Type: Digital Brushless Motor

Product Dimensions (L x W x H): 41.97" x 9.06" x 8.35"

Item Weight: Approximately 9.9 - 9.92 Pounds

Included: 2.5Ah Battery and Auto PWR JUMP Charger

Warranty and Support

For detailed warranty information and customer support, please refer to the documentation included with your product packaging or visit the official Skil website. You can also contact Skil customer service for assistance with product registration, technical support, or replacement parts.

© 2025 Skil. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question