Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Villeroy & Boch NewMoon Collection Bread Plate 6.25in

Villeroy & Boch NewMoon Collection Bread Plate 6.25in User Manual

Model: NewMoon Collection Bread Plate 6.25in

Introduction

This manual provides essential information for the proper use and care of your Villeroy & Boch NewMoon Collection Bread Plate. The NewMoon collection, inspired by the moon's grace, features a distinctive, pared-down design with slightly asymmetrical, puristic shapes. Villeroy & Boch has been a symbol of high-quality porcelain since 1748. This bread plate is designed for modern tableware, offering both elegance and functionality.



Image: A single Villeroy & Boch NewMoon bread plate, showcasing its unique crescent-shaped rim and creamy white finish.

Setup

Before first use, wash the Villeroy & Boch NewMoon Bread Plate thoroughly with warm water and a mild dish soap. Rinse completely and dry with a soft cloth. This ensures the plate is clean and ready for serving.

Operating Instructions

The NewMoon Bread Plate is designed for serving individual portions of bread, rolls, appetizers, or small desserts. Its 6.25-inch diameter makes it suitable for various culinary presentations.

- **Serving Bread:** Place a single slice of bread, a roll, or a small pastry on the plate.
- **Appetizers:** Ideal for individual servings of small appetizers or amuse-bouches.
- **Desserts:** Can be used for small dessert portions.



Image: Two slices of bread served on a Villeroy & Boch NewMoon bread plate, demonstrating its practical use.

This plate is safe for use in both microwave ovens and dishwashers, offering convenience for heating and cleaning.

Maintenance and Care

To maintain the quality and appearance of your Villeroy & Boch NewMoon Bread Plate, follow these care instructions:

- **Dishwasher Safe:** The plate is designed for safe and convenient cleaning in a dishwasher. Use standard dishwasher detergents.
- **Microwave Safe:** The plate can be safely used in microwave ovens for reheating food.
- **Hand Washing:** If hand washing, use a soft sponge or cloth and mild dish soap. Avoid abrasive cleaners or scouring pads, which can scratch the porcelain surface.
- **Storage:** Store plates carefully to prevent chipping or scratching. Stacking with protective layers (e.g., felt pads) between plates is recommended if stacking multiple items.



Image: A dining table set with multiple Villeroy & Boch NewMoon plates and other dinnerware, illustrating the collection's aesthetic.

Troubleshooting

Villeroy & Boch porcelain is manufactured to high standards. However, if you encounter any issues, consider the following:

- **Chipping or Breakage:** Porcelain, while durable, can chip or break if subjected to sharp impacts or extreme temperature changes. Handle with care.
- **Stains:** Most food stains can be removed with regular washing. For stubborn stains, a non-abrasive porcelain cleaner or a paste of baking soda and water can be used, followed by thorough rinsing.
- **Scratches:** Avoid using metal utensils that can leave marks. If minor metal marks appear, they can often be removed with a specialized porcelain cleaner.

Specifications

Feature	Detail
Brand	Villeroy & Boch
Collection	NewMoon
Material	Premium Porcelain
Color	Creamy White
Diameter	6.25 inches (15.875 cm)
Height	0.75 inches (1.9 cm)
Weight	7.5 Ounces (214 g)
Dishwasher Safe	Yes
Microwave Safe	Yes
Origin	Made in Germany
Item Number	1042642660

Warranty Information

Villeroy & Boch products are crafted with a commitment to quality and durability. While specific warranty details for individual dinnerware items may vary, Villeroy & Boch stands behind the craftsmanship of its premium porcelain. For detailed warranty information or to inquire about specific product guarantees, please refer to the official Villeroy & Boch website or contact their customer service directly.

Support

For further assistance, product inquiries, or to explore the full range of Villeroy & Boch collections, please visit the official Villeroy & Boch website:

www.villeroy-boch.com

You may also find contact information for customer service on their website for region-specific support.

© 2026 Villeroy & Boch. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084QXG7ZL

More documents and user manuals: **https://manuals.plus/**