Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KOMOK Electric Pruning Shears (40mm)

KOMOK 40mm Electric Pruning Shears User Manual

Model: Electric Pruning Shears (40mm)

1. Product Overview

The KOMOK 40mm Electric Pruning Shears are designed for efficient and effortless pruning of trees and shrubs. This cordless tool features durable SK5 carbon steel blades, a powerful brushless motor, and long-lasting rechargeable lithium batteries.



Image 1.1: Overview of the KOMOK Electric Pruning Shears with key components labeled. This includes the movable blade, fixed blade, lubricant oil port, ergonomics non-slip handle, lanyard hole, switch, trigger, handguard, battery removal button, and 2Ah lithium battery.

2. Package Contents

Verify that all items are present in the package:

- 1 x Electric Pruning Shears
- 1 x Tool Case
- 1 x Work Gloves
- 1 x Charger
- 2 x Allen Wrenches
- 1 x Lubricant Oil Bottle
- 2 x Lithium Batteries (2Ah)
- 1 x User Manual



Image 2.1: The complete package contents, including the electric pruning shears, tool case, work gloves, charger, Allen wrenches, oil, two lithium batteries, and the user manual.

3. Setup

3.1 Battery Charging

Before first use, fully charge both lithium batteries. The charger is designed with two ports to charge both batteries simultaneously.

1. Insert the batteries into the charging ports on the charger.
2. Connect the charger to a power outlet.
3. The battery indicator lights will show the charging status. Charge until full.



Image 3.1: Two 2000mAh 21V lithium-ion batteries with battery indicators, ready for charging or use.

3.2 Attaching the Battery

To attach a charged battery to the pruning shears:

1. Align the battery with the battery slot at the base of the shears handle.
2. Slide the battery firmly into place until it clicks, indicating it is securely locked.

4. Operating Instructions

4.1 Powering On/Off

1. To power on, press and hold the power switch until the blades open and the indicator light illuminates.
2. To power off, press and hold the power switch until the blades close and the indicator light turns off.

4.2 Pruning

Always wear appropriate safety gear, including work gloves and eye protection, when operating the pruning shears.

1. Ensure the blades are clean and free of debris.
2. Position the branch to be cut between the open blades. Ensure the branch diameter does not exceed 40mm.
3. Press the trigger to close the blades and make the cut. Release the trigger to open the blades.
4. For optimal plant health, make clean cuts close to the main branch or bud.



Image 4.1: The electric pruning shears in action, demonstrating a clean cut on a tree branch.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the KOMOK electric pruners in use, showing how they facilitate easier pruning tasks.

Your browser does not support the video tag.

Video 4.2: This video illustrates the speed and efficiency of the KOMOK electric pruning shears when cutting branches.

5. Maintenance

5.1 Blade Care

Regular blade maintenance ensures optimal performance and longevity.

1. After each use, clean the blades with a dry cloth to remove sap and debris.
2. If necessary, use a mild cleaning solution to remove stubborn residue.
3. Periodically sharpen the blades using a suitable sharpening tool (not included) to maintain cutting efficiency.



Image 5.1: Detail of the SK5 high carbon steel blades with DLC coating, designed for sharpness and rust resistance.

5.2 Lubrication

Apply a few drops of lubricant oil to the blade pivot point and cutting surfaces regularly to ensure smooth operation and prevent rust.

5.3 Storage

Store the pruning shears in their original case in a dry, cool place, away from direct sunlight and out of reach of children. Ensure batteries are removed if storing for extended periods.

6. Troubleshooting

If you encounter issues with your KOMOK Electric Pruning Shears, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Shears do not power on.	Battery not charged or not properly inserted.	Ensure battery is fully charged and securely attached.
Blades do not cut cleanly.	Blades are dull or dirty.	Clean and sharpen the blades.
Shears stop during operation.	Overload protection activated or battery low.	Reduce cutting load or recharge battery.

7. Specifications

- **Brand:** KOMOK
- **Model:** Electric Pruning Shears
- **Cutting Diameter:** Up to 40 mm
- **Blade Material:** SK5 High Carbon Steel
- **Motor:** 1000W Brushless Motor
- **Battery Type:** 21V 2000mAh Lithium Metal
- **Working Time:** 6 to 8 hours (per charge with two batteries)
- **Item Weight:** 700 Grams (1.54 pounds)
- **Product Dimensions:** 11.02"L x 4.49"W
- **Certifications:** CE, ROHS, UL, FCC, EMC

8. Warranty and Support

This product is covered by a return policy allowing for refund or replacement within 30 days of purchase. EU spare part availability duration is 18 months. For further assistance or warranty claims, please contact KOMOK customer support through your retailer or the official KOMOK website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B084ZVNSF7

More documents and user manuals: **https://manuals.plus/**