Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced STREAM-SYSTEM-BM32C1-3521

RemotesReplaced Remote Control User Manual

Model: STREAM-SYSTEM-BM32C1-3521

1. Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, specifically designed for the STREAM-SYSTEM BM32C1. This remote offers all the functionalities of your original remote without the need for complex setup codes. Simply insert the batteries and begin use.

It is a direct replacement, not a universal remote, ensuring full compatibility with your STREAM-SYSTEM BM32C1 device.

2. Product Overview

Familiarize yourself with the layout and functions of your new remote control.





Figure 2.1: Front view of the RemotesReplaced remote control, displaying all functional buttons.



Figure 2.2: Side view of the remote control, illustrating its profile and infrared emitter.

Button Functions:

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **TV/SAT/DVD/AUX:** Selects the input source (Television, Satellite, DVD player, Auxiliary input).
- **MENU:** Accesses the main menu of the connected device.
- **EXIT:** Exits the current menu or function.
- **SHIFT:** (Function may vary depending on device)
- **Number Pad (0-9):** Enters channel numbers or other numerical inputs.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel entry.
- **GUIDE:** Displays the electronic program guide (EPG).
- **SUB:** Accesses subtitle options.
- **SIZE:** Adjusts screen size or aspect ratio.
- **SETUP:** Accesses device setup options.
- **TEXT:** Toggles teletext display.
- **V+/V-:** Increases or decreases volume.
- **P+/P-:** Changes to the next or previous channel.
- **Navigation Buttons (Up, Down, Left, Right):** Navigates through menus and options.
- **OK:** Confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the device.
- **TV/DTV:** Switches between analog and digital television modes.
- **INFO:** Displays information about the current program or input.
- **EPG:** Electronic Program Guide (same as GUIDE).
- **FAV:** Accesses favorite channels list.
- **NET TV:** (Specific function for smart TVs, may launch internet services).
- **Color Buttons (Red, Green, Yellow, Blue):** Context-sensitive functions within menus or applications.
- **Playback Controls (Rewind, Play/Pause, Fast Forward):** Controls media playback.

3. Setup

3.1. Battery Installation

Your RemotesReplaced remote control requires two (2) AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.

3. Insert two AAA batteries, ensuring the positive (+) and negative (-) ends match the diagrams inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

Note: *Always replace both batteries at the same time. Do not mix old and new batteries, or different types of batteries.*

4. Operating Instructions

Once batteries are installed, the remote is ready for use with your STREAM-SYSTEM BM32C1 device. No programming or code entry is required.

4.1. Basic Operation

- **Turning On/Off:** Point the remote at your device and press the **POWER** button.
- **Changing Channels:** Use the **P+** or **P-** buttons to cycle through channels, or use the number pad to directly enter a channel number.
- **Adjusting Volume:** Use the **V+** or **V-** buttons to increase or decrease the volume. Press **MUTE** to silence the audio.
- **Selecting Input Source:** Press the corresponding input button (e.g., **TV**, **SAT**, **DVD**, **AUX**) to switch between connected devices.

4.2. Advanced Functions

- **Menu Navigation:** Press **MENU** to access the device's main menu. Use the navigation arrows (**Up, Down, Left, Right**) to move through options and **OK** to confirm. Press **EXIT** or **BACK** to leave the menu.
- **Electronic Program Guide (EPG):** Press **GUIDE** or **EPG** to view program listings.
- **Information Display:** Press **INFO** to display current program details.
- **Teletext/Subtitles:** Use **TEXT** for teletext and **SUB** for subtitle options.
- **Smart/Net TV Functions:** If your device supports it, press **NET TV** or the **SMART** button to access internet-connected features.
- **Media Playback:** Use the dedicated playback buttons (**Rewind, Play/Pause, Fast Forward**) for controlling media on compatible devices.

5. Maintenance

5.1. Battery Replacement

When the remote control's performance degrades (e.g., reduced range, unresponsive buttons), it's time to replace the batteries. Follow the steps in Section 3.1 for battery installation.

5.2. Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Do not use harsh chemicals or immerse the remote in water.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh ones.
  - Ensure there are no obstructions between the remote control and the device's infrared receiver.

- Make sure you are within the effective operating range (up to 10 meters).

- **Specific buttons not working:**
  - Clean around the button to ensure no debris is preventing it from pressing correctly.
  - If only one or a few buttons are unresponsive after checking batteries, the remote may be faulty and require replacement.

- **Device not switching inputs:**
  - Ensure the correct input button (TV, SAT, DVD, AUX) is being pressed for the desired device.
  - Verify that the external device (e.g., DVD player) is properly connected and powered on.

7. Specifications

Feature	Detail
Brand	RemotesReplaced
Model Number	STREAM-SYSTEM-BM32C1-3521
Connectivity Technology	Infrared
Compatible Devices	Television (STREAM-SYSTEM BM32C1)
Special Features	Ergonomic design
Battery Type	2 x AAA batteries (not included)
Maximum Range	10 Meters
Item Weight	120 Grams
Number of Buttons	(Approximate, based on image)
Controller Type	Button Control

8. Warranty and Support

This RemotesReplaced remote control comes with a **1-year warranty**, covering manufacturing defects and malfunctions under normal use.

For support or warranty claims, please refer to the contact information provided by your retailer or the RemotesReplaced official website. Keep your proof of purchase for warranty validation.

© 2024 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0851L13JY

More documents and user manuals: **https://manuals.plus/**