Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced NEON NE-50FLED

RemotesReplaced Replacement Remote Control for NEON NE-50FLED Television

Instruction Manual

1. Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, designed specifically for the NEON NE-50FLED television model. This remote functions as a direct replacement, offering all the original functionalities without requiring any complex setup codes.





Figure 1: Front view of the RemotesReplaced remote control. This image displays the full layout of buttons, including power, mute, channel numbers, volume controls, navigation, and various function keys.

2. Setup and Battery Installation

The RemotesReplaced remote control requires two AAA batteries for operation. No programming or setup codes are necessary.

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Close the battery compartment cover securely.
5. The remote is now ready for use with your NEON NE-50FLED television.



Figure 2: Side view of the RemotesReplaced remote control. This image shows the slim profile of the remote, which typically houses the battery compartment on the rear.

3. Operating Instructions

This remote control provides full functionality for your NEON NE-50FLED television. Below is a general guide to common button functions.

- **POWER:** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television audio.
- **TV/SAT/DVD/AUX:** Selects input sources.
- **MENU:** Accesses the television's main menu.
- **EXIT:** Exits the current menu or function.
- **Number Buttons (0-9):** Directly selects channels.
- **SOURCE:** Cycles through available input sources.
- **+/- (Channel Up/Down):** Changes television channels.
- **GUIDE:** Displays the electronic program guide (EPG).
- **VOL +/- (Volume Up/Down):** Adjusts the television volume.
- **Navigation Pad (Up, Down, Left, Right, OK):** Navigates through menus and confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **INFO:** Displays information about the current program.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels list.
- **SLEEP:** Sets a sleep timer for the television.
- **TV/DTV:** Switches between analog and digital television modes.
- **NET TV / SMART:** Accesses smart TV features or internet applications (if supported by your TV model).
- **Color Buttons (Red, Green, Yellow, Blue):** Functionality varies depending on the TV menu or application.
- **Playback Controls (Play, Pause, Fast Forward, Rewind):** Controls media playback.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).

- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage.
- **Avoid Damage:** Do not drop the remote, expose it to extreme temperatures, or immerse it in water.

5. Troubleshooting

If you encounter issues with your remote control, refer to the following troubleshooting steps:

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check for any obstructions between the remote's infrared emitter and the TV's IR receiver.
  - Ensure you are within the effective operating range (up to 10 meters).
- **Specific buttons not working:**
  - This remote is a direct replacement; all buttons should function as on the original. If a specific button does not work, ensure it is not stuck or obstructed.
  - Verify the TV is powered on and responsive to other remote commands.
- **Limited range:**
  - Replace batteries.
  - Ensure there are no strong light sources (like direct sunlight) interfering with the IR signal.

6. Specifications

Brand	RemotesReplaced
Model Number	NEON NE-50FLED
Connectivity Technology	Infrared
Compatible Devices	Television (NEON NE-50FLED)
Maximum Range	10 Meters
Batteries Required	2 AAA batteries
Item Weight	120 Grams

7. Warranty and Support

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described.
For technical support, warranty claims, or any questions regarding your remote control, please contact RemotesReplaced customer service through your purchase platform or the official RemotesReplaced website. Please have your purchase details and product model (NEON NE-50FLED) available when contacting support.

© 2023 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0851L25R2

More documents and user manuals: **https://manuals.plus/**