Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced QILIVE-Q.1649-7851

RemotesReplaced Replacement Remote Control User Manual

Model: **QILIVE-Q.1649-7851** | Brand: **RemotesReplaced**

Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, specifically designed for the QILIVE Q.1649 television model. While it is a replacement unit, it is not a generic universal remote; it is pre-programmed to function with your specific QILIVE device.
Key features of this remote control include:

- Direct replacement for the original QILIVE Q.1649 remote control.
- No setup codes required; ready to use after battery insertion.
- Full access to all original functions, including channel tuning.
- Guaranteed for 1 year from the date of purchase.

Setup

The RemotesReplaced remote control is designed for immediate use with your QILIVE Q.1649 television without the need for complex programming or code entry. Follow these simple steps to begin operation:

1. **Battery Installation:** Locate the battery compartment on the back of the remote control. Slide the cover downwards or press the latch to open it.
2. **Insert Batteries:** Insert two (2) AAA batteries into the compartment, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. **Close Compartment:** Replace the battery compartment cover, ensuring it clicks securely into place.
4. **Ready for Use:** The remote control is now ready to operate your QILIVE Q.1649 television. Point the remote directly at your television and begin using its functions.



Image: Side view of the RemotesReplaced remote control, illustrating the general location of the battery compartment.

Operating Instructions

This remote control utilizes infrared (IR) technology to communicate with your television. Ensure there is a clear line of sight between the remote's IR emitter (located at the front) and your television's IR receiver.





Image: Front view of the RemotesReplaced remote control, displaying all functional buttons.

Common Button Functions:

Button	Function
POWER	Turns the television on or off.
MUTE	Mutes or unmutes the television sound.
TV / SAT / DVD / AUX	Selects the input source (e.g., TV, Satellite, DVD player, Auxiliary input).
MENU / EXIT	Accesses the TV's main menu or exits the current menu.
Number Buttons (0-9)	Direct channel selection.
SOURCE	Cycles through available input sources.
+/- (Volume)	Adjusts the volume level.
P+/- (Channel)	Changes the television channel up or down.
Navigation Pad (Up, Down, Left, Right, OK)	Navigates through menus and confirms selections.
BACK	Returns to the previous screen or menu.
INFO / EPG / FAV	Accesses program information, Electronic Program Guide, or Favorite channels.
NET TV / SMART	Accesses smart TV features or internet-connected services.

Button	Function
Playback Controls (Play, Pause, Stop, Rewind, Fast Forward)	Controls media playback on compatible devices.

Note: Specific button functionalities may vary slightly depending on your QILIVE Q.1649 television's firmware and features.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Cleaning:** To clean the remote, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's finish or internal components.
- **Storage:** Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, it is advisable to remove the batteries to prevent leakage.
- **Avoid Drops:** Protect the remote from physical impact. Dropping the remote can damage its internal circuitry or external casing.

Troubleshooting

If you encounter issues with your RemotesReplaced remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check the batteries. Ensure they are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Ensure there is a clear line of sight between the remote and the television's IR receiver. Obstructions can block the signal.
  - Move closer to the television to rule out distance issues.
- **Specific Buttons Not Working:**
  - This could indicate a dirty contact under the button. Try gently pressing the button multiple times. If the issue persists, it may indicate internal damage.
- **Interference:**
  - Bright light sources, especially fluorescent lights or direct sunlight, can sometimes interfere with infrared signals. Try operating the remote in different lighting conditions.

If these steps do not resolve the issue, please refer to the warranty information for further assistance.

Specifications

Feature	Detail
Brand	RemotesReplaced
Model Number	QILIVE-Q.1649-7851
Compatible Devices	QILIVE Q.1649 Television

Feature	Detail
Connectivity Technology	Infrared (IR)
Special Features	Pre-programmed replacement remote (*Note: While listed as 'Universal' in some specifications, this remote is specifically designed as a replacement for the QILIVE Q.1649 and is not a generic universal remote requiring setup codes.*)
Batteries Required	2 x AAA batteries
Item Weight	120 Grams
Manufacturer	Linkwebb

Warranty and Support

This RemotesReplaced remote control is backed by a **1-year guarantee** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described.
For warranty claims or further support, please contact the seller or retailer from whom you purchased the product. Please retain your proof of purchase for warranty validation.

© 2024 RemotesReplaced. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0851L2TSK

More documents and user manuals: **https://manuals.plus/**