RemotesReplaced LED28W13

RemotesReplaced Replacement Remote Control for United LED28W13 TV

Model: LED28W13

Introduction

This manual provides comprehensive instructions for the RemotesReplaced replacement remote control, specifically designed for the United LED28W13 television model. This remote offers full functionality equivalent to the original device. Please read this manual carefully before use to ensure proper operation and longevity of your remote control.

Setup

1. Battery Installation

The remote control requires two AAA batteries for operation. Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

2. Initial Use

No setup codes or programming are required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your United LED28W13 television.

Operating Instructions

This remote control provides access to all standard functions of your United LED28W13 television. Point the remote control directly at the TV's infrared receiver for optimal performance.

Button Layout


POWER
MUTE
TV
SAT
DVD
AUX
MENU
EXIT
SHIFT
1
2
3
4
5
6
7
8
9
SOURCE
0
-/--
GUIDE
SUB
SIZE
SETUP
TEXT
V
P



This image displays the front view of the replacement remote control, highlighting its button layout and infrared emitter. Key buttons include

Power (red), Mute, Volume Up/Down, Channel Up/Down, Menu, and navigation controls.

Familiarize yourself with the button layout:

- **Power (Red Button):** Turns the television on or off.
- **Volume Up/Down:** Adjusts the audio volume.
- **Channel Up/Down:** Changes the television channel.
- **Mute:** Silences or restores the television audio.
- **Menu:** Accesses the television's main menu.
- **Navigation Buttons (Arrow Keys):** Used to navigate through menus and options.
- **OK/Enter:** Confirms selections in menus.
- **Source/Input:** Selects the input source (e.g., HDMI, AV).
- **Number Pad (0-9):** Directly enters channel numbers.

Maintenance

Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the TV's infrared receiver.
  - Make sure you are within the effective range of the TV's infrared receiver.
- **Some buttons not working:**
  - This remote is designed to replicate all original functions. If specific buttons are not working, ensure the TV is fully powered on and not in a specific mode that disables certain functions.
  - Try replacing the batteries.

Specifications

Brand	RemotesReplaced
Compatible Devices	Television (United LED28W13)
Connectivity Technology	Infrared
Number of Batteries Required	2 AAA
Item Weight	120 Grams

Model Number	UNITED-LED28W13-8832

Warranty and Support

Warranty Information

This RemotesReplaced remote control comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, troubleshooting assistance, or warranty claims, please contact RemotesReplaced customer support. Refer to the seller's information on your purchase platform for specific contact details.

© 2026 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question