Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced T40FX275DLBPOS-T2

RemotesReplaced Remote Control Instruction Manual

For TELEFUNKEN T40FX275DLBPOS-T2

Introduction

Thank you for choosing the RemotesReplaced remote control. This remote is a direct replacement, electronically identical to the original, and offers all the same functionalities for your TELEFUNKEN T40FX275DLBPOS-T2 television. This manual provides essential information for its proper setup, operation, and maintenance.

Product Overview

The RemotesReplaced remote control is designed for intuitive use, featuring a standard layout for easy navigation and control of your television. Below is an image illustrating the remote's front face with its various buttons.





Image Description: A full front view of the black RemotesReplaced remote control. It features a standard array of buttons including power, mute, input selection (TV, SAT, DVD, AUX), numerical keypad, navigation cluster with OK button, volume and channel controls, and various function buttons like Menu, Exit, Source, Guide, Info, EPG, Fav, Sleep, TV/DTV, NET TV, and media playback controls. The 'RemotesReplaced RRS41' logo is visible at the bottom.

Setup

This remote control requires no complex setup codes or programming. Simply install the batteries, and it will be ready for immediate use with your TELEFUNKEN T40FX275DLBPOS-T2 television.

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.

3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

Once batteries are installed, the remote is ready to operate your television.



Image Description: A side-angle view of the RemotesReplaced remote control, highlighting the top edge where the infrared (IR) emitter is located. This view also shows the slight curvature of the remote's body and the arrangement of buttons from a low perspective, emphasizing the IR transmission point.

Operating Instructions

This remote control provides full functionality for your TELEFUNKEN T40FX275DLBPOS-T2 television. Point the remote directly at your TV's infrared receiver for optimal performance.

Key Functions:

- **POWER:** Turns the television on or off.
- **MUTE:** Mutes or unmutes the television audio.
- **TV/SAT/DVD/AUX:** Selects different input sources.
- **MENU:** Accesses the television's main menu.
- **EXIT:** Exits the current menu or on-screen display.
- **SHIFT:** May provide access to secondary functions for certain buttons.
- **0-9 (Number Buttons):** Directly enters channel numbers.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel entry.
- **GUIDE:** Displays the electronic program guide (EPG).
- **SUB:** Activates or deactivates subtitles.
- **SIZE:** Adjusts screen display size or aspect ratio.
- **SETUP:** Accesses setup options.
- **TEXT:** Activates or deactivates Teletext.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the television channel.
- **Navigation (Arrows & OK):** Navigates through menus and confirms selections.
- **BACK:** Returns to the previous screen or menu.
- **INFO:** Displays information about the current program or input.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels list.

- **SLEEP:** Sets a sleep timer for the television.
- **TV/DTV:** Switches between analog and digital television modes.
- **NET TV / SMART:** Accesses smart TV features or internet-connected applications.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or smart TV applications.
- **Media Playback Controls (Rewind, Play, Fast Forward, Stop):** Controls media playback on compatible devices or applications.

Maintenance

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity.
  - Replace the batteries with fresh AAA batteries.
  - Ensure there is a clear line of sight between the remote's IR emitter and the TV's IR receiver. Remove any obstructions.
- **Limited range:**
  - Ensure batteries are fresh.
  - Reduce the distance between the remote and the television.
  - Avoid strong light sources (e.g., direct sunlight) that might interfere with the IR signal.

Specifications

Brand	RemotesReplaced
Model Number	TELEFUNKEN-T40FX275DLBPOS-T2-2921
Connections	Infrared
Compatible Devices	Television
Maximum Range	10 Meters
Number of Batteries	2 AAA (not included)
Item Weight	120 Grams

Warranty and Support

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.
For warranty claims, technical support, or any questions regarding your remote control, please contact RemotesReplaced customer service through your original point of purchase or visit the official RemotesReplaced website for contact information.

© 2023 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0851LB5D1

More documents and user manuals: **https://manuals.plus/**