RemotesReplaced FINLUX-XH24E401V-W-2921

RemotesReplaced Replacement Remote Control User Manual

Compatible with FINLUX XH24E401V-W

1. Introduction

Thank you for choosing the RemotesReplaced replacement remote control. This remote is specifically designed to be compatible with your FINLUX XH24E401V-W television, providing full functionality without the need for complex programming or setup codes. It serves as a direct replacement for your original remote.

Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.

2. Product Overview & Features

The RemotesReplaced remote control is engineered for seamless compatibility and ease of use. Key features include:

- **Direct Replacement:** Functions identically to your original FINLUX XH24E401V-W remote.
- **No Setup Required:** Ready to use right out of the box; no programming codes needed.
- **Full Functionality:** Accesses all original remote functions, including menu navigation and setup options.
- **Durable Design:** Built for reliable performance.
- **1-Year Guarantee:** Comes with a 1-year warranty for peace of mind.




MENU
EXIT
SHIFT
1
2
3
4
5
6
7
8
9
SOURCE
0
-/--
GUIDE
SUB
SIZE
SETUP
TEXT
V
P
OK
V
P
BACK
SLEEP
TV/DTV
INFO
EPG
FAV
NET TV
II
SMART
RemotesReplaced
RRS41



Figure 2.1: Front view of the RemotesReplaced replacement remote control. This image displays the full layout of the replacement remote control, showing all buttons including power, mute, number pad, navigation, volume, channel, and special function keys.



Figure 2.2: Side view of the RemotesReplaced replacement remote control. This image shows a side profile of the remote control, with a focus on the top edge where the infrared (IR) emitter is located, which sends signals to the television.

3. Setup

Setting up your RemotesReplaced remote control is quick and easy. No programming or pairing is required.

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery cover securely.

Your remote control is now ready for immediate use with your FINLUX XH24E401V-W television.

4. Operating Instructions

This remote control provides access to all standard functions of your FINLUX XH24E401V-W TV. Point the remote directly at the TV's infrared (IR) receiver for optimal performance.

4.1 Basic Functions

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or unmutes the TV sound.
- **VOL +/-:** Adjusts the volume level.
- **CH +/-:** Changes the TV channel.
- **Number Buttons (0-9):** Directly select channels.
- **SOURCE:** Cycles through input sources (HDMI, AV, etc.).

4.2 Menu Navigation

- **MENU:** Opens the TV's main menu.
- **Navigation Arrows (Up, Down, Left, Right):** Move through menu options.
- **OK:** Confirms a selection.
- **EXIT:** Exits the current menu or screen.
- **BACK:** Returns to the previous screen or menu.

4.3 Special Functions

- **GUIDE:** Displays the electronic program guide (EPG).
- **INFO:** Shows information about the current program.
- **SMART:** Accesses smart TV features (if supported by your TV model).
- **Colored Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or smart TV apps, as indicated on screen.

5. Maintenance

Proper care and maintenance will extend the life of your remote control.

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones.
- **Storage:** If the remote will not be used for an extended period, remove the batteries to prevent leakage. Store in a cool, dry place away from direct sunlight.
- **Avoid Drops:** Protect the remote from physical impact, as this can damage internal components.

6. Troubleshooting

If you experience issues with your remote control, try the following solutions:

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Make sure there are no obstructions between the remote and the TV's IR receiver.
  - Ensure you are within the effective range of the TV's IR receiver.
- **Only some buttons work:**
  - This often indicates low battery power. Replace batteries.
  - Clean the remote's surface and buttons to ensure no debris is interfering with button presses.
- **Remote does not control the TV:**
  - Confirm that your TV model is FINLUX XH24E401V-W. This remote is a specific replacement and

not a universal remote.
- Ensure the TV is powered on and its IR receiver is not blocked.

If the problem persists after trying these steps, please refer to the Warranty & Support section.

7. Specifications

Brand	RemotesReplaced
Model Number	FINLUX-XH24E401V-W-2921
Compatible Devices	Television (FINLUX XH24E401V-W)
Connectivity Technology	Infrared (IR)
Batteries Required	2 x AAA batteries
Item Weight	120 Grams

8. Warranty & Support

Your RemotesReplaced remote control is covered by a **1-year guarantee** from the date of purchase, ensuring protection against manufacturing defects.

For technical support, warranty claims, or any questions regarding your remote control, please contact the seller, **Remotes Replaced**, through your purchase platform. Please have your order details ready when contacting support.

For more information, you may visit the seller's page:Remotes Replaced Seller Information

© 2024 RemotesReplaced. All rights reserved.