RemotesReplaced QILIVE Q.1508

RemotesReplaced Remote Control Instruction Manual for QILIVE Q.1508

Model: QILIVE Q.1508 (Part Number: QILIVE-Q.1508-7851)

1. Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, specifically designed for compatibility with the QILIVE Q.1508 television model. This remote offers identical functionality to the original remote control, ensuring seamless operation of your device.

2. Setup and Battery Installation

The RemotesReplaced remote control for QILIVE Q.1508 requires no complex setup codes or programming. Simply install the batteries, and the remote will be ready for immediate use.

2.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, sliding it back into place until it clicks securely.

The remote control is now ready for operation with your QILIVE Q.1508 television.

3. Operating the Remote Control

This section details the primary functions of the buttons on your RemotesReplaced remote control. Point the remote directly at your QILIVE Q.1508 television's infrared receiver for optimal performance.




TV
SAT
DVD
AUX
MENU
EXIT
SHIFT
1
2
3
4
5
6
7
8
9
SOURCE
0
-/--
GUIDE
SUB
SIZE
SETUP
TEXT
V
P
OK
V
P
BACK
SLEEP
TV/DTV
INFO
EPG
FAV
NET TV
II
SMART
RemotesReplaced
RRS41



Figure 1: Front view of the RemotesReplaced remote control, displaying all functional buttons.

3.1. Key Functions Overview

- **POWER** (Red Button): Turns the television on or off.
- **MUTE**: Silences or restores the television's audio.
- **TV** / **SAT** / **DVD** / **AUX**: Selects the input source for the television.
- **MENU**: Accesses the main menu of the television.
- **EXIT**: Exits the current menu or on-screen display.
- **SHIFT**: May provide access to secondary functions of certain buttons (refer to your TV's manual for specific uses).
- **Number Buttons (0-9)**: Directly selects channels or enters numerical values.
- **SOURCE**: Cycles through available input sources.
- **-/--**: Toggles between single and double-digit channel entry.
- **GUIDE**: Displays the electronic program guide (EPG).
- **SUB**: Activates or deactivates subtitles.
- **SIZE**: Adjusts the screen display size or aspect ratio.
- **SETUP**: Accesses setup or settings menus.
- **TEXT**: Activates or deactivates teletext.
- **Volume Up/Down (V+, V-)**: Adjusts the audio volume.
- **Channel Up/Down (P+, P-)**: Changes the television channel.
- **Navigation Buttons (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms a selection or enters a menu item.
- **BACK**: Returns to the previous menu or screen.
- **SLEEP**: Sets a sleep timer for the television.
- **TV/DTV**: Switches between analog TV and digital TV modes.
- **INFO**: Displays information about the current program or input.
- **EPG**: Electronic Program Guide (same as GUIDE).
- **FAV**: Accesses favorite channels list.
- **NET TV** / **SMART**: Accesses smart TV features or internet-connected applications.
- **Playback Controls (Red, Green, Yellow, Blue, Play, Pause, Stop, Rewind, Fast Forward)**: Controls media playback functions, often used with smart TV apps or connected devices.

4. Maintenance

4.1. Battery Replacement

When the remote control's performance degrades or it stops responding, it is likely time to replace the batteries. Follow the battery installation steps outlined in Section 2.1. Always replace both batteries simultaneously with new AAA batteries.

4.2. Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or excessive moisture, as these can damage the remote's electronics.

5. Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are correctly inserted with the correct polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the television's infrared receiver.
  - Ensure you are pointing the remote directly at the television.
- **Specific buttons not working:**
  - Verify that the button is clean and not stuck.
  - If only certain functions are affected, consult your QILIVE Q.1508 television's original manual to confirm the function is supported by your TV model.
- **Short operating range:**
  - Replace the batteries.
  - Ensure there are no strong light sources (like direct sunlight) interfering with the infrared signal.

6. Specifications



Figure 2: Side view of the RemotesReplaced remote control, highlighting its design.

Feature	Detail
Brand	RemotesReplaced
Model Compatibility	QILIVE Q.1508 Television
Part Number	QILIVE-Q.1508-7851
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Batteries (not included)
Weight	120 Grams
Special Feature	No setup code required; ready to use

7. Warranty and Support

7.1. Warranty Information

This RemotesReplaced remote control comes with a one-year warranty. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and ensures the remote functions as described.

7.2. Customer Support

For further assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact RemotesReplaced customer support through your purchase platform or the official RemotesReplaced website. Provide your product model (QILIVE Q.1508) and any relevant purchase details when seeking support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question