RemotesReplaced MA.32HDT

RemotesReplaced Remote Control for MAGNADYNE MA.32HDT User Manual

Model: MA.32HDT | Brand: RemotesReplaced

1. Introduction

This document provides comprehensive instructions for the RemotesReplaced replacement remote control, specifically designed for the MAGNADYNE MA.32HDT television model. This remote is a direct replacement and is not a universal remote, ensuring full compatibility with your device without the need for complex programming.




4
5
6
7
8
9
SOURCE
0
-/--
GUIDE
SUB
SIZE
SETUP
TEXT
V
P
OK
V
P
BACK
SLEEP
TV/DTV
INFO
EPG
FAV



Figure 1: Overview of the RemotesReplaced remote control. This image shows the full remote control from a slight angle, highlighting its buttons and general design.

2. Setup: Battery Installation

The RemotesReplaced remote control requires two AAA batteries for operation. No setup codes or programming are necessary. Simply insert the batteries, and the remote will be ready for immediate use with your MAGNADYNE MA.32HDT television.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.



Figure 2: Side view of the remote control. This image displays the side profile of the remote, including the infrared emitter at the front, which transmits signals to the television.

3. Operating Instructions

This remote control provides full functionality for your MAGNADYNE MA.32HDT television, including all standard and advanced features. Point the remote control directly at the television's infrared receiver for optimal performance.

3.1 Basic Functions

- **Power Button ( )**: Press to turn the television on or off.
- **Volume Up/Down (VOL +/-)**: Adjusts the sound volume.
- **Channel Up/Down (CH +/-)**: Changes the television channel.
- **Number Buttons (0-9)**: Directly select channels or input numerical values.
- **Mute Button (MUTE)**: Silences or restores the television's audio.

3.2 Advanced Functions

- **Menu Button (MENU)**: Accesses the television's on-screen menu for settings and adjustments.
- **Input/Source Button (INPUT/SOURCE)**: Cycles through available input sources (e.g., HDMI, AV).
- **Navigation Buttons (Up, Down, Left, Right, OK)**: Used to navigate through menus and confirm selections.
- **Exit Button (EXIT)**: Closes the current menu or on-screen display.
- **Tuning Functions**: The remote supports all tuning functions available on the original remote. Refer to your television's manual for specific tuning procedures.

4. Maintenance

To ensure the longevity and optimal performance of your remote control, follow these simple maintenance guidelines:

- **Cleaning**: Wipe the remote control periodically with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, as these can damage the surface or internal components.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can cause damage. Store the remote in a cool, dry place.

5. Troubleshooting

If you experience issues with your remote control, please refer to the following common solutions:

- **Remote not responding**:
  - Ensure the remote is pointed directly at the television's infrared receiver.
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the television.
- **Specific buttons not working**:
  - Clean the remote control, especially around the problematic buttons, to remove any dirt or debris that might be preventing proper contact.
  - If only a few buttons are unresponsive after checking batteries, the remote may require replacement.
- **Television not responding to any remote commands**:
  - Verify that the television itself is powered on and functioning correctly.
  - Try using the manual controls on the television to confirm it is operational.

- Ensure the television's infrared receiver is not blocked or damaged.

6. Specifications

Brand	RemotesReplaced
Model Number	MAGNADYNE-MA.32HDT-8300
Compatible Devices	Television (MAGNADYNE MA.32HDT)
Connectivity Technology	Infrared
Number of Buttons	25
Controller Type	Button Control
Battery Type	2 x AAA batteries (not included)
Item Weight	120 Grams
Color	Black

7. Warranty and Support

This RemotesReplaced remote control is guaranteed for **1 year** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as intended for the specified MAGNADYNE MA.32HDT model.
For technical support, warranty claims, or any questions regarding the operation of your remote control, please contact the seller, Remotes Replaced, through the platform where the purchase was made. Please have your purchase details and model number (MAGNADYNE-MA.32HDT-8300) available when contacting support.

© 2026 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question