ZdalaMit fghea-621

ZdalaMit Remote Control Replacement for ONN TV LED HDTV ONC17TV001 User Manual

Brand: ZdalaMit | Model: fghea-621

1. Introduction

This manual provides comprehensive instructions for the ZdalaMit Remote Control Replacement, model fghea-621. This remote is specifically designed as a direct replacement for ONN LED HDTVs, ensuring compatibility with ONN TV model ONC17TV001. It requires no programming or pairing, offering immediate functionality upon battery installation.

Please read this manual carefully to ensure proper use and to maximize the lifespan of your remote control.

2. Package Contents

- 1 x ZdalaMit Remote Control Replacement (Model: fghea-621)

3. Setup

3.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or outwards to open it.
3. Insert two (2) 1.5V AAA Alkaline batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



This image shows the rear of the remote control with the battery cover detached, revealing the two AAA battery compartments. Observe the positive and negative terminals for correct battery insertion.

3.2 First Use

Once the batteries are correctly installed, the remote control is ready for immediate use with your compatible ONN TV. No additional programming, pairing, or setup steps are required.

4. Operating Instructions

Point the remote control directly at your ONN TV's infrared sensor. Press the desired buttons to control your television functions.



This image displays the front of the ZdalaMit remote control, highlighting the layout of all functional buttons, including power, input, volume, channel, and navigation controls.

4.1 Button Functions Overview

Button	Function
Power (Red Button)	Turns the television on or off.
INPUT	Selects the video input source (e.g., HDMI 1, HDMI 2, AV).
SAP/MTS	Switches between Secondary Audio Program or Multi-channel Television Sound.
CC	Toggles Closed Captions on or off.
TTS	Activates or deactivates Text-to-Speech functionality.
SLEEP TIMER	Sets a timer for the TV to automatically turn off.
INFO	Displays current program information.
MENU	Accesses the TV's main menu.
Navigation Arrows (Up, Down, Left, Right)	Navigates through menus and options.
OK	Confirms selections in menus.
BACK	Returns to the previous screen or menu.
EXIT	Exits the current menu or function.
VOL +/-	Adjusts the volume level.
MUTE	Mutes or unmutes the TV audio.
CH +/-	Changes the TV channel.
Number Buttons (0-9)	Directly enters channel numbers.
ENTER	Confirms channel selection or other numerical inputs.

5. Maintenance

5.1 Battery Replacement

Replace the batteries when the remote control's response becomes slow, inconsistent, or stops working. Always use new 1.5V AAA Alkaline batteries. Do not mix old and new batteries, or different types of batteries, as this can lead to leakage or damage.

5.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Avoid using liquid cleaners, solvents, or abrasive materials, as these can damage the remote's finish, buttons, or internal components.

6. Troubleshooting

6.1 Remote Not Responding

- **Check Battery Polarity:** Ensure that the AAA batteries are inserted correctly, matching the positive (+) and negative (-) terminals.

- **Replace Batteries:** If the batteries are old or depleted, replace them with a fresh pair of 1.5V AAA Alkaline batteries.
- **Remove Obstructions:** Ensure there are no objects blocking the line of sight between the remote control and the TV's infrared sensor.
- **Point Directly:** Make sure the remote is pointed directly at the TV's sensor.

6.2 Limited Range

- **Fresh Batteries:** Ensure the batteries are fresh and fully charged.
- **Clear Line of Sight:** Remove any objects that might be interfering with the infrared signal between the remote and the TV.

7. Specifications

- **Model:** fghea-621
- **Compatible TV Models:** ONN TV LED HDTV ONC17TV001
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Product Dimensions:** Approximately 4.5 x 1.2 x 0.5 inches
- **Item Weight:** Approximately 1.41 ounces
- **Special Feature:** Ergonomic design
- **Color:** Black

8. Warranty and Support

This product is a replacement remote control. For specific warranty information, please refer to the documentation provided at the time of purchase or contact the seller directly. For any support inquiries or further assistance, please reach out to ZdalaMit or your retailer.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question