Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit Compatible with Coby LEDTV3217, LEDTV5526, TFTV2325, TFTV5528, LEDTV3246, TFTV4208, TFTV1225

ZdalaMit Replacement Remote Control User Manual

Compatible with Coby LED TV Models: LEDTV3217, LEDTV5526, TFTV2325, TFTV5528, LEDTV3246, TFTV4208, TFTV1225

1. Introduction

This manual provides instructions for the ZdalaMit replacement remote control, designed for use with specific Coby LED TV models. This remote control requires no programming or pairing; simply insert batteries for operation.

2. Setup: Battery Installation

The remote control operates on two (2) 1.5V AAA Alkaline batteries.

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or in the direction indicated by an arrow to open it.
3. Insert two new AAA Alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into position until it clicks securely.

Important:
Do not use rechargeable batteries. Ensure batteries are inserted correctly to prevent damage or malfunction.

3. Operating Instructions

This replacement remote control is designed to function immediately with compatible Coby LED TV models once batteries are installed. No additional programming or pairing is required.

3.1. Basic Functions

- **Power Button:** Press to turn the TV on or off.
- **Mute Button:** Press to mute or unmute the TV audio.
- **Number Buttons (0-9):** Use to directly select channels.

- **Volume Up/Down (VOL +/-):** Adjusts the TV's volume level.
- **Channel Up/Down (CH +/-):** Changes the TV channel sequentially.
- **Source Button:** Selects input sources (e.g., HDMI, AV).
- **Menu Button:** Accesses the TV's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Exit Button:** Exits the current menu or on-screen display.
- **Return Button:** Returns to the previous screen or channel.

3.2. Remote Control Layout

Refer to the images below for a visual representation of the remote control's buttons and their functions.





Figure 1: Front view of the remote control, displaying all functional buttons.



Figure 2: Angled view of the remote control, illustrating its ergonomic shape.

4. Troubleshooting

- **Remote not responding:**
  - Ensure new AAA Alkaline batteries are correctly installed with proper polarity.
  - Check if the TV is powered on.
  - Remove any obstructions between the remote control and the TV's infrared sensor.
  - Try replacing the batteries with a fresh set.
- **Remote only works intermittently:**
  - This may indicate low battery power. Replace batteries.

- Ensure you are within the effective range and line of sight of the TV's IR sensor.

- **Remote does not control other devices:**
  - This remote is specifically designed for compatible Coby LED TVs and will not program to control DVD players, cable boxes, or other devices.

- **Remote does not work with your Coby TV model:**
  - Verify that your TV model is listed as compatible (LEDTV3217, LEDTV5526, TFTV2325, TFTV5528, LEDTV3246, TFTV4208, TFTV1225). If your model is not listed, this remote may not be compatible.

5. Product Specifications

- **Brand:** ZdalaMit
- **Compatible Devices:** Coby LED TVs (LEDTV3217, LEDTV5526, TFTV2325, TFTV5528, LEDTV3246, TFTV4208, TFTV1225)
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Product Dimensions:** 5.3 x 1.4 x 0.5 inches (approximately)
- **Item Weight:** 1.95 ounces (approximately)
- **Special Feature:** Ergonomic design
- **Color:** Black

6. Warranty and Support

For any queries or assistance regarding this product, please contact the seller directly. Information regarding specific warranty terms may be available from your point of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08536KV5G

More documents and user manuals: **https://manuals.plus/**