ZdalaMit AXD7661

ZdalaMit AXD7661 Replacement Remote Control User Manual

For Pioneer AV Receiver Models VSX-822-K, VSX-1022-K, VSX-1022

Introduction

This manual provides comprehensive instructions for the ZdalaMit AXD7661 replacement remote control. This remote is designed to be fully compatible with various Pioneer AV Receiver models, including VSX-822-K, VSX-1022-K, VSX822K, VSX1022K, and VSX-1022. Please read this manual carefully to ensure proper setup and operation of your new remote control.

Setup

Battery Installation

The AXD7661 remote control requires two (2) 1.5V AAA alkaline batteries for operation. Batteries are not included with the remote control.

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: The ZdalaMit AXD7661 replacement remote control. The battery compartment is located on the back, typically at the bottom.

No Programming or Pairing Required

This replacement remote control is pre-programmed for the specified Pioneer AV Receiver models. No additional programming or pairing steps are required. Once batteries are installed, the remote is ready for immediate use.

Operating Instructions

Familiarize yourself with the button layout and functions of your AXD7661 remote control.



Image: Front view of the ZdalaMit AXD7661 remote control, highlighting the various function buttons.

- **RECEIVER (Power)**: Press to turn the Pioneer AV Receiver on or off.
- **INPUT SELECT**: Use these buttons (NETWORK, BD, DVD, DVR/BDR, SAT/CBL, GAME, VIDEO, CD, TV, TUNER, iPod/USB, ADAPTER) to select the desired input source on your AV Receiver.
- **VOLUME +/-**: Adjusts the master volume level of the AV Receiver.

- **MUTE**: Temporarily silences the audio output. Press again to restore sound.
- **Navigation Buttons (Up, Down, Left, Right Arrows) & ENTER**: Used for navigating menus and confirming selections on the AV Receiver's display.
- **TOOLS MENU**: Accesses the main menu or settings menu of the AV Receiver.
- **AUDIO PARAMETER**: Accesses audio settings and adjustments.
- **PRESET +/-**: Navigates through radio station presets or other stored settings.
- **TUNE +/-**: Adjusts radio frequencies manually.
- **BAND**: Switches between different radio bands (e.g., AM/FM).
- **RETURN**: Returns to the previous menu or screen.
- **Playback Controls (Play, Pause, Stop, Fast Forward, Rewind, Skip)**: Controls playback for connected media devices (e.g., DVD/Blu-ray player).
- **BASS +/-**: Adjusts the bass level.
- **TRE +/-**: Adjusts the treble level.
- **EQ, PHASE, SIGNAL SEL, S.RETRIEVER, SBCH, CH SELECT, DISP**: These buttons provide access to various audio processing, channel selection, and display options specific to your Pioneer AV Receiver. Refer to your receiver's manual for detailed functions.
- **CH +/-**: Changes channels on a connected tuner or cable/satellite box.
- **Numeric Keypad (0-9, +10, ENTER)**: Used for direct input of channel numbers or other numerical selections.
- **DIMMER**: Adjusts the brightness of the AV Receiver's display.
- **CLR (Clear)**: Clears current input or selection.
- **SHIFT**: Used in conjunction with other buttons to access secondary functions (indicated by smaller text above or below primary button labels).

Maintenance

To ensure the longevity and optimal performance of your remote control, follow these maintenance guidelines:

- **Cleaning**: Wipe the remote control with a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or buttons.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or it stops functioning. Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
- **Storage**: If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops and Impacts**: Protect the remote from physical shock, as internal components can be damaged.

Troubleshooting

If you encounter issues with your ZdalaMit AXD7661 remote control, please refer to the following troubleshooting steps:

- **Remote Not Responding**:
  - **Check Batteries**: Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new AAA alkaline batteries.
  - **Line of Sight**: Make sure there is a clear line of sight between the remote control and the infrared sensor on your Pioneer AV Receiver. Obstructions can block the signal.

    - **Distance**: Ensure you are within the effective operating range of the remote control.
    - **Receiver Power**: Confirm that your Pioneer AV Receiver is powered on.
- **Limited Functionality or Incorrect Commands**:
    - **Input Selection**: Verify that the correct input source is selected on your AV Receiver for the device you are trying to control. For example, if controlling a Blu-ray player, ensure the receiver's input is set to "BD" or the corresponding input.
    - **Receiver Compatibility**: Double-check that your Pioneer AV Receiver model is listed as compatible with the AXD7661 remote control (VSX-822-K, VSX-1022-K, VSX822K, VSX1022K, VSX-1022).

If these steps do not resolve the issue, please contact the seller or manufacturer for further assistance.

Specifications

Model Number	AXD7661
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Product Dimensions	5.8 x 1.5 x 0.6 inches (14.7 x 3.8 x 1.5 cm)
Item Weight	0.704 ounces (20 grams)
Connectivity Technology	Infrared (IR)
Compatible Devices	Pioneer AV Receivers (VSX-822-K, VSX-1022-K, VSX822K, VSX1022K, VSX-1022)

Warranty and Support

For specific warranty information regarding your ZdalaMit AXD7661 replacement remote control, please refer to the documentation provided by your retailer or the manufacturer at the time of purchase. Warranty terms may vary.

If you have any questions, require technical assistance, or need to report an issue with your remote control, please contact the seller or manufacturer directly. They will be able to provide the most accurate and timely support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question