Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit AXD7692

ZdalaMit AXD7692 Replacement Remote Control User Manual

For Pioneer AV Receiver Models: VSX-43, VSX-828, VSX-528, VSX-1012-K, VSX-AX5i-G, VSX-828-K, VSX-828-S, VSX-528-K, VSX-528-S

1. Introduction

This manual provides instructions for the ZdalaMit AXD7692 replacement remote control. This remote is designed to function as a direct replacement for the original remote controls of various Pioneer AV Receiver models. It requires no programming or pairing; simply insert batteries, and it is ready for immediate use.

Compatible Pioneer AV Receiver Models:

- VSX-43
- VSX-828
- VSX-528
- VSX43
- VSX828
- VSX528
- VSX-1012-K
- VSX-AX5i-G
- VSX-828-K
- VSX-828-S
- VSX-528-K
- VSX-528-S



Image 1.1: Front view of the ZdalaMit AXD7692 replacement remote control. It features a black casing with clearly labeled buttons for various audio and video functions, including power, input select, volume, channel, and navigation controls.

2. Setup: Battery Installation

The ZdalaMit AXD7692 remote control operates on two AAA alkaline batteries. Batteries are not included with the remote control and must be purchased separately.

1. **Locate the Battery Compartment:** Turn the remote control over to its back. The battery compartment cover is typically located on the lower half of the remote.
2. **Open the Battery Compartment:** Gently slide the battery compartment cover downwards or press the latch and lift it off.
3. **Insert Batteries:** Insert two 1.5V AAA alkaline batteries into the compartment. Ensure that the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment. Incorrect insertion can prevent the remote from functioning.
4. **Close the Battery Compartment:** Replace the battery compartment cover by sliding it back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with your compatible Pioneer AV Receiver. No additional programming or pairing steps are required.



Image 2.1: Angled view of the ZdalaMit AXD7692 remote control, highlighting its ergonomic design and button layout. This perspective shows the slight curvature of the remote, designed for comfortable handling.

3. Operating Instructions

The ZdalaMit AXD7692 remote control provides full functionality for your compatible Pioneer AV Receiver. The button layout is designed to mimic the original remote for ease of use.

Basic Functions:

- **Power On/Off:** Use the **RECEIVER** button (usually at the top left) to power your AV receiver on or off.
- **Input Selection:** Buttons such as **INPUT SELECT**, **BD**, **DVD**, **SAT/CBL**, **CD**, **TV**, **TUNER**, **NETWORK**, **iPod/USB**, and **ADAPTER** allow you to switch between different audio/video sources connected to your receiver.
- **Volume Control:** The **VOL +** and **VOL -** buttons (typically on the right side) adjust the master volume level.
- **Mute:** Press the **MUTE** button to temporarily silence the audio output. Press it again to restore sound.
- **Navigation and Enter:** The circular navigation pad with **UP**, **DOWN**, **LEFT**, **RIGHT**, and **ENTER** buttons is used to navigate menus and confirm selections on your receiver's display.
- **Menu Access:** Buttons like **TOOLS MENU** and **TOP MENU** provide access to the receiver's settings and on-screen menus.
- **Audio Parameters:** The **AUDIO PARAMETER** button allows adjustment of various audio settings.

Refer to your Pioneer AV Receiver's original instruction manual for detailed information on specific functions and advanced settings accessible via the remote control.

4. Maintenance

Proper care of your remote control will ensure its longevity and reliable performance.

- **Cleaning:** Use a soft, dry cloth to wipe the remote control. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface and buttons.
- **Battery Replacement:** Replace batteries promptly when the remote's performance degrades or it stops responding. Always replace both batteries at the same time with new ones of the same type (AAA alkaline). Do not mix old and new batteries, or different types of batteries.
- **Storage:** Store the remote control in a cool, dry place, away from direct sunlight, extreme temperatures, and high humidity.
- **Avoid Drops and Impacts:** Protect the remote from physical damage by avoiding drops and impacts.
- **Liquid Exposure:** Keep the remote control away from liquids. If liquid spills on the remote, remove the batteries immediately and allow it to dry completely before reinserting them.

5. Troubleshooting

If you experience issues with your ZdalaMit AXD7692 remote control, please refer to the following troubleshooting steps:

1. **Remote Not Responding:**
    - **Check Batteries:** Ensure that the batteries are inserted correctly with the correct polarity (+/-). Replace old or depleted batteries with new 1.5V AAA alkaline batteries.
    - **Line of Sight:** Make sure there is a clear line of sight between the remote control and the infrared sensor on your Pioneer AV Receiver. Obstructions can block the signal.
    - **Remote Sensor:** Verify that the remote's infrared emitter (usually at the top front) is not blocked or dirty.
    - **Receiver Sensor:** Ensure the infrared sensor on your AV receiver is clean and unobstructed.
2. **Specific Buttons Not Working:**

- If only certain buttons are unresponsive, it might indicate dirt or debris under the button. Gently press the button multiple times to dislodge any obstruction. Avoid excessive force.
- If the issue persists, the button mechanism might be faulty.

3. **Remote Works Intermittently:**
   - This often indicates low battery power. Replace both batteries.
   - Ensure the battery contacts inside the compartment are clean and making good contact with the batteries.
4. **Remote Does Not Control TV Functions:**
   - This replacement remote is primarily designed for controlling Pioneer AV Receivers. While some original Pioneer remotes may have universal TV control capabilities, this specific replacement model (AXD7692) may not support programming for external TV devices. Its primary function is to operate the compatible Pioneer AV Receiver models listed.

If these steps do not resolve the issue, please contact customer support for further assistance.

6. Specifications

Model Number	AXD7692
Brand	ZdalaMit
Power Supply	2 x 1.5V AAA Alkaline Batteries (not included)
Compatible Devices	Pioneer AV Receivers (specific models listed in Introduction)
Dimensions	6.2 x 1.5 x 0.6 inches (15.75 x 3.81 x 1.52 cm)
Item Weight	1.41 ounces (40 grams)
Special Feature	Pre-programmed (no setup required)
Color	Black

7. Support

For any questions, concerns, or assistance regarding your ZdalaMit AXD7692 replacement remote control, please contact the seller or manufacturer directly. Refer to your purchase documentation for contact information.
While this remote is designed for ease of use, if you encounter persistent issues not covered in the troubleshooting section, professional assistance may be required for your AV receiver itself.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0855MFWP5

More documents and user manuals: **https://manuals.plus/**