Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Brandson 68416854

Brandson 108cm Tower Fan with Remote Control

User Manual

1. Introduction

Thank you for choosing the Brandson 108cm Tower Fan. This manual provides essential information for the safe and efficient operation of your new fan. Please read these instructions carefully before use and keep them for future reference. The Brandson tower fan is designed to provide powerful and refreshing airflow. It features three speed settings, four operating modes, a timer function, 65° oscillation, and a 10° upward tilt capability, all controllable via the included remote control or the integrated LED display.

2. Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following safety precautions:

- Ensure the power supply voltage matches the rating label on the fan.
- Do not operate the fan with a damaged cord or plug. If the cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.
- Unplug the fan from the power outlet when not in use, before cleaning, or before moving it.
- Do not insert fingers or any objects through the grille when the fan is operating.
- Keep the fan away from water or other liquids. Do not use it in wet or damp environments.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Place the fan on a stable, flat surface to prevent it from tipping over.
- Do not cover the fan or obstruct the air inlets/outlets.

3. Package Contents

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, contact customer support.

- Brandson Tower Fan Unit
- Base Plate (two halves)
- Remote Control
- User Manual

4. Setup

1. **Assemble the Base:** The base plate consists of two halves. Align and snap them together.
2. **Attach the Base to the Fan:** Carefully place the main fan unit onto the assembled base. Secure the base to the bottom of the fan using the three supplied screws. No additional tools are required for this step.
3. **Position the Fan:** Place the fan on a stable, level surface. Ensure there is adequate space around the fan for proper airflow and oscillation.
4. **Connect Power:** Plug the power cord into a standard electrical outlet (220-240V AC, 50/60Hz).



Image: The Brandson Tower Fan showing its 108cm height, 31cm base diameter, 10° tilt, and 65° oscillation. Examples of placement in living room, bedroom, and office are also shown.

5. Operating the Fan

5.1 Control Panel

The fan can be operated using the touch control panel located on the top of the unit or with the remote control.



Image: Close-up of the Brandson Tower Fan's LED display and touch control panel, showing buttons for power, speed, mode, oscillation, and timer. The remote control is also pictured, mirroring these functions.

5.2 Remote Control

The infrared remote control allows convenient operation of all functions from a distance. Ensure the remote control is pointed towards the fan's receiver.

- **Power Button:** Turns the fan On/Off.
- **Speed Button:** Cycles through 3 speed levels (Low, Medium, High).
- **Mode Button:** Selects one of the 4 operating modes (Normal, Natural, Sleep, Child).
- **OSC (Oscillation) Button:** Activates or deactivates the 65° oscillation function.
- **Timer Button:** Sets the auto-off timer from 1 to 12 hours.
- **LED Button:** Turns the LED display On/Off.



Image: The Brandson Tower Fan showing a convenient, ultra-slim storage slot for the remote control integrated into the side of the fan unit.

5.3 Operating Modes

- **Normal Mode:** Provides a constant airflow at the selected speed.
- **Natural Mode:** Simulates a natural breeze by varying the fan speed intermittently.
- **Sleep Mode:** Gradually decreases the fan speed over time and then switches off.
- **Child Mode:** Starts at speed level 3, decreases one level every 15 minutes, continues at level 1, and switches off after 3 hours.

5.4 Tilt Function

The fan head can be manually tilted upwards by 10° to direct airflow more effectively.



Image: The Brandson Tower Fan shown with its upper section tilted upwards by 10 degrees, illustrating the adjustable airflow direction.

6. Maintenance

Regular cleaning helps maintain the fan's performance and extends its lifespan.

- **Cleaning the Exterior:** Unplug the fan before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Cleaning the Air Inlets/Outlets:** Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and outlet grilles.
- **Storage:** If storing the fan for an extended period, unplug it, clean it thoroughly, and store it in a cool, dry place, preferably in its original packaging.

7. Troubleshooting

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Power button not pressed; Remote control batteries depleted.	Check power cord connection and outlet; Press the power button on the unit or remote; Replace remote control batteries.
Weak airflow	Fan speed set too low; Air inlets/outlets blocked by dust.	Increase fan speed; Clean air inlets/outlets.
Fan makes unusual noise	Fan not on a stable surface; Internal obstruction; Loose base connection.	Place fan on a flat, stable surface; Unplug and check for obstructions; Ensure base is securely attached. If noise persists, contact support.
Remote control not working	Batteries depleted; Obstruction between remote and fan; Remote not pointed correctly.	Replace batteries; Remove obstructions; Point remote directly at the fan's receiver.
Oscillation not working	Oscillation function not activated.	Press the OSC button on the control panel or remote control.

8. Specifications

Model Number	68416854
Dimensions (H x W x D)	108 cm x 31 cm x 31 cm (approx.)
Weight	6.42 kg
Power Supply	220-240 V AC, 50/60 Hz
Power Consumption	Max. 45 W
Noise Level	40 dBA (at Level 1)
Speed Settings	3
Operating Modes	4 (Normal, Natural, Sleep, Child)
Oscillation Angle	65°
Tilt Angle	10° (upward)
Cable Length	1.35 m
Control Type	Remote Control, Touch Panel

9. Warranty and Support

Brandson products are manufactured to high-quality standards. For any questions, technical issues, or warranty claims,

please contact Brandson customer support. Keep your proof of purchase for warranty purposes.
For further assistance, please visit the official Brandson website or contact your retailer.

© 2024 Brandson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08563K1SG

More documents and user manuals: **https://manuals.plus/**