Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Simple Houseware CB-10C-G

Simple Houseware 3-Tier Heavy Duty Metal Utility Rolling Cart User Manual

Model: CB-10C-G | Brand: Simple Houseware

Introduction

This manual provides essential information for the assembly, operation, and maintenance of your Simple Houseware 3-Tier Heavy Duty Metal Utility Rolling Cart. Please read these instructions carefully before assembly and retain for future reference.





Image: The Simple Houseware 3-Tier Heavy Duty Metal Utility Rolling Cart in Silver, showcasing its three spacious baskets and sturdy frame.

Safety Information

- Ensure all parts are present and undamaged before assembly.
- Do not overtighten screws during assembly to avoid stripping or damaging components.
- Distribute weight evenly across the baskets to maintain stability.
- Engage the locking casters when the cart needs to remain stationary.
- Keep small parts away from children during assembly.

Package Contents

Verify that all components listed below are included in your package:

- 3 x Metal Baskets
- 2 x Side Frames with Handles
- 4 x Heavy-Duty Casters (2 with locking mechanism)
- Connecting Rods/Bars
- Assembly Hardware (screws, nuts, Allen key)
- Optional: Hanging Hooks (quantity may vary)

Setup and Assembly

Follow these steps to assemble your utility cart:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Check against the package contents list.

2. **Attach Casters:** Screw the four casters into the designated holes at the bottom of the two side frames. Ensure the two locking casters are positioned diagonally opposite each other for optimal stability.
3. **Connect Side Frames:** Attach the connecting rods between the two side frames using the provided screws and Allen key. Do not fully tighten the screws yet.
4. **Insert Baskets:** Slide each metal basket into the grooves on the side frames. The baskets should fit snugly.
5. **Secure Baskets:** Once all baskets are in place, fully tighten all screws on the connecting rods and side frames to secure the structure.
6. **Attach Hooks (Optional):** If included, attach the hanging hooks to the top basket's edge as desired.

Assembly typically takes 20-40 minutes. It is recommended to have a second person to assist with stabilizing parts during initial assembly.

Operating Instructions

Your Simple Houseware Utility Cart is designed for versatile storage and easy mobility.

- **Mobility:** The cart is equipped with 4 heavy-duty 2-inch casters for smooth movement across various floor surfaces. Use the curved top handles for easy maneuverability.
- **Locking Mechanism:** Two of the casters feature a locking mechanism. To engage the lock, press down on the lever located on the caster. To unlock, lift the lever. This ensures the cart remains stationary when needed.
- **Storage:** Utilize the three spacious metal baskets for organizing items. The mesh design of the baskets allows for airflow and visibility of contents.



Image: Cart used in an office environment, demonstrating its suitability for storing office supplies and equipment.



Image: Close-up of the cart's top basket filled with various office supplies, including pens, paper, and a calculator.



Image: The cart positioned in a garage, holding tools and automotive liquids, highlighting its heavy-duty capacity.



Image: Cart used in a kitchen, storing pantry items and dishes, demonstrating its versatility for household organization.

Maintenance and Care

To ensure the longevity and optimal performance of your utility cart, follow these maintenance guidelines:

- **Cleaning:** Wipe down the metal frame and baskets with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Caster Maintenance:** Periodically check the casters for any accumulated debris (hair, lint, etc.) and clean as necessary to ensure smooth rolling.
- **Tighten Fasteners:** Over time, screws may loosen. Periodically check all fasteners and tighten them with the provided Allen key to maintain the cart's stability.
- **Avoid Overloading:** Do not exceed the recommended weight capacity for each basket to prevent damage to the cart.

Troubleshooting

Problem	Possible Cause	Solution
Cart is wobbly or unstable.	Loose fasteners; uneven weight distribution.	Ensure all screws are fully tightened. Redistribute items evenly across baskets.
Casters do not roll smoothly.	Debris caught in casters; casters locked.	Clean any debris from the casters. Ensure locking levers are in the unlocked position.

Problem	Possible Cause	Solution
Baskets do not fit into frame.	Side frames not properly aligned or screws overtightened prematurely.	Loosen side frame screws slightly, adjust alignment, insert baskets, then retighten.

Specifications

- **Product Dimensions:** 12.5"D x 17"W x 31.5"H
- **Brand:** Simple Houseware
- **Material:** Steel, Metal
- **Color:** Silver
- **Special Features:** Locking Caster, Mobility, Sturdy
- **Number of Shelves:** 3
- **Item Weight:** 7.28 pounds (3.31 Kilograms)
- **Number of Wheels:** 4
- **Assembly Required:** Yes
- **Model Number:** CB-10C-G
- **UPC:** 811244034733



Image: Diagram showing the dimensions of the utility cart: 12.5 inches deep, 17 inches wide, and 31.5 inches high.

Warranty and Support

For warranty information or product support, please contact Simple Houseware customer service directly. Refer to the product packaging or the Simple Houseware official website for contact details.

© 2023 Simple Houseware. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0856Y3GHG

More documents and user manuals: **https://manuals.plus/**